ITU-T

Q.781

TELECOMMUNICATION STANDARDIZATION SECTOR OF ITU (03/93)

# SPECIFICATIONS OF SIGNALLING SYSTEM No. 7

# SIGNALLING SYSTEM No. 7 - MTP LEVEL 2 TEST SPECIFICATION

# ITU-T Recommendation Q.781

(Previously "CCITT Recommendation")

#### **FOREWORD**

The ITU Telecommunication Standardization Sector (ITU-T) is a permanent organ of the International Telecommunication Union. The ITU-T is responsible for studying technical, operating and tariff questions and issuing Recommendations on them with a view to standardizing telecommunications on a worldwide basis.

The World Telecommunication Standardization Conference (WTSC), which meets every four years, established the topics for study by the ITU-T Study Groups which, in their turn, produce Recommendations on these topics.

ITU-T Recommendation Q.781 was revised by the ITU-T Study Group XI (1988-1993) and was approved by the WTSC (Helsinki, March 1-12, 1993).

#### NOTES

As a consequence of a reform process within the International Telecommunication Union (ITU), the CCITT ceased to exist as of 28 February 1993. In its place, the ITU Telecommunication Standardization Sector (ITU-T) was created as of 1 March 1993. Similarly, in this reform process, the CCIR and the IFRB have been replaced by the Radiocommunication Sector.

In order not to delay publication of this Recommendation, no change has been made in the text to references containing the acronyms "CCITT, CCIR or IFRB" or their associated entities such as Plenary Assembly, Secretariat, etc. Future editions of this Recommendation will contain the proper terminology related to the new ITU structure.

In this Recommendation, the expression "Administration" is used for conciseness to indicate both a telecommunication administration and a recognized operating agency.

#### © ITU 1994

All rights reserved. No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the ITU.

# **CONTENTS**

		Page
1	Introduction	1
2	General principles of level 2 tests	1
3	Test configuration	1
4	Test environment.	2
5	Test list	2
6	Test descriptions	4

# SIGNALLING SYSTEM No. 7 – MTP LEVEL 2 TEST SPECIFICATION

(Melbourne, 1988; modified at Helsinki, 1993)

#### 1 Introduction

This Recommendation contains a set of detailed tests of signalling system No. 7 MTP level 2 protocol. These tests intend to validate the protocol specified in Recommendation Q.703.

This Recommendation conforms to Recommendation Q.780 which describes the basic rules of the Test Specification. In addition the conditions which are specific to level 2 tests are described in the following clauses.

#### **2** General principles of level 2 tests

#### 2.1 Presentation of test descriptions

The level 2 tests aim at testing the level 2 protocol conformance in a given implementation.

Each test description indicates in the "type of test" column; "Validation" (VAT) or "Validation" (VAT) and "compatibility" (CPT).

Although signal units are transmitted and received continuously on level 2, only the signal units which cause and/or indicate the changes of level 2 status are shown in the EXPECTED SIGNAL UNIT SEQUENCE column of each test description.


#### 2.2 Presentation of the test list

These tests as a whole, aim at a complete validation of the level 2 protocol without redundancies. Each test is described as simply as possible to check precisely each elementary function of the protocol, which is referred in the columns "reference", "title" and "sub-title" of each test description.

This list is presented in the form of a succession of tests. The presentation order is essentially functional. However, the operator performing these tests may change this order, taking into account some other practical criteria such as: use pre-test conditions to order the list, the end of a given test may be the pre-test condition of another test.

#### 3 Test configuration

A single link will be used for level 2 tests. Figure 1 shows a single link between SP A and SP B. Test specifications are written to test the level 2 of the SP A.



NOTE – First digit: linkset number. Second digit: link number.

FIGURE 1/Q.781

Test configuration of MTP level 2 test Configuration 1

#### 4 Test environment

See 6.2/Q.780.

#### 5 Test list

NOTE - Compatibility test items are indicated in this list by an asterisk (\*).

The abbreviations PO, LPO, RPO, EM and EDA are used for processor outage, local processor outage, remote processor outage, emergency and expected delay of acknowledgement, respectively.

- 1 Link State Control Expected signal units/orders (see Figures 8/Q.703 and 9/Q.703)
- \* 1.1 Initialisation (Power-up)
- \* 1.2 Timer T2
  - 1.3 Timer T3
  - 1.4 Timer T1 and T4 (Normal)
- 1.5 Normal alignment correct procedure (FISU)
  - 1.6 Normal alignment correct procedure (MSU)
  - 1.7 SIO received during normal proving period
  - 1.8 Normal alignment with PO set (FISU)
  - 1.9 Normal alignment with PO set (MSU)
  - 1.10 Normal alignment with PO set and clear
  - 1.11 Set RPO when "Aligned not ready"
  - 1.12 SIOS received when "Aligned not ready"
  - 1.13 SIO received when "Aligned not ready"
  - 1.14 Set and clear LPO when "Initial alignment"
  - 1.15 Set and clear LPO when "Aligned ready"
  - 1.16 Timer T1 in ""Aligned not ready" state
  - 1.17 No SIO sent during normal proving period
  - 1.18 Set and cease emergency prior to "start alignment"
- \* 1.19 Set emergency while in "not aligned state"
  - 1.20 Set emergency when "aligned"
  - 1.21 Both ends set emergency
  - 1.22 Individual end sets emergency
  - 1.23 Set emergency during normal proving
  - 1.24 No SIO sent during emergency alignment
- \* 1.25 Deactivation during initial alignment
  - 1.26 Deactivation during aligned state
  - 1.27 Deactivation during aligned not ready
  - 1.28 SIO received during link in service
- \* 1.29 Deactivation during link in service
  - 1.30 Deactivation during LPO
  - 1.31 Deactivation during RPO
- \* 1.32 Deactivation during the proving period
  - 1.33 SIO received instead of FISUs
  - 1.34 SIOS received instead of FISUs
  - 1.35 SIPO received instead of FISUs

2

- 2 Link State Control Unexpected signal units/orders (see Figure 8/Q.703)
  - 2.1 Unexpected signal units/orders in "Out of service" state
  - 2.2 Unexpected signal units/orders in "Not aligned" state
  - 2.3 Unexpected signal units/orders in "Aligned" state
  - 2.4 Unexpected signal units/orders in "Proving" state
  - 2.5 Unexpected signal units/orders in "Aligned ready" state
  - 2.6 Unexpected signal units/orders in "Aligned not ready" state
  - 2.7 Unexpected signal units/orders in "In service" state
  - 2.8 Unexpected signal units/orders in "Processor outage" state
- 3 *Transmission failure* (see Figure 8/Q.703)
  - 3.1 Link aligned ready (Break Tx path)
  - 3.2 Link aligned ready (Corrupt FIBs)
  - 3.3 Link aligned not ready (Break Tx path)
  - 3.4 Link aligned not ready (Corrupt FIBs)
  - 3.5 Link in service (Break Tx path)
  - 3.6 Link in service (Corrupt FIBs Basic)
  - 3.7 Link in processor outage (Break Tx path)
  - 3.8 Link in processor outage (Corrupt FIBs Basic)
- 4 Processor Outage Control (see Figure 10/Q.703)
  - 4.1 Set and clear LPO while link in service
  - 4.2 RPO during LPO
  - 4.3 Clear LPO when "Both processor outage"
- 5 SU Delimitation, Alignment, Error Detection and Correction (see Figures 11/Q.703 and 12/Q.703)
  - 5.1 More than seven "1"s between MSU opening and closing flags
  - 5.2 Greater than maximum signal unit length
  - 5.3 Below minimum signal unit length
  - 5.4 Reception of single and multiple flags between FISUs
  - 5.5 Reception of single and multiple flags between MSUs
- 6 SUERM Check (see Figure 18/Q.703)
  - 6.1 Error rate of 1 in 256 Link remains in service
  - 6.2 Error rate of 1 in 254 Link into out of service
  - 6.3 Consecutive corrupted SUs
  - 6.4 Time controlled break of the link
- 7 AERM check (see Figure 17/Q.703)
  - 7.1 Error rate below the normal threshold
  - 7.2 Error rate at the normal threshold
  - 7.3 Error rate above the normal threshold
  - 7.4 Error rate at the emergency threshold
- 8 Transmission and reception control (Basic) (see Figures 13/Q.703 and 14/Q.703)
  - 8.1 MSU transmission and reception
  - 8.2 Negative acknowledgement of MSU
  - 8.3 Check RTB full

- 8.4 Single MSU with erroneous FIB
- 8.5 Duplicated FSN
- 8.6 Erroneous retransmission Single MSU
- 8.7 Erroneous retransmission Multiple FISUs
- 8.8 Single FISU with corrupt FIB
- 8.9 Single FISU prior to RPO being set
- 8.10 Abnormal BSN Single MSU
- 8.11 Abnormal BSN Two consecutive FISUs
- 8.12 Excessive delay of acknowledgement
- 8.13 Level 3 Stop Command
- 9 Transmission and reception control (PCR) (see Figures 15/Q.703 and 16/Q.703)
  - 9.1 MSU transmission and reception
  - 9.2 Priority control
  - 9.3 Forced retransmission with the value N<sub>1</sub>
  - 9.4 Forced retransmission with the value N<sub>2</sub>
  - 9.5 Forced retransmission cancel
  - 9.6 Repetition of forced retransmission
  - 9.7 MSU transmission while RPO set
  - 9.8 Abnormal BSN Single MSU
  - 9.9 Abnormal BSN Two MSUs
  - 9.10 Unexpected FSN
  - 9.11 Excessive delay of acknowledgement
  - 9.12 FISU with FSN expected for MSU
  - 9.13 Level 3 Stop Command
- 10 Congestion Control (see Figure 19/Q.703)
  - 10.1 Congestion abatement
  - 10.2 Timer T7
  - 10.3 Timer T6

#### 6 Test descriptions

TEST	NUMBER: 1.1	PAGE: 1 OF 1					
REFE:	RENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 12; Fig. 13						
TITLE: Link State Control – Expected signal units/orders							
SUB 7	FITLE: Initialization (Power-up)						
PURP	OSE: To check that the No. 7 terminal equipment enters the correct state on p	oower-up					
PRE-T	TEST CONDITIONS: Line equipment – ON; No. 7 equipment – OFF						
CONF	FIGURATION: 1	TYPE OF TEST: VAT, CPT					
EXPE	CTED SIGNAL UNIT SEQUENCE:						
	SP B	SP A					
Link		Link					
1 – 0	SIOS>						
		: Power ON					
	<	1 – 0 SIOS					
TEST	DESCRIPTION						
1.	Check link enters correct state.						
2.	At "Power – On" or Initialization the FIB, BIB, FSN, and BSN shall be as fo FIN = BIB = 1 : FSN = BSN = 127 (HEX 7F)	llows:					
3.	Repeat test in reverse direction.						

TEST NUMBER: 1.2	PAGE: 1 OF 1						
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9; Fig. 11; Fig. 13; Fig. 14							
TITLE: Link State Control – Expected signal units/orders							
SUB TITLE: Timer T2							
PURPOSE: To check "Not Aligned" Timer T2							
PRE-TEST CONDITIONS: Link out of service							
CONFIGURATION: 1	TYPE OF TEST: VAT, CPT						
EXPECTED SIGNAL UNIT SEQUENCE:							
SP B	SP A						
Link	Link						
1 – 0 SIOS>							
<	1 – 0 SIOS						
	: start						
<	1 – 0 SIO						
	T2						
<	1 – 0 SIOS						
TEST DESCRIPTION							
1. Timer T2 shall be in the range 5 secs to 150 secs.							

TEST NUMBER: 1.3	PAGE: 1 OF 1
REFERENCE: Q.703 Clause 7 STD: Fig. 9; Fig. 14	
TITLE: Link State Control – Expected signal units/orders	
SUB TITLE: Timer T3	
PURPOSE: To check "Aligned" Timer T3	
PRE-TEST CONDITIONS: Link out of service	
CONFIGURATION: 1	TYPE OF TEST: VAT
EXPECTED SIGNAL UNIT SEQUENCE:	
SP B	SP A
Link	Link
<	1 – 0 SIOS
1 – 0 SIOS	>
	: start
<	1 – 0 SIO
1 – 0 SIO	>
<	1 – 0 SIN
	Т3
<	1 – 0 SIOS
TEST DESCRIPTION	
1. Timer T3 shall be in the range 1 sec to 1.5 secs.	

TEST	EST NUMBER: 1.4 PAGE: 1 OF 1					
REFEI	RENCE:	Q.703 Clause 7 STD:	Fig. 8; Fig. 9			
TITLE	: Link St	ate Control – Expected sign	al units/orders			
SUB T	TTLE: Ti	mer T1 & Timer T4 (Norma	al)			
PURP	OSE: To	check "Aligned ready" Time	er T1 and "Proving period" Timer T4 (N	Iormal)		
PRE-T	EST CON	DITIONS: Link out of ser	vice			
CONF	IGURATI(	ON: 1		TYPE OF TE	EST: V	AT
EXPE	CTED SIG	NAL UNIT SEQUENCE:				
	SP	В			SP	A
Link				Link		
			<	1 – 0	SIC	OS
1 – 0	SIC	OS	>			
					: star	t
			<	1 - 0	SIC	)
1 - 0	SIG	)	>			
			<	1 - 0	SIN	1
1 - 0	SIN	1	>			
						T4 (Pn)
			<	1 - 0	FIS	U
						T1
			<	1 - 0	SIC	os estados est
TEST	DESCRIP'	TION				
1.	At 64 kbi 40 secs to	t/s Timer T4 shall be in the 50 secs.	range 7.5 secs to 9.5 secs (nominally 8.	2 secs) and Tin	ner T1 s	hall be in the range
2.	At 4.8 kt range 500	oit/s Timer T4 shall be in the secs to 600 secs.	ne range 100 secs to 120 secs (nominal	ly 110 secs) an	d Time	T1 shall be in the

TEST	NUMBER: 1.5	PAGE: 1 OF 1					
REFE	RENCE: Q.703 Clause	7					
TITLE	E: Link State Control – F	Expected signal units/orders					
SUB	FITLE: Normal alignmen	nt – correct procedure (FISU)					
PURP	OSE: To check normal a	alignment procedure					
PRE-T	TEST CONDITIONS: L	ink out of service					
CONF	FIGURATION: 1		TYPE OF T	EST: VAT, CPT			
MESS	SAGE SEQUENCE:						
	SP B			SP A			
Link			Link				
		<	1 – 0	SIOS			
1 – 0	SIOS	>					
				: start			
		<	1 - 0	SIO			
1 – 0	SIO	>					
		<	1 - 0	SIN			
1 – 0	SIN	>					
		<	1 - 0	FISU			
1 – 0	FISU	>					
TEST	TEST DESCRIPTION						
1.	Start normal alignment	procedure.					
2.	Check link aligns and en	nters "In service" state.					
3.	Check that "In service"	state is maintained.					
4.	In VAT only check it is possible to perform a normal alignment procedure in the following cases:  - use LSSU in point B with a status field of 8 bits;  - use LSSU in point B with a status field of 16 bits.						

TEST	NUMBER: 1.6		PAGE: 1	PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clause 7 S	ΓD: Fig. 8; Fig. 9				
TITLE	E: Link State Control – Expected	signal units/orders				
SUB 7	FITLE: Normal alignment – corre	ect procedure (MSU)				
PURP	OSE: To check normal alignmen	t procedure				
PRE-T	TEST CONDITIONS: Link out or	f service				
CONF	FIGURATION: 1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUENC	ČE:				
	SP B			SP A		
Link			Link			
		<	1 - 0	SIOS		
1-0	SIOS	>				
				: start		
		<	1 - 0	SIO		
1 – 0	SIO	>				
		<	1 - 0	SIN		
1 – 0	SIN	>				
		<	1 - 0	FISU		
1 – 0	MSU	>				
TEST	DESCRIPTION					
1.	Start normal alignment procedur	e.				
2.	Check link aligns and enters "In	service" state.				
3.	Check that "In service" state is n	naintained.				

TEST	NUMBER: 1.7		PAGE: 1 C	OF 1			
	TAGE. 1.7						
REFE	RENCE: Q.703 Clauses 7, 10.3	STD: Fig. 9; Fig. 17					
TITLE	E: Link State Control – Expected	signal units/orders					
SUB	FITLE: SIO received during norm	al proving period					
PURP	OSE: To test the response to the r	reception of an SIO during the normal proving	ving period				
PRE-T	TEST CONDITIONS: Link out of	service					
CONF	FIGURATION: 1		TYPE OF	TEST: VAT			
EXPE	CTED SIGNAL UNIT SEQUENC	E:					
	SP B			SP A			
Link			Link				
		<	1 – 0	SIOS			
1 – 0	SIOS	>					
				: start			
		<	1 – 0	SIO			
1 – 0	SIO	>					
		<	1 - 0	SIN			
1 – 0	SIN	>		T4 Stopped			
1-0	SIO (one only)	>					
1 – 0	SIN	>					
		<	1 – 0	SIN T4(Pn)			
		<	1 – 0	FISU			
TEST	DESCRIPTION						
1.	Send an SIO at B during normal	proving period.					
2.	Check that new normal period is	entered.					

TEST NUMBER: 1.8	PAGE: 1 OF 1					
REFERENCE: Q.703 Clauses 7, 8 STD: Fig. 8						
TITLE: Link State Control – Expected signal units/orders						
SUB TITLE: Normal alignment with PO set (FISU)						
PURPOSE: To check the response following normal alignment when PO has been	set					
PRE-TEST CONDITIONS: Link out of service						
CONFIGURATION: 1	TYPE OF TEST: VAT					
EXPECTED SIGNAL UNIT SEQUENCE:						
SP B	SP A					
Link	Link					
<	1 – 0 SIOS					
1 – 0 SIOS>						
	: set LPO : start					
<	1 – 0 SIO					
1 – 0 SIO>						
<	1 – 0 SIN					
1 – 0 SIN>						
<	1 – 0 SIPO					
1 – 0 FISU>						
<	1-0 SIPO					
TEST DESCRIPTION						
1. Check that normal alignment is carried out with LPO set at A.						
2. Check that SIPO is returned when aligned, and that A stays in "processor ou	tage" state.					
3. Repeat test with LPO set at B.						

			•			
TEST	TEST NUMBER: 1.9 PAGE: 1 OF 1					
REFE	RENCE: Q.703	3 Clauses 7, 8	STD: Fig. 8			
TITLE	E: Link State Co	ontrol – Expected sig	gnal units/orders			
SUB 7	TITLE: Normal	alignment with PO	set (MSU)			
PURP	OSE: To check	the response follow	ing normal alignment when PO has been	set		
PRE-T	EST CONDITI	ONS: Link out of se	ervice			
CONF	IGURATION:	1		TYPE OF T	EST: VAT	
EXPE	CTED SIGNAL	UNIT SEQUENCE:				
	SP	В			SP A	
Link				Link		
			<	1 – 0	SIOS	
1 – 0	SIOS		>			
					: set LPO	
					: start	
			<	1 - 0	SIO	
1 – 0	SIO		>			
			<	1 - 0	SIN	
1 – 0	SIN		>			
			<	1 - 0	SIPO	
1 - 0	MSU		>			
			<	1 – 0	SIPO	
		_				
TEST	DESCRIPTION	[				
1.	Check that nor	mal alignment is car	ried out with LPO set at A.			
2.	Check that SIF	O is returned when a	aligned, and that A stays in "processor ou	tage" state.		
3.	Repeat test wit	th LPO set at B.				

TEST	NUMBER: 1.10			PAGE: 1 OF 1		
REFE	RENCE: Q.703 C	Clauses 7, 8 ST	TD: Fig. 8			
TITLE	E: Link State Con	trol – Expected sign	al units/orders			
SUB 7	ΓΙΤLE: Normal al	lignment with PO se	et and clear			
PURP	OSE: To check the	ne response followin	ng normal alignment when PO has been	set and cleared		
PRE-7	TEST CONDITION	NS: Link out of ser	vice			
CONF	FIGURATION: 1			TYPE OF TH	EST: VAT	
EXPE	CTED SIGNAL U	NIT SEQUENCE:				
	SP	В			SP A	
Link				Link		
			<	1 – 0	SIOS	
1 – 0	SIOS		>			
					: set LPO : clear LPO : start	
			<	1 – 0	SIO	
1 – 0	SIO		>			
			<	1 - 0	SIN	
1 – 0	SIN		>			
			<	1 – 0	FISU	
1 – 0	FISU		>			
TECT	DESCRIPTION					
1.		al alignment is carri				
2.	Check that link a	lligns and enters "In	service" state.			

		·	1	
TEST	NUMBER: 1.11		PAGE: 1 C	DF 1
REFE	RENCE: Q.703 Clauses 7, 8	STD: Fig. 8		
TITLE	E: Link State Control – Expected s	ignal units/orders		
SUB T	FITLE: Set RPO when "Aligned n	ot ready"		
PURP	OSE: To check the response follow	wing normal alignment when PO has been	set	
PRE-T	TEST CONDITIONS: Link out of	service; ability to set PO		
CONF	FIGURATION: 1		TYPE OF T	TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUENC	E:		
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
	: set LPO			: set LPO : start
		<	1 - 0	SIO
1 – 0	SIO	>		
		<	1 - 0	SIN
1 – 0	SIN	>		
		<	1 – 0	SIPO
1 – 0	SIPO	>		
TEST	DESCRIPTION			
1.	Set LPO at A and B.			
2.	Start alignment.			
3.	Check that both LPO and RPO af	ter alignment completes.		

TEST	NUMBER: 1.12		PAGE: 1	OF 1	
REFE	RENCE: Q.703 Clauses 7,	8 STD: Fig. 8	- 1		
TITLE	E: Link State Control – Exp	pected signal units/orders			
SUB T	ΓΙΤLE: SIOS received whe	n "Aligned not ready"			
PURP	OSE: To check the respons	e following normal alignment when PO has be	en set		
PRE-T	TEST CONDITIONS: Link	out of service			
CONF	FIGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQ	UENCE:			
	SP B			SP A	
Link			Link		
		<	1 - 0	SIOS	
1 – 0	SIOS	>			
				: set LPO : start	
		<	1 - 0	SIO	
1 – 0	SIO	>			
		<	1 - 0	SIN	
1 – 0	SIN	>			
		<	1 - 0	SIPO	
1-0	: stop SIOS	>			
		<	1 – 0	SIOS	
TEST	DESCRIPTION				
1.	Soon after alignment comp	oletes, A enters "Aligned not ready".			
2.	Before alignment complete	es, stop command is given at B.			
3.	Check that, on reception of SIOS, A enters "Out of service" state.				
4.	Repeat test with LPO set a	t B.			

			·		
TEST	NUMBER: 1.	13		PAGE: 1	OF 1
REFE	RENCE: Q.703	3 Clauses 7, 8	STD: Fig. 8		
TITLE	E: Link State C	ontrol – Expected	signal units/orders		
SUB 7	TITLE: SIO rec	ceived when "Alig	gned not ready"		
PURP	OSE: To check	the response foll	owing normal alignment when PO has	been set	
PRE-T	EST CONDITI	ONS: Link out o	of service		
CONF	IGURATION:	1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAL	UNIT SEQUEN	CE:		
	SP	В			SP A
Link				Link	
			<	1 – 0	SIOS
1 – 0	SIOS		>		
					: set LPO : start
			<	1 - 0	SIO
1 – 0	SIO		>		
			<	1 - 0	SIN
1 – 0	SIN		>		
			<	1 – 0	SIPO
1 – 0	SIO		>		
			<	1 - 0	SIOS
TEST DESCRIPTION					
1.	Soon after alig	nment completes	, A enters "Aligned not ready".		
2.					
3.					
4.		th LPO set at B.	,		
	_				

TEST	NUMBER: 1.14		PAGE: 1 OF	1	
REFE	RENCE: Q.703 Clauses 7, 8	STD: Fig. 8			
TITLE	E: Link State Control – Expected	signal units/orders			
SUB 7	ΓΙΤLE: Set and clear LPO when '	"Initial alignment"			
PURP	OSE: To check normal alignmen	t when PO set and clear during "Initial align	ment"		
PRE-T	TEST CONDITIONS: Link out o	f service			
CONF	FIGURATION: 1		TYPE OF TE	ST: VAT	
EXPE	CTED SIGNAL UNIT SEQUEN	CE:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
		<	1 – 0	SIN	
				: set LPO	
1 – 0	SIN	>			
				: clear LPO	
		<	1 – 0	FISU	
1 – 0	FISU	>			
		<	1 – 0	FISU	
TEST DESCRIPTION					
1.	Set LPO at A during "Initial alig	nment" state.			
2.	Check A remains in "Initial align	nment" state.			
3.					
4.	Check A enters "In service" state after normal alignment.				
5.	Repeat the test at B.				

TEST NUMBI	ER: 1.15		PAGE: 1 OF	1
REFERENCE:	Q.703 Clauses 7, 8 ST	D: Fig. 8		
TITLE: Link	State Control – Expected signa	al units/orders		
SUB TITLE:	Set and clear LPO when "align	ned ready"		
PURPOSE: T	To test the response to LPO who LPO is cleared	en "aligned ready" and to ensure that the	e aligned ready	state resumes when
PRE-TEST CO	ONDITIONS: Link out of serv	rice		
CONFIGURA	TION: 1		TYPE OF TE	ST: VAT
EXPECTED S	IGNAL UNIT SEQUENCE:			
9	SP B			SP A
Link			Link	
		<	1 - 0	SIOS
1-0	SIOS	>		
				: start
		<	1 – 0	SIO
1-0	SIO	>		
		<	1 – 0	SIN
1-0	SIN	>		
		<	1 – 0	FISU
				: set LPO
		<	1 – 0	SIPO
				: wait 5 secs. : clear LPO
		<	1 – 0	FISU
TEST DESCRIPTION				
1. Start li	nk at A.			
2. At "ali (Suppr	gned ready" state set LPO at A ess return of FISUs at B to mai	ntain "aligned ready" state.)		
3. Clear I	LPO at A.			
4. Check	A resumes "aligned ready" sta	te.		

TEST	NUMBER: 1.16		PAGE: 1 O	F 1
REFE	RENCE: Q.703 Clauses 7, 8	STD: Fig. 8		
TITLE	E: Link State Control – Expected	signal units/orders		
SUB 7	FITLE: Timer T1 in "aligned not	ready" state		
PURP	OSE: To test the operation of Tir	ner T1 when in the "aligned not ready" state		
PRE-T	TEST CONDITIONS: Link out o	f service		
CONF	FIGURATION: 1		TYPE OF T	EST: VAT
EXPE	CTED SIGNAL UNIT SEQUENC	CE:		
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: set LPO : start
		<	1 - 0	SIO
1-0	SIO	>		
		<	1 – 0	SIN
1-0	SIN	>		
		<	1 – 0	SIPO
				T1
		<	1 – 0	SIOS
TEST	DESCRIPTION			
1.	Set LPO and start link at A.			
2.	Check A enters the "aligned not	ready" state.		
3.	Check A takes the link out of ser	rvice after time T1.		
4.	Timer T1 shall be in the range 40	0 secs to 50 secs.		

TEST	NUMBER: 1.1	7		PAGE: 10	F 1
REFEI	RENCE: Q.703	Clause 7 STD:	Fig. 9		
TITLE	: Link State Co	ontrol – Expected signa	al units/orders		
SUB T	TITLE: No SIO	sent during normal pro	oving period		
PURP	OSE: To ensure	e that normal alignmer	nt still occurs when SIO is omitted		
PRE-T	EST CONDITION	ONS: Link out of serv	vice		
CONF	IGURATION:	1		TYPE OF T	EST: VAT
EXPE	CTED SIGNAL	UNIT SEQUENCE:			
	SP	В			SP A
Link				Link	
			<	1 – 0	SIOS
1 – 0	SIOS		>		
					: start
			<	1 - 0	SIO not aligned
1 – 0	SIN		>		
			<	1 – 0	SIN
1 – 0	SIN		>		T3
					T4(Pn)
			<	1 – 0	FISU
TEST	DESCRIPTION				
1.	Check normal	alignment occurs with	no SIO sent from SP B.		

TEST	NUMBER: 1.18		PAGE: 1 OF 1
REFE	RENCE: Q.703 Clause 7	7 STD: Fig. 8	
TITLE	E: Link State Control – E	Expected signal units/orders	
SUB 7	TITLE: Set and cease em	nergency prior to "start alignment"	
PURP	OSE: To test the normal	proving period is employed having "emergency" se	t and cleared
PRE-T	TEST CONDITIONS: Li	ink out of service	
CONF	TIGURATION: 1		TYPE OF TEST: VAT
EXPE	CTED SIGNAL UNIT SE	EQUENCE:	
	SP B		SP A
Link			Link
		<	1 – 0 SIOS
1 – 0	SIOS	>	
			: set EM : clear EM : start
		<	1 – 0 SIO
1 – 0	SIO	>	
		<	1-0 SIN
1 – 0	SIN	>	T
			T4(Pn)
		<	1 – 0 FISU
TEST	DESCRIPTION		
1.	Check emergency set an	nd cleared prior to start of alignment.	
2.	Check normal proving p		

TEST	NUMBER: 1.19		PAGE: 1 OF	1	
REFE	RENCE: Q.703 Clause 7 STD: F	ig. 8; Fig. 9			
TITLE	: Link State Control – Expected signal	units/orders			
SUB T	TTLE: Set emergency while in "not alig	gned state"			
PURP	OSE: To test that emergency proving ca	n be set during normal initial alignme	ent		
PRE-T	EST CONDITIONS: Link out of service	ee			
CONF	IGURATION: 1		TYPE OF TE	ST: VAT, CPT	
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
	<	<u></u>	1 – 0	SIOS	
1 - 0	SIOS -	>			
				: start	
	<		1 - 0	SIO	
				: set EM	
1 – 0	SIO -	>			
	<	<u></u>	1 – 0	SIE	
1 – 0	SIN -	>		T	
				T4(Pe)	
	<	<u> </u>	1 - 0	FISU	
TEST	TEST DESCRIPTION				
1.	Check that emergency proving period is	s used after set EM during normal init	ial alignment.		
2.	The timing of this test is critical, emerg received (i.e. during Timer T2 operation	ency must be set once the start comma		ven and before SIO is	
3.	At 64 kbit/s Timer T4 shall be in the rai		sec).		
4.	At 4.8 kbit/s Timer T4 shall be in the ra	ange 6 secs to 8 secs (nominally 7 secs	s).		

TEST NUMBER: 1.20	PAGE: 1 OF 1
REFERENCE: Q.703 Clause 7 STD: Fig. 9	
TITLE: Link State Control – Expected signal units/orders	
SUB TITLE: Set emergency when "aligned"	
PURPOSE: To test that emergency proving period is used when emergency set p	ior to receiving SIN
PRE-TEST CONDITIONS: Link out of service	
CONFIGURATION: 1	TYPE OF TEST: VAT
EXPECTED SIGNAL UNIT SEQUENCE:	
SP B	SP A
Link	Link
<	1-0 SIOS
1 – 0 SIOS>	
	: start
<	1 – 0 SIO
1 – 0 SIO>	
<	1 – 0 SIN
\	
	: set EM
<	1 – 0 SIE
1-0 SIN>	T4 (D.)
	T4 (Pe)
<	1-0 FISU
TEST DESCRIPTION	
	J., ****
1. Check that emergency proving period is used after SIE sent during "aligne	
2. The timing of this test is critical. Emergency must be set once SIN has bee	a sent but before Timer 13 expires.

TEST NUMBER: 1.21	PAGE: 1 OF 1
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9	,
TITLE: Link State Control – Expected signal units/orders	
SUB TITLE: Both ends set emergency	
PURPOSE: To check the emergency alignment procedure and Tim	ner T4 (Pe)
PRE-TEST CONDITIONS: Link out of service	
CONFIGURATION: 1	TYPE OF TEST: VAT
EXPECTED SIGNAL UNIT SEQUENCE:	
SP B	SP A
Link	Link
<	- 1 – 0 SIOS
1 – 0 SIOS	
	: set EM : start
<	- 1 – 0 SIO
1 – 0 SIO	>
<	1 – 0 SIE
1 – 0 SIE	
	T4 (Pe)
<	- 1 – 0 FISU
TEST DESCRIPTION	
Check correct emergency alignment procedure is performed	

TEST	NUMBER: 1.22		PAGE: 1	OF 1	
REFE	RENCE: Q.703 Clause 7	STD: Fig. 9			
TITLE	E: Link State Control – Exp	ected signal units/orders			
SUB	FITLE: Individual end sets	emergency			
PURP	OSE: To check emergency	alignment procedure, Emergency set at the oth	ner end		
PRE-T	TEST CONDITIONS: Link	out of service			
CONF	TIGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQ	UENCE:			
	SP B			SP A	
Link			Link		
		<	1 - 0	SIOS	
1 – 0	SIOS	>			
1 – 0	SIO	>			
				: start	
		<	1 - 0	SIO	
1 – 0	SIE	>			
		<	1 - 0	SIN	
				T4 (Pe)	
		<	1 - 0	FISU	
TEST	TEST DESCRIPTION				
1.	Emergency alignment set a	+ D			
2.	Start alignment at A.	ll D.			
3.		wa with the american as maring maried			
3.	Check that angument occur	rs with the emergency proving period.			

TEST NUMBER: 1.23		PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clause 7	ГD: Fig. 9		
TITLE	E: Link State Control – Expected	signal units/orders		
SUB 7	FITLE: Set emergency during nor	rmal proving		
PURP	PURPOSE: To test that setting emergency during normal proving stops normal proving and starts the emergency proving			
PRE-T	PRE-TEST CONDITIONS: Link out of service			
CONF	CONFIGURATION: 1 TYPE OF TEST: VAT			TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUENC	CE:		
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: start
		<	1 - 0	SIO
1 – 0	SIO	>		
		<	1 - 0	SIN
1 – 0	SIN	>		
				: set EM
		<	1 - 0	SIE
1 – 0	SIN	>		T4 (D.)
				T4 (Pe)
		<	1 - 0	FISU
TEST DESCRIPTION				
1.	Set emergency during normal pro	oving period at A.		
2.	Check A sends SIE.			
3.	Repeat test in reverse direction.			

TEST NUMBER: 1.24		PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 7 STD: Fig. 9				
TITLE: Link State Control – Expected signal units/orders				
SUB	SUB TITLE: No SIO sent during emergency alignment			
PURP	OSE: to ensure that emergency	alignment still occurs when SIE is received f	ollowing SIOS	
PRE-TEST CONDITIONS: Link out of service				
CONFIGURATION: 1 TYPE OF TEST: VAT			Т	
EXPE	CTED SIGNAL UNIT SEQUEN	CE:		
	SP B		SP	A
Link			Link	
		<	1 – 0 SIOS	1
1 – 0	SIOS	>		
			: set E : start	M
		<	1 – 0 SIO	
1 – 0	SIE	>		
		<	1 – 0 SIE	
				T4 (Pe)
		<	1-0 FISU	Г
TEST DESCRIPTION				
1.	Set emergency and start link at	A.		
2.	A receives SIE after sending SI	0.		
3.	Check that link aligns OK after	emergency proving.		

TEST NUMBER: 1.25		PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9			
TITLE	: Link State Control – Expected signal units/orders			
SUB T	TTLE: Deactivation during initial alignment			
PURPOSE: To test the response to the receipt of the stop command while in the initial alignment state (initial alignment is Not Aligned State)				
PRE-TEST CONDITIONS: Link out of service				
CONFIGURATION: 1 TYPE		TYPE OF TE	E OF TEST: VAT, CPT	
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B		SP A	
Link		Link		
	<	1 - 0	SIOS	
1 - 0	SIOS>			
			: start	
	<	1 - 0	SIO	
			: wait 5 secs. : stop	
	<	1 – 0	SIOS	
TEST DESCRIPTION				
1.	Check that alignment ceases after Stop command given.			
2.	The stop command must be issued before timer T2 expires.			
3.	Timer T2 shall be in the range 5 secs to 150 secs.			

TEST NUMBER: 1.26				PAGE: 1 OF 1	
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9					
TITLE: Link State Control – Expected signal units/orders					
SUB 7	SUB TITLE: Deactivation during aligned state				
PURPOSE: To test the response to the receipt of the stop command while in the initial alignment state (initial alignment is aligned state)					
PRE-T	TEST CONDITIONS:	Link out of service			
CONF	FIGURATION: 1			TYPE O	F TEST: VAT
EXPE	CTED SIGNAL UNIT	SEQUENCE:			
	SP B				SP A
Link				Link	
		<		1 - 0	SIOS
1 – 0	SIOS	>			
	5100				: start
		<		1 – 0	SIO
1 0	GIO.			1 0	510
1 – 0	SIO	>			
		<		1 – 0	SIN
					: stop
		<		1 - 0	SIOS
TEST DESCRIPTION					
1.	Check that alignmen	t ceases after STOP command given.			
2.	The stop command n	nust be issued before timer T3 expires.			
3.	Timer T3 shall be in	the range 1 sec to 1.5 secs.			
		, and the second			

TEST NUMBER: 1.27	PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 7, 8 STD: Fig. 8			
TITLE: Link State Control – Expected signal units/orders			
SUB TITLE: Deactivation during aligned not ready			
PURPOSE: To check the response following normal alignment when PO has been set			
PRE-TEST CONDITIONS: Link out of service			
CONFIGURATION: 1 TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:			
SP B	SP A		
Link	Link		
<	1 – 0 SIOS		
1 – 0 SIOS>			
	: set LPO : start		
<	1 – 0 SIO		
1 – 0 SIO>			
<	1 – 0 SIN		
1 – 0 SIN>			
<	1 – 0 SIPO		
	: stop		
<	1 – 0 SIOS		
TEST DESCRIPTION			
Soon after alignment completes, A enters "Aligned not ready".			
2. Before alignment completes at B, stop command is given at A.			
3. Check that A enters "Out of service" state.	Check that A enters "Out of service" state.		
4. Repeat test with LPO set at B.			

TEST NUMBER: 1.28	PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 14			
TITLE: Link State Control – Expected signal units/orders			
SUB TITLE: SIO received during link in service			
PURPOSE: To check the deactivation of a signalling link from the "In Service" state			
PRE-TEST CONDITIONS: Link in service			
CONFIGURATION: 1 TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:			
SP B	SP A		
Link	Link		
1 – 0 FISU	1 – 0 FISU		
1 – 0 SIO>	1-0		
<	1 – 0 SIOS		
TEST DESCRIPTION			
SIO is sent to A during link in service.			
2. Check that an "in service" link can be taken out of service at A.			

TEST NUMBER: 1.29	PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 14			
TITLE: Link State Control – Expected signal units/orders			
SUB TITLE: Deactivation during link in service			
PURPOSE: To check the deactivation of a signalling link from the "In Service" s	state		
PRE-TEST CONDITIONS: Link in service			
CONFIGURATION: 1 TYPE OF TEST: VAT, CPT			
EXPECTED SIGNAL UNIT SEQUENCE:			
SP B	SP A		
Link	Link		
1 – 0 FISU>			
<	1-0 FISU		
: stop			
1 – 0 SIOS>			
<	1-0 SIOS		
TEST DESCRIPTION			
Check that an "In service" link can be taken out of service by command at	B.		
2. Repeat test, command given at A.			

TEST	NUMBER: 1.3	0		PAGE: 1 O	F 1
REFE	RENCE: Q.703	Clauses 7, 8 ST	TD: Fig. 10		
TITLE	E: Link State Co	entrol – Expected sign	nal units/orders		
SUB 7	TITLE: Deactive	ation during LPO			
PURP	OSE: To check	the response to the st	op command during LPO		
PRE-T	EST CONDITIO	ONS: Link in service	;		
CONF	IGURATION:	1		TYPE OF T	EST: VAT
EXPE	CTED SIGNAL	UNIT SEQUENCE:			
	SP	В			SP A
Link				Link	
			<	1 – 0	FISU
1 – 0	FISU		>	1 – 0	FISU
					: set LPO
			<	1 – 0	SIPO
1 – 0	FISU		>		
					: stop
			<	1 – 0	SIOS
TEST	DESCRIPTION				
1.		A. stop command give	ven at A, check link enters out of service	e state.	
2.			command at B, check link enters out of s		

TEST NUMBER: 1.31	PAGE: 1 OF 1
REFERENCE: Q.703 Clauses 7, 8 STD: Fig. 10	
TITLE: Link State Control – Expected signal units/orders	
SUB TITLE: Deactivation during RPO	
PURPOSE: To test the response to the stop command during RPO	
PRE-TEST CONDITIONS: Link in service	
CONFIGURATION: 1	TYPE OF TEST: VAT
EXPECTED SIGNAL UNIT SEQUENCE:	
SP B	SP A
Link	Link
1 – 0 FISU>	
1 - 0 F1SU	1 – 0 FISU
1 – 0 SIPO>	
	: stop
<	1 – 0 SIOS
TEST DESCRIPTION	
SIPO received at A, stop command given at A, check link enters out of service.	ce state.
2. Repeat test, SIPO received at B, stop command given at B, check link enters	out of service state.

TEST	NUMBER: 1.3	2		PAGE: 1 OI	F 1
REFE	REFERENCE: Q.703 Clauses 7, 10.3 STD: Fig. 8; Fig. 9				
TITLE	E: Link State Co	ontrol – Expected sig	nal units/orders		
SUB 7	TITLE: Deactiva	ation during the prov	ring period		
PURP	OSE: To test the	e response to the rec	eipt of SIOS during the proving period		
PRE-T	EST CONDITIO	ONS: Link out of se	ervice		
CONF	IGURATION:	1		TYPE OF T	EST: VAT, CPT
EXPE	CTED SIGNAL	UNIT SEQUENCE:			
	SP	В			SP A
Link				Link	
			<	1 – 0	SIOS
1 – 0	SIOS		>		
			<	1 0	: start
1 – 0	SIO		>	1 – 0	SIO
1-0	310		<	1 – 0	SIN
1 – 0	SIN		>	1 0	
	: stop				
1-0	SIOS		>		
			<	1 – 0	SIOS
TEST	DESCRIPTION				
1.	Check link ente	ers out of service stat	te when SIOS is received at A during the	proving period	
2.	Repeat test, SIG	OS received at B dur	ing proving period.		

		•			
TEST	NUMBER: 1.33		PAGE: 1	OF 1	
REFE	RENCE: Q.703 Clause 7	STD: Fig. 8			
TITLE	E: Link State Control – Expo	ected signal units/orders			
SUB T	TITLE: SIO received instead	d of FISUs			
PURP	OSE: To check the response	e to the receipt of SIO instead of FISUs in the al	ligned ready st	tate	
PRE-T	TEST CONDITIONS: Link	out of service			
CONF	TIGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQU	UENCE:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: start	
1 0	aro.	<	1 – 0	SIO	
1 – 0	SIO	> <	1 – 0	SIN	
1 – 0	SIN	>	1 – 0	SIIN	
1 0	Sirv	<	1 – 0	FISU	
1 – 0	SIO	>			
		<	1 – 0	SIOS	
TEST	TEST DESCRIPTION				
1.	Check link enters out of ser	rvice state when SIO is received at A instead of	FISUs in the a	aligned ready state.	

TEST NUMBER: 1.34	PAGE: 1 OF 1			
EFERENCE: Q.703 Clause 7 STD: Fig. 8				
TITLE: Link State Control – Expected signal units/orders				
SUB TITLE: SIO received instead of FISUs				
PURPOSE: To check the response to the receipt of SIOS instead of FIS	SUs in the aligned ready state			
PRE-TEST CONDITIONS: Link out of service				
CONFIGURATION: 1	TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B	SP A			
Link	Link			
<	1 – 0 SIOS			
1 – 0 SIOS>				
<	: start 1 – 0 SIO			
1-0 SIO>				
<	1 – 0 SIN			
1 – 0 SIN>				
<	1 – 0 FISU			
: stop				
1 – 0 SIOS>				
<	1 – 0 SIOS			
TEST DESCRIPTION				
Check link enters out of service state when SIOS is received at A	A instead of FISUs in the aligned ready state.			

TEST	NUMBER: 1.35		PAGE: 1	OF 1
REFE	RENCE: Q.703 Clauses 7, 8	STD: Fig. 8		
TITLE	: Link State Control – Expe	cted signal units/orders		
SUB T	TITLE: SIPO received instea	d of FISUs		
PURP	OSE: To check the response	to the receipt of SIPO instead of FISUs in th	e aligned ready s	tate
PRE-T	EST CONDITIONS: Link of	out of service		
CONF	IGURATION: 1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAL UNIT SEQU	ENCE:		
	SP B			SP A
Link			Link	
		<	1 - 0	SIOS
1 – 0	SIOS	>		
				: start
		<	1 - 0	SIO
1 – 0	SIO	>		
		<	1 – 0	SIN
1 – 0	SIN	>		
		<	1 - 0	FISU
	: set LPO			
1 – 0	SIPO	>		
		<	1 – 0	FISU
TEST	TEST DESCRIPTION			
1.	Check link enters processor	outage state when SIPO is received at A instr	ead of FISUs in t	he aligned ready state.

TEST	NUMBER: 2.	1		PAGE: 10	OF 1
REFE	RENCE: Q.70	3 Clauses 7, 11	STD: Fig. 8	<u> </u>	
TITLE	E: Link State C	Control – Unexpe	cted signal units/orders		
SUB 7	TITLE: Unexp	ected signal units	s/orders in "Out of service" state		
PURP	OSE: To check	k that the unexpe	cted signal units/orders are ignored		
PRE-T	TEST CONDIT	IONS: Link out	of service		
CONF	IGURATION:	1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAI	L UNIT SEQUE	NCE:		
	SP	В			SP A
Link				Link	
			<	1 - 0	SIOS
1 – 0	SIOS		>	1 0	5.00
	xxx		>		
					yyy : start
			<	1 - 0	SIO
1-0	SIO		>		
			<	1 - 0	SIN
1 – 0	SIN		>	1 0	EIGH
1-0	FISU		<>	1 - 0	FISU
	1150				
TEST	DESCRIPTION	N			
1.	Check that the	ne unexpected si	gnal units xxx received from B are i	gnored without imp	pact on the system. xxx are
2.	-		ers yyy = Stop from level 3 are ignored		
			•	_	

TEST	NUMBER: 2.2		PAGE: 1 C	F 1
REFE	RENCE: Q.703 Clauses 7,	,11 STD: Fig. 9	•	
TITLE	: Link State Control – Un	expected signal units/orders		
SUB T	TITLE: Unexpected signal	units/orders in "Not aligned" state		
PURP	OSE: To check that the un	nexpected signal units/orders are ignored		
PRE-T	EST CONDITIONS: Link	k out of service		
CONF	IGURATION: 1		TYPE OF T	EST: VAT
EXPE	CTED SIGNAL UNIT SEQ	QUENCE:		
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 – 0	SIOS	>		
				: start
		<	1 – 0	SIO
	XXX	>		ууу
1 – 0	SIO	>		,,,
		<	1 – 0	SIN
1 – 0	SIN	>		
1 – 0	FISU	<>	1 – 0	FISU
1 0	1150			
TEST	DESCRIPTION			
1.	Check that the unexpecte successively SIOS SIPO	ed signal units xxx received from B are SIB, aberrant LSSU, FISU and MSU.	ignored without impa	act on the system. xxx are
2.	Check that the unexpected	ed orders yyy received from level 3 are	ignored without impa	act on the system. yyy are
	successively clear EM and	d start (if applicable).		

TEST	NUMBER: 2.3		PAGE: 1 OF	1	
REFE	REFERENCE: Q.703 Clauses 7, 11 STD: Fig. 9				
TITL	E: Link State Control -	- Unexpected signal units/orders			
SUB	TITLE: Unexpected sign	gnal units/orders in "Aligned" state			
PURI	POSE: To check that the	ne unexpected signal units/orders are ignored			
PRE-	TEST CONDITIONS:	Link out of service			
CON	FIGURATION: 1		TYPE OF TE	ST: VAT	
EXPE	ECTED SIGNAL UNIT	SEQUENCE:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1-0	SIOS	>	1 – 0	3103	
				: start	
		<	1 - 0	SIO	
1 – 0	SIO	>			
	XXX	<>	1 – 0	SIN	
	AAA			ууу	
1 – 0	SIN	>			
		<	1 - 0	FISU	
1 – 0	FISU	>			
TEST	DESCRIPTION				
1.	Check that the unexp successively SIO, SIP	pected signal units xxx received from B a PO, SIB, aberrant LSSU, FISU and MSU.	re ignored without impac	t on the system. xxx are	
2.	Check that the unexp	pected orders yyy received from level 3 a 1 and start (if applicable).	re ignored without impac	t on the system. yyy are	
	Successively clear Liv	- and sair (it approvate).			

TEST	NUMBER: 2.4		PAGE: 1	OF 1
REFEI	EFERENCE: Q.703 Clauses 7, 11 STD: Fig. 9			
TITLE	: Link State Control – U	Inexpected signal units/orders		
SUB T	TTLE: Unexpected signa	al units/orders in "Proving" state		
PURP	OSE: To check that the u	nexpected signal units/orders are ignored		
PRE-T	EST CONDITIONS: Li	nk out of service		
CONF	IGURATION: 1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAL UNIT SE	EQUENCE:		
	SP B			SP A
Link			Link	
		<	1 - 0	SIOS
1 – 0	SIOS	>		
				: start
		<	1 - 0	SIO
1 - 0	SIO	>		
		<	1 - 0	SIN
1 - 0	SIN	>		
	XXX	>		
				ууу
		<	1 - 0	FISU
1 - 0	FISU	>		
TEST	DESCRIPTION			
1.	Check that the unexpect successively SIPO, SIB,	eted signal units xxx received from B are ignoraberrant LSSU, FISU and MSU.	red without imp	pact on the system. xxx are
2.	•	eted orders yyy received from level 3 are ignor	red without imp	pact on the system. yyy are
	•	of SIB in "Initial alignment" state may possibly	y cause link fai	lure after transferring to "In

TEST	NUMBER: 2.5	5		PAGE: 1	PAGE: 1 OF 1		
REFE	REFERENCE: Q.703 Clauses 7, 11 STD: Fig. 8						
TITLE	E: Link State Co	ontrol – Unexp	pected signal units/orders				
SUB T	SUB TITLE: Unexpected signal units/orders in "Aligned ready" state						
PURP	OSE: To check	that the unexp	pected signal units/orders are ignored	d			
PRE-T	EST CONDITI	ONS: Link o	ut of service				
CONF	IGURATION:	1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL	UNIT SEQUI	ENCE:				
	SP	В			SP A		
Link				Link			
			<	1 – 0	SIOS		
1 – 0	SIOS		>				
			<	1 - 0	: start SIO		
1 – 0	SIO		>	1 – 0	510		
			<	1 - 0	SIN		
1-0	SIN		>				
			<	1 - 0	FISU		
	xxx		>				
					ууу		
1 – 0	FISU		>				
TEST	DESCRIPTION	ſ					
1.	Check that the successively S	e unexpected IB and aberran	signal units xxx received from B tt LSSU.	are ignored without im	apact on the system.	xxx are	
2.	Check that the successively se	e unexpected et EM, clear El	orders yyy received from level 3 M, clear LPO and start (if applicable	are ignored without im	pact on the system.	yyy are	
	NOTE – The service" state b	reception of Specause of the	SIB in "Aligned ready" state may T6 expiration.	possibly cause link fa	ilure after transferring	g to "In	

TEST	ST NUMBER: 2.6 PAGE: 1 OF 1				
REFE	RENCE: Q.703	3 Clauses 7, 11	STD: Fig. 8		
TITLE	E: Link State C	ontrol – Unexpe	ected signal units/orders		
SUB 7	ΓΙΤLE: Unexpe	ected signal unit	s/orders in "Aligned not ready" state		
PURP	OSE: To check	that the unexpe	ected signal units/orders are ignored		
PRE-T	TEST CONDITI	ONS: Link out	of service		
CONF	FIGURATION:	1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAL	UNIT SEQUE	NCE:		
	SP	В			SP A
Link				Link	
			<	1 – 0	SIOS
1 – 0	SIOS		>		
					: set LPO : start
			<	1 - 0	SIO
1 – 0	SIO		>		
			<	1 - 0	SIN
1 – 0	SIN		>		
			<	1 – 0	SIPO
	XXX		>		
1-0	FISU		>		ууу
1 0	1150		<	1 – 0	SIPO
TEST	DESCRIPTION	ſ			
1.	Check that th	e unexpected si	ignal units xxx received from B are ig	nored without imp	pact on the system. xxx are
2.		IB and aberrant	LSSU. rders yyy received from level 3 are ig	nored without imp	aget on the system yaya are
۷.	successively se	et EM, clear EM	I, clear LPO and start (if applicable).	norea without hip	act on the system. yyy are
	•				

TEST	NUMBER: 2.7		PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clauses 7, 11	STD: Fig. 8			
TITLE	E: Link State Control – Unexpected s	ignal units/orders			
SUB 7	FITLE: Unexpected signal units/orde	rs in "In service" state			
PURP	OSE: To check that the unexpected s	signal units/orders are ignored			
PRE-T	TEST CONDITIONS: Link out of se	rvice			
CONF	IGURATION: 1		TYPE OF TE	EST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU	
1-0	FISU	>			
	aberrant LSSU	>			
				ууу	
		<	1 – 0	FISU	
1-0	FISU	>			
TEST DESCRIPTION					
1.	Check that an aberrant LSSU receive	ed from B is ignored without impact on t	he system.		
2.	2. Check that the unexpected orders yyy received from level 3 are ignored without impact on the system. yyy are successively set EM, clear EM, clear LPO and start (if applicable).				

TEST	NUMBER: 2.8	PAGE: 1 OF 1
REFE	RENCE: Q.703 Clauses 7, 11 STD: Fig. 8	
TITLE	E: Link State Control – Unexpected signal units/orders	
SUB 7	FITLE: Unexpected signal units/orders in "Processor outage" state	
PURP	OSE: To check that the unexpected signal units/orders are ignored	
PRE-T	TEST CONDITIONS: Link in service	
CONF	IGURATION: 1	TYPE OF TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:	
	SP B	SP A
Link		Link : set LPO
	<	1 – 0 SIPO
	xxx>	
1 0	DIGIT	ууу
1 – 0	FISU>	
TEST	DESCRIPTION	
1.	Check that the unexpected signal units xxx received from B are ignored successively SIB and aberrant LSSU.	without impact on the system. xxx are
2.	Check that the unexpected orders yyy received from level 3 are ignored successively set EM, clear EM and start (if applicable).	without impact on the system. yyy are

TEST NUMBER: 3.1 PAGE: 1 OF 1			OF 1		
REFE	REFERENCE: Q.703 Clause 4, subclause10.2 STD: Fig. 8				
TITLE	E: Transmission failure				
SUB T	TITLE: Link aligned ready (I	Break Tx path)			
PURP	OSE: To test the response to	a transmission failure - detected by SUEI	RM – when in "Alig	ned ready" state	
PRE-T	PRE-TEST CONDITIONS: Link out of service				
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQU	ENCE:	·		
	SP B			SP A	
Link			Link		
		<	1 - 0	SIOS	
1 – 0	SIOS	>			
				: start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
		<	1 – 0	SIN	
1 – 0	SIN	>			
		<	1 - 0	FISU	
	: break Tx				
		<	1 - 0	SIOS	
TEST	DESCRIPTION				
1.	Break Tx path at B when in of service.	"Aligned ready" state, check that the SU	ERM detects the fai	lure and the link is taken out	
2.	Repeat test, break Tx at A.				
	The state of the s				

TEST	NUMBER: 3.2		PAGE: 1 OF	1	
REFERENCE: Q.703 Subclause 5.3 STD: Fig. 8					
TITLE	TITLE: Transmission failure				
SUB T	TITLE: Link aligned ready (Corrupt	FIBs – Basic)			
PURP	PURPOSE: To check the response to a link failure after corruption of two FIBs – detected by reception control – while in Aligned ready State				
PRE-T	EST CONDITIONS: Aligned read	y			
CONF	IGURATION: 1		TYPE OF TE	ST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE				
	SP B			SP A	
Link			Link		
		<	1 - 0	FISU	
1 – 0	FISU corrupt FIB (FIB + FSN = 7F)	>			
1 – 0	FISU corrupt FIB (FIB + FSN = 7F)	>			
		<	1 – 0	SIOS	
TEST	DESCRIPTION				
1.	Check that receipt of two FISUs at service.	A with corrupt FIB's at link aligned rea	ndy state causes	the link to be taken out of	

				1
TEST	NUMBER: 3.3		PAGE: 10	OF 1
REFE	RENCE: Q.703 Clause 8, subcl	ause 10.3 STD: Fig. 8		
TITLE	: Transmission failure			
SUB T	TTLE: Link aligned not ready (	Break Tx path)		
PURP	OSE: To test the response to a	oreak in the transmission path – detect	ed by SUERM – in "	Aligned not ready" state
PRE-T	TEST CONDITIONS: Link out	of service		
CONF	IGURATION: 1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUEN	ICE:	1	
	SP B			SP A
Link			Link	
		<	1 - 0	SIOS
1 - 0	SIOS	>		
				: set LPO
				: start
		<	1 - 0	SIO
1 – 0	SIO	>		
1 0	510	<	1 0	CINI
1 0	CDI		1 – 0	SIN
1 – 0	SIN	>		
		<	1 - 0	SIPO
	: break Tx			
		<	1 – 0	SIOS
TEST	DESCRIPTION			
1.	Set LPO at A.			
2.	Start link alignment at A.			
3.		oreak Tx at B and check link is taken o	out of service	
4.		Tx at A, check link is taken out of serv		
			V100.	
5.	The Tx path must be broken be	fore Timer II expires.		

		MIP, LEVEL 2				
TEST	NUMBER: 3.4		PAGE: 10	OF 1		
REFE	REFERENCE: Q.703 subclauses 5.3, Clause 8 STD: Fig. 8					
TITLE	E: Transmission failure					
SUB 7	FITLE: Link aligned not ready (	Corrupt FIBs – Basic)				
PURP	OSE: To check the response to "Aligned not ready"	a link failure after corruption of two F	IBs – detected by red	ception control – while in		
PRE-T	TEST CONDITIONS: Link out	of service				
CONF	IGURATION: 1		TYPE OF	TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUEN	ICE:	1			
	SP B			SP A		
Link			Link			
		<	1 – 0	SIOS		
1 – 0	SIOS	>				
				: set LPO		
			1 0	: start		
		<	1 - 0	SIO		
1 – 0	SIO	>				
		<	1 - 0	SIN		
1 - 0	SIN	> <	1 0	CIDO		
1 0	FYOM		1 – 0	SIPO		
1 – 0	FISU corrupt FIB $(FIB + FSN = 7F)$	>				
1 – 0	FISU corrupt FIB	>				
	(FIB + FSN = 7F)	<	1 – 0	SIOS		
			1 0	5105		
TEST	DESCRIPTION					
1.	Set LPO at A.					
2.	Start link alignment at A.					
3.	Send two corrupt FISUs (corru	pt FIBs) on link aligned not ready.				
4.	Check link is taken out of servi	ce at A.				

TEST	NUMBER: 3.5	PAGE: 1 OF 1
REFE	RENCE: Q.703 Clause 4, subclause 10.2 STD: Fig. 8	
TITLE	E: Transmission failure	
SUB	FITLE: Link in service (Break Tx path)	
PURP	OSE: To test the response to a transmission failure when the link is "In service	ee"
PRE-T	TEST CONDITIONS: Link in service	
CONF	FIGURATION: 1	TYPE OF TEST: VAT, CPT
EXPE	CTED SIGNAL UNIT SEQUENCE:	
	SP B	SP A
Link		Link
	<	1 – 0 FISU
1 – 0	FISU>	
	: break Tx	
	<	SIOS
TEST	DESCRIPTION	
1.	Break Tx at B, check SIOS returned from A.	
2.	Repeat test, break at A.	

TEST	NUMBER: 3.6		PAGE: 1 OF 1		
REFE	RENCE: Q.703 Subclause 5.3	STD: Fig. 8	•		
TITLE	: Transmission failure				
SUB 7	TITLE: Link in service (Corrupt F	IBs – Basic)			
PURP	PURPOSE: To check the response to a link failure after corruption of two FIBS – detected by reception control – while "In service"				
PRE-T	EST CONDITIONS: Link in serv	vice			
CONF	IGURATION: 1		TYPE OF TEST: VAT		
EXPE	CTED SIGNAL UNIT SEQUENC	E:			
	SP B		SP A		
Link			Link		
		<	1-0 FISU		
1 – 0	FISU  (FIB + FSN = FF)	>			
1 – 0	FISU corrupt FIB (FIB + FSN = 7F)	>			
1 – 0	FISU corrupt FIB (FIB + FSN = 7F)	>			
		<	1-0 SIOS		
TEST	TEST DESCRIPTION				
1.	Check that receipt of two FISUs service.	s at A with corrupt FIBs at link in service	e state causes the link to be taken	out of	

TEST NUMBER: 3.7 PAGE: 1 OF 1			OF 1		
REFE	RENCE: Q.703 Clause 8, sub	clause 10.2 STD: Fig. 8			
TITLE	E: Transmission failure				
SUB	TITLE: Link in processor outa	age (Break Tx path)			
PURP	OSE: To test the response to	a transmission failure when the link is "F	Processor outage"		
PRE-T	TEST CONDITIONS: Link in	service			
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUI	ENCE:			
	SP B			SP A	
Link			Link		
		<	1 - 0	FISU	
1-0	FISU	>			
				: set LPO	
		<	1 – 0	SIPO	
	: break Tx				
		<	1 - 0	SIOS	
TEST	TEST DESCRIPTION				
1.	1. Break Tx path at B when in "Processor outage" state, check that the SUERM detects the failure and the link is taken out of service.				
2.	Repeat test, break TX at A.				
	· ·				

	PAGE: 1 OF	1		
REFERENCE: Q.703 subclauses 5.3, Clause 8 STD: Fig. 8				
rrupt FIBs – Basic)				
s failure after corruption of two FIBs – d	etected by recep	otion control – while in		
	TYPE OF TE	EST: VAT		
		SP A		
	Link			
<	1 - 0	FISU		
>				
		: set LPO		
<	1 – 0	SIPO		
>				
>				
<	1 – 0	SIOS		
A with corrupt FIBs on processor outag	ge state causes t	the link to be taken out of		
	rrupt FIBs – Basic)  c failure after corruption of two FIBs – d	rrupt FIBs – Basic)  rafailure after corruption of two FIBs – detected by receptors  TYPE OF TE  Link 1 – 0		

TEST NUMBER: 4.1 PAGE: 1 OF 1 REFERENCE: Q.703 Clause 8 STD: Fig. 10 TITLE: Processor outage control SUB TITLE: Set and clear LPO while link in service PURPOSE: To check the ability to perform correctly when LPO is set and recovered PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** (FSN = 7F, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 7F)accepted 1 - 0MSU (1) (FSN = 0, BSN = 7F)MSU (2) (FSN = 1, BSN = 7F) <-----1 - 0: set LPO 1 - 0MSU (FSN = 0, BSN = 0)1 - 0SIPO (FSN = 0, BSN = 7F): clear LPO 1 - 0<-----MSU (3) (FSN = 1, BSN = 5)TEST DESCRIPTION 1. Set LPO at A while link in service. Check that MSU from B is discarded. 2. 3. Clear LPO at A. 4. Check that "old" messages are flushed from level 2 buffers and not transmitted on the link. Check that new MSUs are sent correctly.

TEST N	NUMBER: 4.2		PAGE: 1 OF 1	
REFER	ENCE: Q.703 Clause 8 STD:	Fig. 10		
TITLE:	Processor outage control			
SUB TI	TLE: RPO during LPO			
PURPO	OSE: To test the response to RPO is	set and cleared when "LPO"		
PRE-TE	EST CONDITIONS: Link in service	. LPO set at B		
CONFI	GURATION: 1		TYPE OF TI	EST: VAT
EXPEC	TED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
				: set LPO
		<	1 – 0	SIPO
1 – 0	SIPO	>		
		<	1 – 0	SIPO
	: clear LPO			
1 – 0	TSR	>		
		<	1 – 0	SIPO
TEST E	DESCRIPTION			
1.	Set LPO at A.			
2.	Clear LPO at B.			
3.	Check is SIPO sent from A.			

TEST	NUMBER: 4.3		PAGE: 1 O	F 1
REFE	RENCE: Q.703 Clause 8 STD	: Fig. 10		
TITLE	E: Processor outage control			
SUB T	CITLE: Clear LPO when "Both proc	essor outage"		
PURP	OSE: To test the response to LPO, I	RPO recovered when "Both processor out	age"	
PRE-T	TEST CONDITIONS: LPO set at A	and B		
CONFIGURATION: 1 TYPE OF TEST: VAT			EST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 – 0	SIPO
1 – 0	SIPO	>		l Ino
		<	1 – 0	: clear LPO FISU
	: clear LPO	<u> </u>	1 – 0	FISU
1 – 0	FISU	>		
1 0	1150	<	1 – 0	FISU
TEST	DESCRIPTION			
1.	Clear LPO at A.			
2.	Clear LPO at B.			
3.	Check is FISU sent from A.			

TEST	NUMBE	R: 5.1		PAGE: 1 OF 1	
REFERENCE: Q.703 Subclause 4.1 STD: Fig. 11					
TITLE	E: SU de	limitation, alignment, error de	tection and correction		
SUB 7	ΓITLE: Ν	More than seven '1's between	MSU opening and closing flags		
PURP	OSE: To	o test the signal unit delimitati more consecutive '1's	on, alignment, and error detection actio	on on receipt of a	an MSU containing seven
PRE-T	TEST CO	NDITIONS: Link in service			
CONF	FIGURAT	TION: 1		TYPE OF TE	ST: VAT
EXPE	CTED SI	GNAL UNIT SEQUENCE:			
	S	Р В			SP A
Link				Link	
			<	1 – 0	FISU
1 – 0	F	ISU	>		
1 – 0	(F (c	orrupt MSU FIB + FSN = 80) containing seven consecutive '1's)	>		
			<	1 – 0	FISU (BSN unchanged)
1 – 0	F	ISU	>		
TEST DESCRIPTION					
1.	Send a c	corrupt MSU at B containing s	seven consecutive '1's.		
2.	Check that A discards the signal unit, and goes into octet counting mode.				
3.			that A leaves the octet counting mode	and remains in t	he "in service" state
J.		r or a control i 150, check	1 100 / 00 mile octor counting mode	Territaini III (	

TEST	NUMBER: 5.2		PAGE: 1 O	F 1
REFE	RENCE: Q.703 Subclause 4.1	STD: Fig. 11	1	
TITLE	E: SU delimitation, alignment, error	detection and correction		
SUB T	FITLE: Greater than maximum signa	al unit length		
PURP	OSE: To test the signal unit delimit maximum length	ation, alignment, error detection action o	n receipt of sign	nal unit greater than the
PRE-T	TEST CONDITIONS: Link in service	ee		
CONF	FIGURATION: 1		TYPE OF T	EST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<>	1 - 0	FISU
1 - 0	FISU			
1-0	corrupt MSU (FIB + FSN = 80) (signal unit length > max. allowed)	>		
		<	1 – 0	FISU (BSN unchanged)
1 – 0	FISU	>		
TEST DESCRIPTION				
TEST DESCRIPTION				
1.		num length plus extra bits and good sumo	check.	
2.	Check A discards the signal unit, ar			4 6
3.	On reception of a correct FISU, che	eck that A leaves the octet counting mode	and remains in	the "in service" state.

TEST	NUMBER: 5.3		PAGE: 1	OF 1
REFEI	RENCE: Q.703 Subclause 4.1	STD: Fig. 11		
TITLE	E: SU delimitation, alignment, err	or detection and correction		
SUB T	TITLE: Below minimum signal u	nit length		
PURP	OSE: To test the signal unit delir minimum length	mitation, alignment and error detection ac	tion on receipt o	of signal unit less than the
PRE-T	TEST CONDITIONS: Link in ser	vice	_	
CONF	IGURATION: 1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUENC	CE:		
	SP B			SP A
Link			Link	
		<	1 – 0	FISU (BIB + BSN = FF)
1 – 0	FISU	>		
1 – 0	corrupt MSU (FIB + FSN = 80) (signal unit less than 6 octets)	>		
		<	1 – 0	FISU (BSN unchanged)
1 – 0	FISU	>		
TEST DESCRIPTION				
1.	Generate a corrupt MSU at B of	less than 6 octet (i.e. less than 5 octets be	tween flags).	
2.		, and goes into octet counting mode.	J.,	
3.	On reception of a correct FISU,	check that A leaves the octet counting mo	de and remains	in the "in service" state.

TEST 1	NUMBER: 5.4		PAGE: 1 OF 1		
REFER	RENCE: Q.703 Clause 2	STD: Fig. 11	·		
TITLE	: SU delimitation, alignmen	t, error detection and correction			
SUB T	ITLE: Reception of single a	and multiple flags between FISUs			
PURPO	OSE: To check that single a	nd multiple flags between FISUs can be receive	ed		
PRE-T	EST CONDITIONS: Link i	n service			
CONF	CONFIGURATION: 1 TYPE OF TEST: VAT				
EXPE	CTED SIGNAL UNIT SEQU	JENCE:			
Link	SP B		SP A		
1 – 0	FISU	>	Lilik		
	case 1	FISU F FISU			
	2	FIGH E E FIGH	P. Pl.		
	case 2	FISU F F FISU	F: Flag		
1-0	FISU	n(≥ 2)	n = number of flags		
	Tige	·			
TEST	DESCRIPTION				
1.	Check that single and n flag	s, case 1 and case 2 respectively, can be received	red.		

TEST 1	NUMBER: 5.5		PAGE: 1 OF 1
REFER	RENCE: Q.703 Clause 2	STD: Fig. 11	
TITLE	: SU delimitation, alignment	, error detection and correction	
SUB T	ITLE: Reception of single ar	nd multiple flags between MSUs	
PURPO	OSE: To check that single an	d multiple flags between MSUs can be re	ceived
PRE-T	EST CONDITIONS: Link in	service	
CONF	IGURATION: 1		TYPE OF TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUI	ENCE:	
	SP B		SP A
Link	77.07.1	>	Link
1 – 0	FISU		
	case 1	MSU F MSU	
	case 2	MSU F F MSU	F: Flag
		n(≥ 2)	n = number of flags
1 – 0	FISU	>	
TEST	DESCRIPTION		
1.	Check that single and n flags	, case 1 and case 2 respectively, can be re	eceived.

TEST NUMBER: 6.1 PAGE: 1 OF 1

REFERENCE: Q.703 Subclause 10.2 STD: Fig. 11, Fig. 18, Fig. 8

TITLE: SUERM check

SUB TITLE: Error rate of 1 in 256 – Link remains in service

PURPOSE: To check the SUERM at a link error rate of 1 in 256 units

PRE-TEST CONDITIONS: Link in service

CONFIGURATION: 1 TYPE OF TEST: VAT

EXPECTED SIGNAL UNIT SEQUENCE:

SP B SP A

Link

<----- 1 – 0 FISU

1 – 0 FISU -----

Ct : corrupt 1 in 256

#### TEST DESCRIPTION

- 1. Check that "In service" state is maintained. The test should run for several minutes.
- 2. Ct = the count of corrupted FISUs.

NOTE – 1) The number (x) of corrupt signal units before an SIOS returned is calculated according to the following formula (a = number of correct signal units):

$$x = \frac{1}{1+a} \left( \frac{256 \times 64}{\frac{256}{1+a} - 1} \right) \text{ for } a < 256$$

2) In this case as a = 255, so x = infinity.

TEST NUMBER: 6.2	PAGE: 1 OF 1			
REFERENCE: Q.703 Subclause 10.2 STD: Fig. 11, Fig. 18, Fig. 8				
TITLE: SUERM check				
SUB TITLE: Error rate of 1 in 254 – Link out of service				
PURPOSE: To check the SUERM at a link error rate of 1 in 254 units				
PRE-TEST CONDITIONS: Link in service				
CONFIGURATION: 1	TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B	SP A			
Link	Link			
<	1 – 0 FISU			
1 – 0 FISU>				
Ct : corrupt 1 in 254				
<	1 – 0 SIOS			
TEST DESCRIPTION				
SIOS should be returned after approx. 8192 corrupt FISUs (e.g. CRC error).	. SIOS should be returned after approx. 8192 corrupt FISUs (e.g. CRC error).			
2. Ct = the count of corrupted FISUs.				

TEST NU	MBER: 6.3		PAGE: 1 OF	F 1
REFERE	NCE: Q.703 Subclause 10.2	STD: Fig. 11, Fig. 18, Fig. 8		
TITLE:	SUERM check			
SUB TITI	LE: Consecutive corrupted SUs			
PURPOSI	E: To test the SUERM on consec	utive corrupted signal units		
PRE-TES	T CONDITIONS: Link in service			
CONFIGU	URATION: 1		TYPE OF TI	EST: VAT
EXPECTI	ED SIGNAL UNIT SEQUENCE:			
	SP B			SP A
Link			Link	
		<	1 - 0	FISU
1 – 0	FISU	>		
Ct	: corrupt 1 in 1			
	ı	<	1 – 0	SIOS
mean p.p.	a an increase			
TEST DESCRIPTION				
1. SI	1. SIOS should be returned after approx. 64 corrupt FISUs (e.g. CRC error).			
2. C1	t = the count of corrupted FISUs.			

TEST	NUMBER: 6.4		PAGE: 1 OF 1			
REFE	REFERENCE: Q.703 Subclause 10.2 STD: Fig. 11, Fig. 18					
TITLE	E: SUERM check					
SUB	TITLE: Time controlled break of the	link				
PURP	OSE: To check response to a range of	of time controlled breaks of Tx or Rx				
PRE-T	TEST CONDITIONS: Link in service	3				
CONF	IGURATION: 1		TYPE OF TEST: VAT			
EXPE	CTED SIGNAL UNIT SEQUENCE:					
	SP B		SP A			
Link			Link			
		<	1-0 FISU			
1 – 0	FISU	>				
	: break Tx					
	: restore Tx					
	FISU	>				
		<	1-0 FISU			
TEST	DESCRIPTION					
1.	Break the transmission link, and restore before level 2 goes out of service. (Break time is less than approx. 128ms for 64 kbit/s).			or		
2.	Check that A enters and leaves the o	ctet counting mode on reception of an Fl	ISU.			

TEST	NUMBER: 7.1		PAGE: 10	OF 1	
REFE	RENCE: Q.703 Subclause 10.3	STD: Fig. 9, Fig. 11, Fig. 17	-		
TITLE	E: AERM check				
SUB 7	FITLE: Error rate below the norma	al threshold			
PURP	OSE: To test the AERM on error	rates below the normal threshold			
PRE-T	TEST CONDITIONS: Link out of	service			
CONF	TIGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENC	E:			
	SP B			SP A	
Link			Link		
		<	1 – 0	SIOS	
1 – 0	SIOS	>			
				: start	
		<	1 – 0	SIO	
1 – 0	SIO	>			
		<	1 – 0	SIN	
1 – 0	SIN	>			
1 – 0	corrupt LSSUs	>		T4	
1 – 0	SIN	>			
		<	1 – 0	FISU	
TEST	TEST DESCRIPTION				
1.	Start link at A.				
2.	Generate x number of corrupt LS	SUs (e.g. CRC error) at $B.(x < Tin)$ .			
3.		ntinues and the link aligns successfully.			
	. 0.	·			

TEST	NUMBER: 7.2		PAGE: 1 OF 1		
REFE	REFERENCE: Q.703 Subclause 10.3 STD: Fig. 9, Fig. 11, Fig. 17				
TITLE	E: AERM check				
SUB 7	FITLE: Error rate at the normal	threshold			
PURP	OSE: To test the AERM at an o	error rate equal to the normal threshold			
PRE-T	TEST CONDITIONS: Link out	of service			
CONF	TIGURATION: 1		TYPE OF TEST:	VAT	
EXPE	CTED SIGNAL UNIT SEQUEN	NCE:			
	SP B		SP	A	
Link			Link		
		<	1 - 0	SIOS	
1 – 0	SIOS	>			
			:	start	
		<	1 - 0	SIO	
1 – 0	SIO	>			
		<	1 - 0	SIN	
1 – 0	SIN	>			
1 – 0	corrupt LSSUs	>			
	SIN	>		T4	
		<	1 – 0 FIS	SU	
TEST	DESCRIPTION				
1.	Start link at A.				
2.	Generate x number of corrupt l	LSSUs (e.g. CRC error) at B.( $x \ge Tin$ )			
3.	Check that the proving period	is aborted, then restarted and link aligns	successfully.		

TEST NU	JMBER: 7.3		PAGE: 1	OF 1	
REFERE	REFERENCE: Q.703 Subclause 10.3 STD: Fig. 9, Fig. 11, Fig. 17				
TITLE:	AERM check				
SUB TIT	LE: Error rate above the no	ormal threshold			
PURPOS	E: To test the AERM at an	error rate above the threshold over five	proving periods		
PRE-TES	ST CONDITIONS: Link ou	t of service			
CONFIG	URATION: 1		TYPE OF	TEST: VAT	
EXPECT	ED SIGNAL UNIT SEQUE	NCE:			
	SP B			SP A	
Link			Link		
		<	1 - 0	SIOS	
1 – 0	SIOS	>			
				: start	
		<	1 - 0	SIO	
1 - 0	SIO	>			
		<	1 - 0	SIN	
1 - 0	SIN	>			
1 - 0	corrupt LSSUs	>			
		<	1 - 0	SIN	
1 - 0	SIN	>			
1 - 0	corrupt LSSUs	>			
		<	1 - 0	SIN	
1 - 0	SIN	>			
1 - 0	corrupt LSSUs	>			
		<	1 – 0	SIN	
1 – 0	SIN	>			
1 – 0	corrupt LSSUs	>	1 0	CDV	
	an.	<	1 - 0	SIN	
1 – 0	SIN	>			
1 – 0	corrupt LSSUs	<>		gro a	
			1 – 0	SIOS	
TEST DE	ESCRIPTION				
1. S	tart link at A.				
2. G	enerate x number of corrupt	LSSUs (e.g. CRC error) at B.( $x \ge Tin$	).		
3. O	bserve that 5 proving period	l attempts are made before link out of se	ervice state.		

TEST	NUM	BER: 7.4		PAGE: 1 C	DF 1
REFE	RENC	E: Q.703 Subclause 10.3	STD: Fig. 9, Fig. 11, Fig. 17		
TITLE	E: <b>A</b> E	RM check			
SUB 7	ΓITLE:	: Error rate at the emergency th	nreshold		
PURP	OSE:	To test the AERM at the emerg	gency threshold		
PRE-T	TEST (	CONDITIONS: Link out of ser	rvice		
CONF	IGUR	ATION: 1		TYPE OF T	TEST: VAT
EXPE	CTED	SIGNAL UNIT SEQUENCE:			
		SP B			SP A
Link				Link	
			<	1 - 0	SIOS
1 – 0		SIOS	>		
					: start
			<	1 - 0	SIO
1 – 0		SIO	>		
1 0		GIF.	<	1 - 0	SIN
1 - 0	İ	SIE	>		
1 - 0		corrupt LSSU	>		
1 - 0 $T4$		SIE	<>	1 – 0	SIN
(Pe)			<	1 - 0 $1 - 0$	FISU
			•	1 0	1150
TEST	DESC	CRIPTION			
1.		link at A, check emergency pro			
2.	Gene	erate x number of corrupt LSSU	s (e.g. CRC error) at B.(5 > $x \ge Tie$ ).		
3.	Chec	ek that link aligns successfully.			

TEST NUMBER: 8.1 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 5.2 STD: Fig. 13, Fig. 14 TITLE: Transmission and reception control (Basic) SUB TITLE: MSU transmission and reception PURPOSE: To check basic MSU transmission and reception PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT, CPT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP A Link Link 1 - 0**FISU** 1 - 0**FISU** 1 - 0MSU (FIB + FSN = 80)(BIB + BSN = FF)1 - 0FISU (FIB + FSN = FF)(BIB + BSN = 80)1 - 0**FISU** (FIB + FSN = 80) (BIB + BSN = FF)1 - 0MSU (FIB + FSN = 80)(BIB + BSN = 80)1 - 0**FISU** (FIB + FSN = 80)(BIB + BSN = 80)**FISU** 1 - 0(FIB + FSN = 80)(BIB + BSN = 80)TEST DESCRIPTION 1. Generate an MSU at B. 2. Check that A receives the MSU correctly, and returns a positive acknowledgement. 3. Generate an MSU at A. Check that B receives the MSU correctly, and returns a positive acknowledgement. 4.

TEST NUMBER: 8.3		PAGE: 1 OF 1		
REFERENCE: Q.703 Subclause	5.3 STD: Fig. 13			
TITLE: Transmission and recept	ion control (Basic)			
SUB TITLE: Check RTB full				
PURPOSE: To check that MSUs	s are buffered when no acknowledgements are recei	ved		
PRE-TEST CONDITIONS: Link	c in service			
CONFIGURATION: 1		TYPE OF TEST: VAT		
EXPECTED SIGNAL UNIT SEQ	UENCE:			
SP B		SP A		
Link		Link		
	<	1 – 0 FISU		
1-0 FISU (BIB + BSN = FF)	>			
,	<	1-0 MSU		
		(FIB + FSN = 80)		
	<	1-0 MSU (FIB + FSN = FE)		
	<	1 – 0 FISU (FIB + FSN = FE)		
1 – 0 FISU	>			
(BIB + BSN = 7F)	<	1 – 0 MSU		
		(FIB + FSN = 00)		
		•		
	<	$ \begin{array}{cc} 1 - 0 & MSU \\ (FIB + FSN = 7E) \end{array} $		
TEST DESCRIPTION				
Generate MSUs at A, at a	rate of 100 per second, in order to fill the RTB before	ore the EDA timer T7 expires.		
2. No acknowledgements are	e sent from B until the last message is received, the	n send negative acknowledgement to the		
_	first message received.  Check that the complete contents of the RTB are retransmitted.			

TEST NUMBER: 8.4 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 5.2 STD: Fig. 14 TITLE: Transmission and reception control (Basic) SUB TITLE: Single MSU with erroneous FIB PURPOSE: To ensure correct performance when an MSU with erroneous FIB is received PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** (BIB + BSN = 7F)1 - 0**FISU** (FIB + FSN = 7F)1 - 0(FIB + FSN = 80)1 - 0**FISU** (BIB + BSN = 7F)1 - 0**FISU** (FIB + FSN = 00)**FISU** 1 - 0(FIB + FSN = 00)1 - 0FISU (BIB + BSN = FF)1 - 0MSU (FIB + FSN = 80)FISU 1 - 0(BIB + BSN = 80)TEST DESCRIPTION 1. Generate an MSU at B with FIB inverted. Check A discards the MSU. 2. Generate 2 FISUs at B with correct FIB. 3. 4. Check A discards the FISU and negative acknowledgement returned. 5. Check that B retransmits the MSU correctly, and positive acknowledgement returned.

TEST	NUMBER: 8.5		PAGE: 1	OF 1	
REFE	REFERENCE: Q.703 Subclause 5.2 STD: Fig. 14				
TITLE	E: Transmission and reception co	ntrol (Basic)			
SUB 7	TITLE: Duplicated FSN				
PURP	OSE: To test the reception contr	ol response to duplicated FSNs			
PRE-T	TEST CONDITIONS: Link in se	rvice			
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUEN	CE:			
	SP B			SP A	
Link			Link		
		<	1 - 0	FISU	
1 – 0	FISU	>			
1 – 0	MSU  (FIB + FSN = 80)	>			
		<	1 – 0	FISU (BIB + BSN = 80)	
1 – 0	MSU (FIB + FSN = 80)	>			
1 – 0	FISU (FIB + FSN = 81)	>			
		<	1 – 0	FISU (BIB + BSN = 00)	
1-0	MSU  (FIB + FSN = 01)	>			
		<	1 – 0	FISU (BIB + BSN = 01)	
TEST DESCRIPTION					
1.	Generate an MSU at B, check A receives the MSU correctly and returns a positive acknowledgement.				
2.					
3.	3. Retransmit the MSU with correct FSN, check that A replies with a positive acknowledgement.				

TEST	NUMBER: 8.6		PAGE: 10	OF 1	
REFE	RENCE: Q.703 Subclause 5.2	STD: Fig. 14			
TITLE	: Transmission and reception con	trol (Basic)			
SUB 7	TTLE: Erroneous retransmission	– Single MSU			
PURP	OSE: To test the reception contro	l response to retransmission of a single MS	U		
PRE-T	EST CONDITIONS: Link in serv	vice			
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENC	E:			
	SP B			SP A	
Link			Link		
		<	1 – 0	FISU (BIB + BSN = FF)	
1 – 0	FISU $(FIB + FSN = FF)$	>			
1 – 0	MSU (FIB + FSN = 00)	>			
1 – 0	FISU $(FIB + FSN = 80)$	>			
1-0	FISU (FIB + FSN = 80)	>			
		<	1 – 0	FISU (BIB + BSN = 7F)	
1 – 0	MSU (FIB + FSN = 00)	>			
	(	<	1 – 0	FISU (BIB + BSN = 00)	
TEST	TEST DESCRIPTION				
1.	A single MSU with FIB inverted	in error is sent to A, followed by FISUs wit	h correct FIB	S.	
2.	Check that A returns a negative a	cknowledgement for the MSU.			
3.					
4.	Check that A receives the MSU c	orrectly and returns a positive acnowledger	ment.		

TEST	NUMBER: 8.7		PAGE: 1	OF 1	
REFE	RENCE: Q.703 Subclause 5.3	STD: Fig. 14	1		
TITLE	E: Transmission and reception co	ontrol (Basic)			
SUB 7	FITLE: Erroneous retransmission	n – Multiple FISUs			
PURP	OSE: To test reception control r	esponse to retransmission of multiple FISUs			
PRE-T	TEST CONDITIONS: Link in se	rvice			
CONF	TIGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUEN	CE:			
	SP B			SP A	
Link			Link		
		<>	1 - 0	FISU	
1 – 0	FISU (FIB + FSN = FF)				
1 – 0	FISU (FIB + FSN = 7F)	>			
1-0	FISU  (FIB + FSN = FF)	>			
1 – 0	FISU (FIB + FSN = 7F)	>			
		<	1 – 0	SIOS	
TEST	TEST DESCRIPTION				
1.	Generate FISUs with the FIB in	verted at B.			
2.	2. Check that A responds with link out of service.				
Generate FISUs with the FIB inverted at B.					

TEST	NUMBER: 8.8		PAGE: 1	OF 1		
REFE	RENCE: Q.703 Subclause 5.3	STD: Fig. 14	1			
TITLE: Transmission and reception control (Basic)						
SUB T	TITLE: Single FISU with corrupt	FIB				
PURP	OSE: To test the response to rec	eive an FISU with a corrupt FIB				
PRE-T	TEST CONDITIONS: Link in set	vice				
CONF	CONFIGURATION: 1 TYPE OF TEST: VAT					
EXPE	CTED SIGNAL UNIT SEQUEN	CE:				
	SP B			SP A		
Link			Link			
		<	1 – 0	FISU		
1 – 0	FISU (FIB + FSN = FF)	>				
1 – 0	FISU (FIB + FSN = 7F)	>				
		<	1 - 0	FISU		
1 – 0	FISU (FIB + FSN = FF)	>				
		<	1 – 0	FISU		
TEST	TEST DESCRIPTION					
1.		pt FIB at B, and check that the link state	tus remains in serv	ice		
1.	Generale one rise with a corru	of 115 at 5, and encor that the link state	ado remains in serv			

TEST	NUMBER: 8.9		PAGE: 1	OF 1	
REFE	RENCE: Q.703 Subclause 5.2	STD: Fig. 10, Fig. 14			
TITLE	E: Transmission and reception co	ntrol (Basic)			
SUB T	TITLE: Single FISU prior to RPC	) being set			
PURP	OSE: To test the response to RP	O while in the abnormal FIB state			
PRE-T	TEST CONDITIONS: Link in se	rvice			
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUEN	CE:			
	SP B			SP A	
Link			Link		
		<	1 - 0	FISU	
1-0	FISU	>			
1 - 0	FISU (one only) $(FIB + FSN = 7F)$				
1 – 0	SIPO	>			
1-0	MSU (FIB + FSN = 80)	>			
1-0	FISU (FIB + FSN = 80)				
1 – 0	FISU (FIB + FSN = 80)	>			
		<	1 – 0	FISU (BIB + BSN = 7F)	
1 – 0	MSU (FIB + FSN = 00)	>			
	(FID + FSIN = 00)	<	1 – 0	FISU (BIB + BSN = 00)	
a) RI	a) RPO at A has recovered, but this FISU is discarded.				
TEST DESCRIPTION					
1.					
2.					
3.					
				•	

TEST	NUMBER: 8.10		PAGE: 1	PAGE: 1 OF 1	
REFEI	RENCE: Q.703 Subclause 5.3	STD: Fig. 14	1		
TITLE	: Transmission and reception cor	atrol (Basic)			
SUB T	TTLE: Abnormal BSN – single M	1SU			
PURP	OSE: To test the response to an a	bnormal BSN			
PRE-T	EST CONDITIONS: Link in ser	vice			
CONFIGURATION: 1 TYPE OF TEST: VAT					
EXPE	CTED SIGNAL UNIT SEQUENC	E:			
	SP B			SP A	
Link			Link		
1 0	FIGH	<	1 - 0	FISU	
1 – 0	FISU $(FIB + FSN = FF)$ $(BIB + BSN = FF)$	>			
1 – 0	MSU $(FIB + FSN = 80)$ $(BIB + BSN = BF)$	>			
1 – 0	FISU $(FIB + FSN = 80)$ $(BIB + BSN = FF)$	> a)			
1 – 0	FISU $(FIB + FSN = 80)$ $(BIB + BSN = FF)$	>			
		<	1 – 0	FISU $(BIB + BSN = 7F)$	
1 – 0	MSU (FIB + FSN = 00) (BIB + BSN = FF)	>		(3.2 · 33. · 7.)	
	(515 + 551 ( 11)	<	1 – 0	FISU (BIB + BSN = 00)	
a) Though UNB: = 1, abnormal BSNR is not cancelled.					
TEST	TEST DESCRIPTION				
1.	Generate a single MSU with abnormal BSN at B, followed by FISUs with correct BSN.				
2.					
3.	Retransmit the MSU correctly at	В.			
4.	Check that the MSU is received of	correctly and positive acknowledgement i	s given.		

TEST	NUMBER: 8.11		PAGE: 10	OF 1	
REFE	RENCE: Q.703 Subclause 5.3	STD: Fig. 14			
TITLE	E: Transmission and reception cont	trol (Basic)			
SUB T	TITLE: Abnormal BSN – two cons	ecutive FISUs			
PURP	OSE: To test the response to abno	rmal BSNs in two consecutive FISUs			
PRE-T	EST CONDITIONS: Link in serv	ice			
CONF	IGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE	∃:			
	SP B			SP A	
Link			Link		
		<>	1 - 0	FISU	
1-0	FISU  (BIB + BSN = FF)				
1 – 0	FISU (BIB + BSN = BF)	>			
1-0	FISU (BIB + BSN = BF)	>			
1-0	FISU (BIB + BSN = FF)	>			
		<	1 - 0	SIOS	
TEST	TEST DESCRIPTION				
1.	Generate two consecutive FISUs a	at R with abnormal RSNs			
2.	Check that A responds by taking t				
۷.	Chock that it responds by taking t	no mix out of service.			

TEST NUMBER: 8.12 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 5.3 STD: Fig. 14 TITLE: Transmission and reception control (Basic) SUB TITLE: Excessive delay of acknowledgement PURPOSE: To test the transmission control response to the expiration of EDA timer T7 PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link **FISU** 1 - 01 - 0**FISU** (BIB + BSN = FF)1 - 0MSU (FIB + FSN = 80)T7 **SIOS** 1 - 0TEST DESCRIPTION 1. Generate an MSU at A. 2. Discard the received MSU at B and send no acknowledgement to A for more than T7 period. 3. Check that the link is taken out of service by SIOS generated at A after T7 has expired. 4. Timer T7 shall be in the range 0.5 secs to 2.0 secs.

TEST NUMBER: 8.13 PAGE: 1 OF 1			7 1			
REFERENCE: Q.703 Clause 7 STD: Fig. 14						
TITLE	E: Transmission and reception control (Basic)					
SUB 7	FITLE: Level 3 Stop command					
PURP	OSE: To test the response to a Stop command					
PRE-T	TEST CONDITIONS: Link in service					
CONF	FIGURATION: 1	TYPE OF TH	EST: VAT			
EXPE	CTED SIGNAL UNIT SEQUENCE:					
	SP B		SP A			
Link		Link				
	<	1 - 0	FISU			
1 – 0	FISU>					
			: stop			
	<	1 - 0	SIOS			
TEST	DESCRIPTION					
1.	Give Stop command at A.					
2.	Check that A responds with link out of service.					

TEST NUMBER: 9.1 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.2 STD: Fig. 15, Fig. 16 TITLE: Transmission and reception control (PCR) SUB TITLE: MSU transmission and reception PURPOSE: To check basic MSU transmission and reception PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT, CPT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** (FSN = 7F, BSN = 7F)1 - 0FISU (FSN = 7F, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)MSU 1 - 0(FSN = 0, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 0)**FISU** 1 - 0(FSN = 0, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 0)FISU 1 - 0(FSN = 0, BSN = 0)TEST DESCRIPTION 1. Generate an MSU at A. 2. Check that B receives the MSU correctly. 3. Check that A sends FISUs after receiving an FISU with a positive acknowledgement. 4. Generate an MSU at B. 5. Check that A receives the MSU correctly and returns a positive acknowledgement.

TEST NUMBER: 9.2		PAGE: 1	OF 1
REFERENCE: Q.703 Subclause 6.3	STD: Fig. 15, Fig. 16		
TITLE: Transmission and reception cont	rol (PCR)		
SUB TITLE: Priority control			
PURPOSE: To check the preventive retra	ansmission procedure		
PRE-TEST CONDITIONS: Link in servi			
CONFIGURATION: 1		TYPE OF	TEST: VAT
EXPECTED SIGNAL UNIT SEQUENCE		1112 01	1201. 7111
SP B	J.		SP A
Link		Link	SI A
	<	1 – 0	FISU (FSN = 7F, BSN = 7F)
1-0 FISU (FSN = 7F, BSN = 7F)	>		
	<	1 – 0	MSU $(FSN = 0, BSN = 7F)$
	<	1 – 0	MSU (FSN = 1, BSN = 7F)
	<	1 – 0	MSU (FSN = 2, BSN = 7F)
	<	1 – 0	MSU (FSN = 0, BSN = 7F)
	<	1 - 0	MSU (FSN = 1, BSN = 7F)
	<	1 – 0	MSU (FSN = 2, BSN = 7F)
A O TYGY			•
$ \begin{array}{ll} 1 - 0 & \text{FISU} \\ (\text{FSN} = 7\text{F, BSN} = 0) \end{array} $	>		
1-0 FISU (FSN = 7F, BSN = 1)	>		
1-0 FISU (FSN = 7F, BSN = 2)	>		
(1511 – 71, B511 – 2)	<	1 – 0	FISU $(FSN = 2, BSN = 7F)$
TEST DESCRIPTION			
Generate two MSUs at A.			
2. No positive acknowledgement is s	ent from B.		
3. Check that MSUs are retransmitted	d at A.		
4. Generate another MSU at A.			
5. Check that B receives MSUs corre	ectly.		
6. Reply with positive acknowledgen	ment at B.		
7. Check that A stops retransmission FISU.	after receiving the positive ackno	wledgement for the la	ast MSU in RTB and sends

TEST	NUMBER: 9.3		PAGE: 1	OF 1
REFE	RENCE: Q.703 Subclause 6.4	STD: Fig. 15	·	
TITLE	E: Transmission and reception cont	trol (PCR)		
SUB 7	ΓΙΤLE: Forced retransmission with	the value N <sub>1</sub>		
PURP	OSE: To check that "RTB full" is	detected by N <sub>1</sub> and forced retrans	smission occurs	
PRE-T	TEST CONDITIONS: Link in serv	ice		
CONF	FIGURATION: 1		TYPE OF	TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE	E:		
Link	SP B	<	Link 1 – 0	SP A
1 – 0	FISU (FSN = 7F, BSN = 7F)	> <	1 – 0	(FSN = 7F, BSN = 7F)  MSU (FSN = 0, BSN = 7F)
		<	1 - 0 $1 - 0$	MSU (FSN = 7E, BSN = 7F) MSU (FSN = 0, BSN = 7F)
1 – 0	FISU (FSN = 7F, BSN = 0)	<>	1 – 0	MSU (FSN = X, BSN = 7F)
		<	1 – 0	MSU (FSN = X + 1, BSN = 7F)
		<	1 – 0	MSU (FSN = 7F, BSN = 7F)
TEST	DESCRIPTION			
1.	Generate 128 MSUs at A, at a rate	•		EDA timer T7 expires.
2.	No positive acknowledgement is s			
3.	Reply with a positive acknowledg			
4.	Check that the forced retransmissi $NOTE - N_1$ is the maximum numl (The value of $N_1$ is normally 127)	ber of MSUs which are available		n RTB.

TEST NUMBER: 9.4 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.4 STD: Fig. 15 TITLE: Transmission and reception control (PCR) SUB TITLE: Forced retransmission with the value N<sub>2</sub> PURPOSE: To check that "RTB full" is detected by N2 and forced retransmission starts PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0FISU (FSN = 7F, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 7F)MSU 1 - 0(FSN = 0, BSN = 7F)<-----1 - 0MSU (FSN = N - 1, BSN = 7F)MSU (FSN = 0, BSN = 7F)MSU <-----1 - 0(FSN = X, BSN = 7F)1 - 0FISU (FSN = 7F, BSN = a - 1)MSU 1 - 0(FSN = a, BSN = 7F)1 - 0MSU (FSN = N, BSN = 7F)(a > X)TEST DESCRIPTION 1. Generate N + 1 MSUs at A (the octet count of N MSUs is larger than N<sub>2</sub>). 2. Send no positive acknowledgement at B until a forced retransmission starts at A. 3. Check that B receives the MSUs with FSN = 0 up to FSN = N - 1 but does not receive the MSU with FSN = N. 4. Reply with a positive acknowledgement with BSN = a - 1 at B. 5. Check that the retransmission restarts from the next value of FSN which is acknowledged by B when the retransmission is interrupted. 6. Check that B receives the MSU with FSN = N.  $NOTE - N_2$  is the maximum number of octets which are available for retransmission.

TEST NUMBER: 9.5 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.4 STD: Fig. 15 TITLE: Transmission and reception control (PCR) SUB TITLE: Forced retransmission cancel PURPOSE: To check that the forced retransmission is cancelled when BSN equal to FSNL is received PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0FISU (FSN = 7F, BSN = 7F)FISU 1 - 0(FSN = 7F, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)1 - 0MSU (FSN = 7E, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)MSU 1 - 0(FSN = X, BSN = 7F)1 - 0FISU (FSN = 7F, BSN = 7E)MSU 1 - 0(FSN = 7F, BSN = 7F)TEST DESCRIPTION 1. Generate  $N_1 + 1$  MSUs at A (e.g. 128). 2. Send no positive acknowledgement at B until a retransmission occurs at A. 3. Reply with a positive acknowledgement with BSN = 7E at B. 4. Check that a forced retransmission is cancelled and the MSU with FSN = 7F is sent at A. NOTES FSNL is the FSN of the last MSU in RTB. Alternatively, the number of octets threshold (N2), instead of the number of MSUs threshold (N1), could be used to start forced retransmission.

TEST NUMBER: 9.6 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.4 STD: Fig. 15 TITLE: Transmission and reception control (PCR) SUB TITLE: Repetition of forced retransmission PURPOSE: To check that the forced retransmission repeats when "RTB full" is still detected after finishing a forced retransmission PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0FISU (FSN = 7F, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)MSU 1 - 0(FSN = 7E, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)1 - 0MSU (FSN = 7E, BSN = 7F)MSU 1 - 0(FSN = 0, BSN = 7F)TEST DESCRIPTION Generate MSUs at A at a rate of N per second, in order to make A repeat a forced retransmission.  $(N \ge 127 \div T, \text{ where } T = \text{lower limit of } T7)$ No acknowledgement is sent from B. 2. 3. Check that A repeats a forced retransmission.

TEST NUMBER: 9.7 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.2 STD: Fig. 15 TITLE: Transmission and reception control (PCR) SUB TITLE: MSU transmission while RPO set PURPOSE: To ensure correct performance while RPO is set PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** (FSN = 7F, BSN = 7F)FISU 1 - 0(FSN = 7F, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F): set LPO 1 - 0SIPO (FSN = 7F, BSN = 7F)1 - 0**FISU** (FSN = 0, BSN = 7F): clear LPO MSU 1 - 0(FSN = 0, BSN = 7F)1 - 0**FISU** (FSN = 0, BSN = 0)1 - 0MSU (FSN = 0, BSN = 7F)1 - 0**FISU** (FSN = 0, BSN = 0)TEST DESCRIPTION Generate an MSU at A. 1. 2. Instead of sending positive acknowledgement, set and keep PO at B. 3. Check A stops a retransmission of the MSU and sends FISUs, and does not detect link failure by the expiration of T7. 4. Cease PO and send an MSU with no positive acknowledgement at B. 5. Check A flushed its buffer and no old MSU is sent. 6. Generate an MSU at B. 7. Check A receives the MSU and responds correctly.

TEST NUMBER: 9.8	PAGE: 1 OF 1						
REFERENCE: Q.703 Subclause 6.3 STD: Fig. 16							
TITLE: Transmission and reception control (PCR)							
SUB TITLE: Abnormal BSN – Single MSU							
PURPOSE: To test the response to an abnormal BSN							
PRE-TEST CONDITIONS: Link in service							
CONFIGURATION: 1	TYPE OF TEST: VAT						
EXPECTED SIGNAL UNIT SEQUENCE:							
SP B	SP A						
Link  1 - 0 FISU	Link $1-0   FISU   (FSN = 7F, BSN = 7F)$ $1-0   FISU   (FSN = 7F, BSN = 0)$						
TEST DESCRIPTION	TEST DESCRIPTION						
<ol> <li>Generate a single MSU at B with abnormal BSN followed by retransmission of that MSU with normal BSN.</li> <li>Check that A responds with a positive acknowledgement and not detect link failure.</li> </ol>							

TEST NUMBER: 9.9 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.3 STD: Fig. 16 TITLE: Transmission and reception control (PCR) SUB TITLE: Abnormal BSN - Two MSUs PURPOSE: To test the response to two consecutive MSUs with an MSU having normal BSN between them PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0FISU (FSN = 7F, BSN = 7F)1 - 0FISU (FSN = 7F, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7E)1 - 0MSU (FSN = 0, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7E)1 - 0SIOS (FSN = 7F, BSN = 7F)TEST DESCRIPTION 1. Generate two consecutive MSUs at B with abnormal BSN with an MSU having normal BSN between them. 2. Check that all MSUs are discarded at A. 3. Check that A responds by taking the link out of service.

TEST	TEST NUMBER: 9.10			PAGE: 1 OF 1	
REFE	RENCE: Q.703 Subclause 6.2 S	STD: Fig. 16			
TITLE	: Transmission and reception control	(PCR)			
SUB T	TTLE: Unexpected FSN				
PURP	OSE: To check the reception control	response to an MSU with unexpected FS	SN		
PRE-T	EST CONDITIONS: Link in service				
CONF	IGURATION: 1		TYPE OF TH	EST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:				
	SP B			SP A	
Link  1-0  1-0  1-0	FISU (FSN = 7F, BSN = 7F) MSU (FSN = 0, BSN = 7F) MSU (FSN = 2, BSN = 7F)	<>>>> <	Link 1 – 0	FISU (FSN = 7F, BSN = 7F) FISU (FSN = 7F, BSN = 0)	
TEST	DESCRIPTION				
1. 2.	Generate an MSU with unexpected F Check A discards the MSU with unex	SN at B.  Expected FSN and not sends acknowledge	ement for that N	MSU.	

TEST NUMBER: 9.11 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.3 STD: Fig. 15 TITLE: Transmission and reception control (PCR) SUB TITLE: Excessive delay of acknowledgement PURPOSE: To test the transmission control response to the expiration of EDA timer T7 PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0FISU (FSN = 7F, BSN = 7F)1 - 0FISU (FSN = 7F, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)SIOS 1 - 0(FSN = 0, BSN = 7F)TEST DESCRIPTION 1. Generate an MSU at A. 2. Suspend sending positive acknowledgement at B for more than T7 period. 3. Check that A sends SIOSs instead of retransmission of MSU after T7 expires. 4. Timer T7 shall be in the range 0.5 secs to 2.0 secs.

TEST NUMBER: 9	0.12		PAGE: 1 OF 1	
REFERENCE: Q.7	03 Subclause 6.2 S	TD: Fig. 16		
TITLE: Transmissi	on and reception control	(PCR)		
SUB TITLE: FISU	with FSN expected for N	MSU		
PURPOSE: To che	ck that the received FISU	U having FSN expected for MSU is disc	arded	
PRE-TEST CONDIT	ΓΙΟΝS: Link in service			
CONFIGURATION	: 1		TYPE OF TE	EST: VAT
EXPECTED SIGNA	L UNIT SEQUENCE:			
SP	В			SP A
Link			Link	
1-0 FISU (FSN =	7F, BSN = 7F)	>		
		<	1 – 0	FISU (FSN = 7F, BSN = 7F)
1-0 FISU (FSN =	0, BSN = 7F)	>		
		<	1 – 0	FISU (FSN = 7F, BSN = 7F)
TEST DESCRIPTIO	N .			
1. Generate an	FISU with FSN expected	f for MSU at B.		
2. Check that A	discards the FISU and r	responds with an FISU with correct BSN	٧.	

TEST	NUMBER: 9.13	PAGE: 1 OF 1				
REFERENCE: Q.703 Clause 7 STD: Fig. 16						
TITLE	E: Transmission and reception control (PCR)					
SUB	FITLE: Level 3 Stop command					
PURP	OSE: To test the response to a Stop command					
PRE-7	TEST CONDITIONS: Link in service					
CONF	FIGURATION: 1	TYPE OF TH	EST: VAT			
EXPE	CTED SIGNAL UNIT SEQUENCE:					
	SP B		SP A			
Link		Link				
	<	1 - 0	FISU			
1-0	FISU>					
			: stop			
	<	1 – 0	SIOS			
TEST	DESCRIPTION					
1.	Give Stop command at A.					
2.	Check that A responds with link out of service.					

TEST	NUMBER: 10.1	PAGE: 1 OF 1		
REFE	RENCE: Q.703 Clause 9 STD: Fig. 19			
TITLE	E: Congestion Control			
SUB T	TITLE: Congestion abatement			
PURP	OSE: To check the congestion abatement procedure			
PRE-T	TEST CONDITIONS: Link in service			
CONF	TIGURATION: 1	TYPE OF TE	ST: VAT	
EXPE	CTED SIGNAL UNIT SEQUENCE:			
	SP B		SP A	
Link		Link		
			: make congestion state	
	<	1 – 0	SIB	
		Т5		
	<	1 – 0	SIB	
			•	
			: clear congestion state	
	<	1 - 0	FISU	
TEST	DESCRIPTION			
1.	Make congestion state at A and check A sends SIB.  (Implementation of congestion control is not specified.)			
2.	Check B receives SIBs at the interval of T5.			
3.	Clear congestion state at A and check A stops sending SIBs.			
4.	Timer T5 shall be in the range 80 ms to 120 ms.			

				<u> </u>		
TEST	EST NUMBER: 10.2 PAGE: 1 OF 1					F 1
REFE	RENCE: Q.703 Subcla	ause 9.2	STD: Fig. 19			
TITLE	E: Congestion Control					
SUB T	TITLE: Timer T7					
PURP	OSE: To check timer	T7 is restarted	d at the reception	of SIB (without expiring	g of T6)	
PRE-T	TEST CONDITIONS:	Link in service	ce			
CONF	IGURATION: 1				TYPE OF T	EST: VAT
EXPE	CTED SIGNAL UNIT	SEQUENCE:	:			
	SP B					SP A
Link					Link	
			<		1 - 0	MSU
1 – 0	SIB			>		
1 – 0	SIB •	Ct		>		
	•					
1 – 0	SIB	Bt		>		Т6
1 – 0	FISU	I		>		
						'
TEST	DESCRIPTION					
1.	Generate an MSU at A	 A.				
2.	Generate SIBs at B w	ith the time ir	ntervals of T5 for	Ct, instead of positive a	ncknowledgeme	nt.
3.				1	C	
4.	Check that link remains in service during Ct.  Send FISU with positive acknowledgement from B after Bt expires.					
5.	Check that link remain		agement from B a	inter Breaphes.		
6.	Ct = more than T7 and					
7.	Ct = more than  T /  and Bt = less than  T7.	a icoo man 10	·.			
		T.C				
8.	(Ct + Bt) is less than $T$	10.				

TEST	TEST NUMBER: 10.3			PAGE: 1 OF 1			
REFE	REFERENCE: Q.703 Subclause 9.3 STD: Fig. 19						
TITLE	E: Congestion Control						
SUB 7	FITLE: Timer T6						
PURP	OSE: To check "Remote Conge	estion" Timer T6					
PRE-T	TEST CONDITIONS: Link in so	ervice					
CONF	FIGURATION: 1		TYPE OF T	EST: VAT			
EXPE	CTED SIGNAL UNIT SEQUEN	ICE:					
	SP B			SP A			
Link 1 – 0	SIB	>	Link	1			
1 - 0 1 - 0	SIB	>					
	•			Т6			
1 – 0	SIB	>					
	•						
1 – 0	SIB	>					
		<	1 - 0	SIOS			
TEST	DESCRIPTION						
1.	Generate SIB at B until Timer	_					
2.	Check link becomes out of serv	vice.					
3.	Timer T6 shall be in the range?	3 secs to 6 secs (8 to 12 secs for 4.8 k	bit/s).				