Workshop
ITU HFBC software

Nedialko Miltchev
Broadcasting Services Division
International Telecommunication Union

Introduction to the ITU HFBC software package

- **General principles:**
  - Consistent with Article 12 and Resolution 535 (WRC-97).
  - Developed in consultation with administrations, broadcasters, and coordination groups.
  - Takes into account the availability of suitable computer hardware by administrations to run the software.

Key features of the software modules

- **HFBC REQ – Data capture**
- **ITU HFBC – Calculation software**
- **HFBC VAL – Data validation**
- **HFBC ANT – Antenna calculation**

HFBC REQ – Data capture

- Capture new HFBC requirements.
- Modify existing requirements files.
- Change “Start/Stop date” of a season.
- Create a notification file.

The software is linked to the HFBC

<u>Reference tables</u>

Reference data

- HFBC database, called Reference tables, maintained by ITU.
- 15 reference tables.
- Unique codes.
- To simplify the schedule and the notification file.

- **Update them regularly!** from the ITU web site

HFBC REQ – Data capture



ITU HFBC – Calculation soft

- Displays the seasonal schedule: list view, maps view.
- Propagation prediction: calculates propagation data; results in tabular form or on maps.
- Compatibly analysis: calculates interference from other requirements; identifies interference sources; results are shown on maps.

ITU HFBC – Calculation soft



HFBC VAL – Data validation

- **Assists administrations to validate their requirement files before submission.**
  - For RR12 HFBC bands.
  - For Regional Coordination Groups bands
  - Detects and displays errors

- **Remove requirements with frequencies out of RR12 bands.**

HFBC VAL – Data validation

HFBC VAL 2.0 - M:\BRTSD\BCD\HFBC\B10\B10S1ReadyForPublication\B10T2-15918-CZE.txt

File Edit Validate Tools Help Français Español

4 error(s); Total number of requirements = 26

```
; B10 CZE 30-AUG-2010 TCH
;
;
;----+----+----+------------------------------+---+----+-------+---+---+-------+------+------+-+-----+----------+---+---+---+-----+-+-----+-----+-----+-------
;FREQ STRT STOP CIRAF ZONES                    LOC POWR AZIMUTH SLW ANT DAYS    FDATE  TDATE MOD AFRQ LANGUAGE   ADM BRC FMO REQ# OLD ALT1 ALT2  ALT3  NOTES
;----+----+----+------------------------------+---+----+-------+---+---+-------+------+------+-+-----+----------+---+---+---+-----+-+-----+-----+-----+-------
 5930 0700 0800 27,28,37                       LIT  100 260       0 101 1234567 311010 270311 D       FraDeu     CZE RPR TCH  8086
 3333 1600 1630 27,28                          LIT  100 260       0 101 1234567 311010 270311 D       Deu        CZE RPR TCH  8087
 5930 1700 1730 99                             LIT  100 290       0 206 1234567 311010 270311 D       Eng        CZE RPR TCH  8089
 5930 1730 1800 27,28                          LIT  100 260       0 206 1234567 311010 270311 D       Fra        CZE RPR TCH  8090
 5930 1800 1830 27,28                          ZZZ  100 290       0 206 1234567 311010 270311 D       Eng        CZE RPR TCH  8091
 5930 1900 2000 27,28,36,37                    LIT  100 245       0 894 1234567 311010 270311 D       SpaFra     CZE RPR TCH  8094
 5930 2000 2100 27,28,36,37                    LIT  100 245       0 894 1234567 311010 270311 D       SpaCes     CZE RPR TCH  8093
 5930 2100 2130 27,28                          LIT  100 290       0 206 1234567 311010 270311 D       Eng        CZE RPR TCH  6346
 5930 2130 2230 13,14,37                       LIT  100 365       0 894 1234567 311010 270311 D       SpaCes     CZE RPR TCH 14123
 5930 2300 2400 3-10                           LIT  100 310       0 146 1234567 311010 270311 D       FraEng     CZE RPR TCH  8084
 5980 0500 0530 28-30                          LIT  100 60        0 206 1234567 311010 270311 D       Rus        CZE RPR TCH  8096
 5995 1830 1900 28-31                          LIT  100 60        0 206 1234567 311010 270311 D       Rus        CZE RPR TCH 12238
 6055 1230 1300 28-31                          LIT  100 60        0 206 1234567 311010 270311 D       Rus        CZE RPR TCH  8097
 6055 1300 1400 18,27,28                       LIT  100 0         0 927 1234567 311010 270311 D       DeuCes     CZE RPR TCH  6351
 7280 1630 1700 38-40                          LIT  100 125       0 891 1234567 311010 270311 D       Ces        CZE RPR TCH 14122
 7345 0300 0330 12-16                          LIT  100 245       0 894 1234567 311010 270311 D       Spa        CZE RPR TCH 15132
 7345 0330 0430 7-10                           LIT  200 310       0 146 1234567 311010 270311 D       CesEng     CZE RPR TCH 15131
 7345 0800 0830 27                             LIT  100 290       0 206 1234567 311010 270311 D       Eng        CZE RPR TCH  6360
 7345 1100 1130 27-29                          LIT  200 0         0 926 1234567 311010 270311 D       Deu        CZE RPR TCH  6358
 7355 2230 2300 37,38,46,47                    LIT  100 199       0 146 1234567 311010 270311 D       Eng        CZE RPR TCH  6392
 7410 0100 0300 7-10                           LIT  100 310       0 146 1234567 311010 270311 D       EngSpaCes  CZE RPR TCH 14074
 7420 1530 1600 29-32                          LIT  100 60        0 206 1234567 311010 270311 D       Rus        CZE RPR TCH 14143
 9790 0000 0100 12-16                          LIT  100 245       0 878 1234567 311010 270311 D       SpaCes     CZE RPR TCH  8085
 9855 0430 0500 38,39,48                       LIT  100 144       0 892 1234567 311010 270311 D       Eng        CZE RPR TCH  6369
 9880 1130 1230 18,28                          LIT  100 356       0 878 1234567 311010 270311 D       EngCes     CZE RPR TCH  8101
21745 1000 1100 37,46                          LIT  100 210       0 878 1234567 311010 270311 D       EngCes     CZE RPR TCH  6387
```

HFBC ANT – Antenna calculation

- Theoretical approach based on Recommendation ITU-R BS.705
- Calculates the radiation patterns and gain of the most common used HF antennas.
- Provide quick reference for administrations and broadcasters in identifying antennas.

HFBC ANT – Antenna calculation



HFBC software - installation

From the CD-ROM:

Installation Notes-E.docx

Thank you for your attention!