TELECOMMUNICATION STANDARDIZATION SECTOR OF ITU

Q.781 (07/96)

SERIES Q: SWITCHING AND SIGNALLING Specifications of Signalling System No. 7 – Test specification

MTP level 2 test specification

ITU-T Recommendation Q.781

(Previously CCITT Recommendation)

ITU-T Q-SERIES RECOMMENDATIONS

SWITCHING AND SIGNALLING

SIGNALLING IN THE INTERNATIONAL MANUAL SERVICE	Q.1–Q.3
INTERNATIONAL AUTOMATIC AND SEMI-AUTOMATIC WORKING	Q.4–Q.59
FUNCTIONS AND INFORMATION FLOWS FOR SERVICES IN THE ISDN	Q.60-Q.99
CLAUSES APPLICABLE TO ITU-T STANDARD SYSTEMS	Q.100-Q.119
SPECIFICATION OF SIGNALLING SYSTEMS No. 4 AND No. 5	Q.120-Q.249
SPECIFICATIONS OF SIGNALLING SYSTEM No. 6	Q.250-Q.309
SPECIFICATIONS OF SIGNALLING SYSTEM R1	Q.310-Q.399
SPECIFICATIONS OF SIGNALLING SYSTEM R2	Q.400-Q.499
DIGITAL EXCHANGES	Q.500-Q.599
INTERWORKING OF SIGNALLING SYSTEMS	Q.600-Q.699
SPECIFICATIONS OF SIGNALLING SYSTEM No. 7	Q.700-Q.849
General	Q.700
Message transfer part	Q.701-Q.709
Simplified message transfer part	Q.710
Signalling connection control part	Q.711-Q.719
Telephone user part	Q.720-Q.729
ISDN supplementary services	Q.730-Q.739
Data user part	Q.740-Q.749
Signalling System No. 7 management	Q.750-Q.759
ISDN user part	Q.760-Q.769
Transaction capabilities application part	Q.770-Q.779
Test specification	Q.780 – Q.799
Q3 interface	Q.800-Q.849
DIGITAL SUBSCRIBER SIGNALLING SYSTEM No. 1	Q.850-Q.999
PUBLIC LAND MOBILE NETWORK	Q.1000-Q.1099
INTERWORKING WITH SATELLITE MOBILE SYSTEMS	Q.1100-Q.1199
INTELLIGENT NETWORK	Q.1200-Q.1999
BROADBAND ISDN	Q.2000-Q.2999

For further details, please refer to ITU-T List of Recommendations.

ITU-T RECOMMENDATION Q.781

MTP LEVEL 2 TEST SPECIFICATION

Summary

This Recommendation contains a set of detailed tests of Signalling System No. 7 MTP level 2 protocol. These tests intend to validate the protocol specified in Recommendation Q.703.

This Recommendation conforms to Recommendation Q.780 which describes the basic rules of the Test Specification. In addition, the conditions which are specific to level 2 tests are described.

Source

ITU-T Recommendation Q.781 was revised by ITU-T Study Group 11 (1993-1996) and was approved under the WTSC Resolution No. 1 procedure on the 9th of July 1996.

FOREWORD

ITU (International Telecommunication Union) is the United Nations Specialized Agency in the field of telecommunications. The ITU Telecommunication Standardization Sector (ITU-T) is a permanent organ of the ITU. The ITU-T is responsible for studying technical, operating and tariff questions and issuing Recommendations on them with a view to standardizing telecommunications on a worldwide basis.

The World Telecommunication Standardization Conference (WTSC), which meets every four years, establishes the topics for study by the ITU-T Study Groups which, in their turn, produce Recommendations on these topics.

The approval of Recommendations by the Members of the ITU-T is covered by the procedure laid down in WTSC Resolution No. 1.

In some areas of information technology which fall within ITU-T's purview, the necessary standards are prepared on a collaborative basis with ISO and IEC.

NOTE

In this Recommendation, the expression "Administration" is used for conciseness to indicate both a telecommunication administration and a recognized operating agency.

INTELLECTUAL PROPERTY RIGHTS

The ITU draws attention to the possibility that the practice or implementation of this Recommendation may involve the use of a claimed Intellectual Property Right. The ITU takes no position concerning the evidence, validity or applicability of claimed Intellectual Property Rights, whether asserted by ITU members or others outside of the Recommendation development process.

As of the date of approval of this Recommendation, the ITU had/had not received notice of intellectual property, protected by patents, which may be required to implement this Recommendation. However, implementors are cautioned that this may not represent the latest information and are therefore strongly urged to consult the TSB patent database.

© ITU 1997

All rights reserved. No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from the ITU.

CONTENTS

		Page
1	Introduction	1
2	General principles of level 2 tests	1
2.1	Presentation of test descriptions	1
2.2	Presentation of the test list	1
3	Test configuration	1
4	Test environment	2
5	Test list	2
6	Test descriptions	6

Recommendation Q.781

MTP LEVEL 2 TEST SPECIFICATION

(Melbourne, 1988; modified at Helsinki, 1993; revised in 1996)

1 Introduction

This Recommendation contains a set of detailed tests of signalling system No. 7 MTP level 2 protocol. These tests intend to validate the protocol specified in Recommendation Q.703.

This Recommendation conforms to Recommendation Q.780 which describes the basic rules of the Test Specification. In addition, the conditions which are specific to level 2 tests are described in the following clauses.

2 General principles of level 2 tests

2.1 Presentation of test descriptions

The level 2 tests aim at testing the level 2 protocol conformance in a given implementation.

Each test description indicates in the "type of test" column; "Validation" (VAT) or "Validation" (VAT) and "compatibility" (CPT).

Although signal units are transmitted and received continuously on level 2, only the signal units which cause and/or indicate the changes of level 2 status are shown in the EXPECTED SIGNAL UNIT SEQUENCE column of each test description.


2.2 Presentation of the test list

These tests as a whole, aim at a complete validation of the level 2 protocol without redundancies. Each test is described as simply as possible to check precisely each elementary function of the protocol, which is referred in the columns "reference", "title" and "sub-title" of each test description.

This list is presented in the form of a succession of tests. The presentation order is essentially functional. However, the operator performing these tests may change this order, taking into account some other practical criteria such as: use pre-test conditions to order the list, the end of a given test may be the pre-test condition of another test.

3 Test configuration

A single link will be used for level 2 tests. Figure 1 shows a single link between SP A and SP B. Test specifications are written to test the level 2 of the SP A.



NOTE – First digit: linkset number. Second digit: link number.

Figure 1/Q.781 – Test configuration of MTP level 2 test Configuration 1

4 Test environment

See 6.2/Q.780.

5 Test list

NOTE – Compatibility test items are indicated in this list by an asterisk (*).

The abbreviations PO, LPO, RPO, EM and EDA are used for processor outage, local processor outage, remote processor outage, emergency and expected delay of acknowledgement, respectively.

- 1 Link State Control Expected signal units/orders (see Figures 8/Q.703 and 9/Q.703)
- * 1.1 Initialisation (Power-up)
- * 1.2 Timer T2
 - 1.3 Timer T3
 - 1.4 Timer T1 and T4 (Normal)
- * 1.5 Normal alignment correct procedure (FISU)
 - 1.6 Normal alignment correct procedure (MSU)
 - 1.7 SIO received during normal proving period
 - 1.8 Normal alignment with PO set (FISU)
 - 1.9 Normal alignment with PO set (MSU)
 - 1.10 Normal alignment with PO set and clear
 - 1.11 Set RPO when "Aligned not ready"
 - 1.12 SIOS received when "Aligned not ready"
 - 1.13 SIO received when "Aligned not ready"
 - 1.14 Set and clear LPO when "Initial alignment"
 - 1.15 Set and clear LPO when "Aligned ready"
 - 1.16 Timer T1 in "Aligned not ready" state
 - 1.17 No SIO sent during normal proving period
 - 1.18 Set and cease emergency prior to "start alignment"
- 1.19 Set emergency while in "not aligned state"
 - 1.20 Set emergency when "aligned"
 - 1.21 Both ends set emergency
 - 1.22 Individual end sets emergency

- 1.23 Set emergency during normal proving
- 1.24 No SIO sent during emergency alignment
- 1.25 Deactivation during initial alignment
 - 1.26 Deactivation during aligned state
 - 1.27 Deactivation during aligned not ready
 - 1.28 SIO received during link in service
 - 1.29 Deactivation during link in service
 - 1.30 Deactivation during LPO
 - 1.31 Deactivation during RPO
 - 1.32 Deactivation during the proving period
 - 1.33 SIO received instead of FISUs
 - 1.34 SIOS received instead of FISUs
 - 1.35 SIPO received instead of FISUs
 - 2 Link State Control Unexpected signal units/orders (see Figure 8/Q.703)
 - 2.1 Unexpected signal units/orders in "Out of service" state
 - 2.2 Unexpected signal units/orders in "Not aligned" state
 - 2.3 Unexpected signal units/orders in "Aligned" state
 - 2.4 Unexpected signal units/orders in "Proving" state
 - 2.5 Unexpected signal units/orders in "Aligned ready" state
 - 2.6 Unexpected signal units/orders in "Aligned not ready" state
 - 2.7 Unexpected signal units/orders in "In service" state
 - 2.8 Unexpected signal units/orders in "Processor outage" state
 - 3 Transmission failure (see Figure 8/Q.703)
 - 3.1 Link aligned ready (Break Tx path)
 - 3.2 Link aligned ready (Corrupt FIBs Basic)
 - 3.3 Link aligned not ready (Break Tx path)
 - 3.4 Link aligned not ready (Corrupt FIBs Basic)
 - 3.5 Link in service (Break Tx path)
 - 3.6 Link in service (Corrupt FIBs Basic)
 - 3.7 Link in processor outage (Break Tx path)
 - 3.8 Link in processor outage (Corrupt FIBs Basic)
 - 4 Processor Outage Control (see Figure 10/Q.703)
 - 4.1 Set and clear LPO while link in service
 - 4.2 RPO during LPO
 - 4.3 Clear LPO when "Both processor outage"
 - 5 SU Delimitation, Alignment, Error Detection and Correction (see Figures 11/Q.703 and 12/Q.703)
 - 5.1 More than seven "1"s between MSU opening and closing flags
 - 5.2 Greater than maximum signal unit length

- 5.3 Below minimum signal unit length
- 5.4 Reception of single and multiple flags between FISUs
- 5.5 Reception of single and multiple flags between MSUs
- 6 SUERM Check (see Figure 18/Q.703)
 - 6.1 Error rate of 1 in 256 Link remains in service
 - 6.2 Error rate of 1 in 254 Link into out of service
 - 6.3 Consecutive corrupted SUs
 - 6.4 Time controlled break of the link
- 7 AERM check (see Figure 17/Q.703)
 - 7.1 Error rate below the normal threshold
 - 7.2 Error rate at the normal threshold
 - 7.3 Error rate above the normal threshold
 - 7.4 Error rate at the emergency threshold
- 8 Transmission and reception control (Basic) (see Figures 13/Q.703 and 14/Q.703)
 - 8.1 MSU transmission and reception
 - 8.2 Negative acknowledgement of MSU
 - 8.3 Check RTB full
 - 8.4 Single MSU with erroneous FIB
 - 8.5 Duplicated FSN
 - 8.6 Erroneous retransmission Single MSU
 - 8.7 Erroneous retransmission Multiple FISUs
 - 8.8 Single FISU with corrupt FIB
 - 8.9 Single FISU prior to RPO being set
 - 8.10 Abnormal BSN Single MSU
 - 8.11 Abnormal BSN Two consecutive FISUs
 - 8.12 Excessive delay of acknowledgement
 - 8.13 Level 3 Stop Command
- 9 Transmission and reception control (PCR) (see Figures 15/Q.703 and 16/Q.703)
 - 9.1 MSU transmission and reception
 - 9.2 Priority control
 - 9.3 Forced retransmission with the value N_1
 - 9.4 Forced retransmission with the value N₂
 - 9.5 Forced retransmission cancel
 - 9.6 Repetition of forced retransmission
 - 9.7 MSU transmission while RPO set
 - 9.8 Abnormal BSN Single MSU
 - 9.9 Abnormal BSN Two MSUs
 - 9.10 Unexpected FSN
 - 9.11 Excessive delay of acknowledgement

Recommendation Q.781 (07/96)

4

- 9.12 FISU with FSN expected for MSU
- 9.13 Level 3 Stop Command
- 10 Congestion Control (see Figure 19/Q.703)
 - 10.1 Congestion abatement
 - 10.2 Timer T7
 - 10.3 Timer T6

6 Test descriptions

TEST	Γ NUMBER: 1.1	PAGE: 1 OF 1			
REFI	ERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 12; Fig. 13				
TITL	E: Link State Control – Expected signal units/orders				
SUB'	TITLE: Initialization (Power-up)				
PUR	POSE: To check that the No. 7 terminal equipment enters the co	orrect state on power-up			
PRE-	TEST CONDITIONS: Line equipment – ON; No. 7 equipment	t – OFF			
CON	FIGURATION: 1	TYPE OF TEST: VAT, CPT			
EXP	ECTED SIGNAL UNIT SEQUENCE:				
Link 1 – 0	SP B SIOS	SP A Link : Power ON 1 – 0 SIOS			
TEST	Γ DESCRIPTION				
2.	 Check link enters correct state. At "Power – On" or Initialization the FIB, BIB, FSN, and BSN shall be as follows: FIN = BIB = 1: FSN = BSN = 127 (HEX 7F). 				
3.	Repeat test in reverse direction.				

TEST NUMBER: 1.2	PAGE: 1 OF 1				
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9; Fig. 11; I	Fig. 13; Fig. 14				
TITLE: Link State Control – Expected signal units/orders					
SUBTITLE: Timer T2					
PURPOSE: To check "Not Aligned" Timer T2					
PRE-TEST CONDITIONS: Link out of service					
CONFIGURATION: 1	TYPE OF TEST: VAT, CPT				
EXPECTED SIGNAL UNIT SEQUENCE:					
SP B Link 1-0 SIOS	SP A Link 1 - 0 SIOS : start 1 - 0 SIO				
TEST DESCRIPTION					
1. Timer T2 shall be in the range 5 secs to 150 secs.					

TEST NUMBER: 1.3		PAGE: 1 OF 1				
REFERENCE: Q.703 Clause 7	STD: Fig. 9; Fig. 14					
TITLE: Link State Control – Ex	pected signal units/orders					
SUBTITLE: Timer T3						
PURPOSE: To check "Aligned"	Timer T3					
PRE-TEST CONDITIONS: Lin	k out of service					
CONFIGURATION: 1		TYPE OF TEST: VAT				
EXPECTED SIGNAL UNIT SEC	QUENCE:	,				
SP B Link		SP A Link				
LIIIK	<	1 – 0 SIOS				
1-0 SIOS	>	1-0 5105				
1-0 5105		: start				
	<	1 – 0 SIO				
1 – 0 SIO	· >	1 0 220				
	<	1-0 SIN				
		T3				
	<	1 – 0 SIOS				
TEST DESCRIPTION	TEST DESCRIPTION					
1. Timer T3 shall be in the rai	nge 1 sec to 1.5 secs.					

		·					
TEST NU	MBER: 1.4		PAGE: 1 OF 1				
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9							
TITLE: I	Link State Control – Expo	ected signal units/orders					
SUBTITL	E: Timer T1 & Timer T	^C 4 (Normal)					
PURPOSE	E: To check "Aligned re	ady" Timer T1 and "Proving perio	d" Timer T4 (Normal)			
PRE-TES	T CONDITIONS: Link	out of service					
CONFIGU	JRATION: 1		TYPE OF T	EST: VAT			
EXPECTE	ED SIGNAL UNIT SEQ	UENCE:					
	SP B			SP A			
Link			Link				
		<	1 – 0	SIOS			
1 - 0	SIOS	>					
				: start			
		<	1 – 0	SIO			
1 – 0	SIO	· >	1 0	STO			
1 0	510	<	1 – 0	SIN			
1 – 0	SIN	>	1 – 0				
1-0	SIIV			T4 (Pn)			
			1 - 0				
		<	1 – 0	FISU			
			1 0	T1			
		<	1 - 0	SIOS			
TEST DE	TEST DESCRIPTION						

- 1. At 64 kbit/s Timer T4 shall be in the range 7.5 secs to 9.5 secs (nominally 8.2 secs) and Timer T1 shall be in the range 40 secs to 50 secs.
- 2. At 4.8 kbit/s Timer T4 shall be in the range 100 secs to 120 secs (nominally 110 secs) and Timer T1 shall be in the range 500 secs to 600 secs.

			WIII, EE VEE 2		
TEST	Γ NUMBER:	1.5		PAGE: 1	1 OF 1
REFI	ERENCE: Q).703 Claus	se 7 STD: Fig. 8; Fig. 9		
TITL	E: Link Sta	te Control -	- Expected signal units/orders		
SUB'	TITLE: Not	mal alignm	nent – correct procedure (FISU)		
PUR	POSE: To c	heck norma	al alignment procedure		
PRE-	TEST CONI	DITIONS:	Link out of service		
CON	FIGURATIO)N: 1		TYPE O	F TEST: VAT, CPT
MES	SAGE SEQU	JENCE:			
	SP	В			SP A
Link				Link	
			<	1 - 0	SIOS
1 – 0	SIOS		>		
					: start
			<	1 - 0	SIO
1 – 0	SIO		>		
			<	1 - 0	SIN
1 – 0	SIN		>		
			<	1 - 0	FISU
1 – 0	FISU		>		
TEST DESCRIPTION					
1.	Start norma	l alignment	procedure.		
2.	Check link	aligns and	enters "In service" state.		
3.	Check that	"In service'	' state is maintained.		
4.	- use LS	SU in point	s possible to perform a normal alig B with a status field of 8 bits; B with a status field of 16 bits.	nment procedure	e in the following cases:

TEST	Γ NUMBER: 1.6		PAGE: 1 OF 1		
REF	ERENCE: Q.703 CI	lause 7 STD: Fig. 8; Fig. 9			
TITL	E: Link State Contr	rol – Expected signal units/orders			
SUB	TITLE: Normal alig	gnment – correct procedure (MSU)			
PUR	POSE: To check no	ormal alignment procedure			
PRE-	TEST CONDITION	S: Link out of service			
CON	FIGURATION: 1		TYPE OF TEST: VAT		
EXP	ECTED SIGNAL UN	NIT SEQUENCE:			
Link	SP B		SP A Link		
		<	1 – 0 SIOS		
1 – 0	SIOS	>			
			: start		
1 0	GIO.	<>	1 – 0 SIO		
1 – 0	SIO	<>	1 – 0 SIN		
1 – 0	SIN	>	i o siiv		
		<	1 – 0 FISU		
1 – 0	MSU	>			
TEST	Γ DESCRIPTION				
1.	Start normal alignm	nent procedure.			
2.	•				
3.	3. Check that "In service" state is maintained.				

TEST	ΓNUMBER: 1	7		PAGE: 1 OF 1	
REFI	ERENCE: Q.70	3 Clause 7, subclause 10.3	STD: Fig. 9; l	Fig. 17	
TITL	E: Link State	Control – Expected signal units	s/orders		
SUB	ΓΙΤLE: SIO re	ceived during normal proving	period		
PUR	POSE: To test	the response to the reception o	f an SIO during th	e normal pro	oving period
PRE-	TEST CONDIT	IONS: Link out of service			
CON	FIGURATION	1		TYPE OF	TEST: VAT
EXP	ECTED SIGNA	L UNIT SEQUENCE:			
Link 1-0 1-0 1-0 1-0 1-0	SIOS SIO SIN SIO (one only)	<	>>>>>	Link $1-0$ $1-0$ $1-0$ $1-0$ $1-0$	SP A SIOS : start SIO SIN T4 Stopped SIN T4(Pn) FISU
TEST DESCRIPTION					
1. 2.		B during normal proving perion normal period is entered.	od.		

TEST	NUMBER:	1.8	PAGE: 1 OF 1		
REFE	ERENCE: Q	.703 Clauses 7,	8 STD: Fig. 8		
TITL	E: Link State	e Control – Exp	ected signal units/orders		
SUBT	TITLE: Norr	nal alignment w	rith PO set (FISU)		
PURI	POSE: To ch	eck the respons	e following normal alignment whe	n PO has be	en set
PRE-	TEST COND	ITIONS: Link	out of service		
CON	FIGURATIO	N: 1		TYPE OF	TEST: VAT
EXPE	ECTED SIGN	AL UNIT SEQ	UENCE:		
	SP	В			SP A
Link				Link	
			<	1 - 0	SIOS
1 - 0	SIOS		>		
					: set LPO : start
			<	1 - 0	SIO
1 – 0	SIO		>		
			<	1 - 0	SIN
1 – 0	SIN		>		
			<	1 - 0	SIPO
1 - 0	FISU		>		
			<	1 - 0	SIPO
TEST DESCRIPTION					
1. Check that normal alignment is carried out with LPO set at A.					
2.					
3.	Repeat test v	with LPO set at 1	В.		

TEST	TEST NUMBER: 1.9				PAGE: 1 OF 1		
REFE	ERENCE: Q	703 Clauses 7,	8 STD: Fig. 8				
TITL	E: Link State	e Control – Exp	pected signal units/orders				
SUB	ΓΙΤLE: Norr	nal alignment w	with PO set (MSU)				
PURI	POSE: To ch	eck the respons	se following normal alignment whe	n PO has been	n set		
PRE-	TEST COND	ITIONS: Link	out of service				
CON	FIGURATIO	N: 1		TYPE OF T	TEST: VAT		
EXPI	ECTED SIGN	AL UNIT SEQ	UENCE:				
	SP	В			SP A		
Link				Link			
			<	1 - 0	SIOS		
1 – 0	SIOS		>				
					: set LPO : start		
			<	1 - 0	SIO		
1 – 0	SIO		>				
			<	1 - 0	SIN		
1 – 0	SIN		>				
			<	1 - 0	SIPO		
1 – 0	MSU		>				
			<	1 - 0	SIPO		
TEST DESCRIPTION							
1.	1. Check that normal alignment is carried out with LPO set at A.						
2.							
3.	Repeat test v	vith LPO set at	В.				

TEST NUMBER: 1.10	PAGE: 1 OF 1		
REFERENCE: Q.703 Clauses 7, 8 STD: Fig. 8			
TITLE: Link State Control – Expected signal units/orders			
SUBTITLE: Normal alignment with PO set and clear			
PURPOSE: To check the response following normal alignment whe	n PO has been set and cleared		
PRE-TEST CONDITIONS: Link out of service			
CONFIGURATION: 1	TYPE OF TEST: VAT		
EXPECTED SIGNAL UNIT SEQUENCE:			
SP B Link	SP A Link		
1 – 0 SIOS>	1 - 0 SIOS: set LPO: clear LPO: start		
<> 1 – 0 SIO>	1 – 0 SIO		
<> 1 – 0 SIN>	1-0 SIN		
1 – 0 SIN <	1 – 0 FISU		
TEST DESCRIPTION			
 Check that normal alignment is carried out. Check that link aligns and enters "In service" state. 			

TEST	NUMBER: 1.11		PAGE: 1 OF 1		
REFE	ERENCE: Q.703 Clauses 7,	. 8 STD: Fig. 8			
TITL	E: Link State Control – Exp	pected signal units/orders			
SUBT	FITLE: Set RPO when "Ali	gned not ready"			
PURF	POSE: To check the respon	se following normal alignment whe	n PO has been	set	
PRE-	TEST CONDITIONS: Link	k out of service; ability to set PO			
CONI	FIGURATION: 1		TYPE OF T	EST: VAT	
EXPE	ECTED SIGNAL UNIT SEC	UENCE:			
Link 1-0 1-0 1-0	SP B SIOS : set LPO SIO SIN SIPO	<> <> <> <> <>	Link 1 - 0 1 - 0 1 - 0 1 - 0	SP A SIOS : set LPO : start SIO SIN SIPO	
TEST DESCRIPTION					
1.	TEST DESCRIPTION 1. Set LPO at A and B.				
2.	Start alignment.				
3.	Check that both LPO and R	PO after alignment completes.			

TEST	TEST NUMBER: 1.12			PAGE: 1 OF 1		
REFI	ERENCE: Q.703 Clauses 7	7, 8 STD: Fig. 8				
TITL	E: Link State Control – Ex	xpected signal units/orders				
SUB	ΓΙΤLE: SIOS received wh	en "Aligned not ready"				
PURI	POSE: To check the respo	nse following normal alignment wh	en PO has be	en set		
PRE-	TEST CONDITIONS: Li	nk out of service				
CON	FIGURATION: 1		TYPE OF	TEST: VAT		
EXPI	ECTED SIGNAL UNIT SE	QUENCE:	1			
	SP B			SP A		
Link			Link			
Zink		<	1-0	SIOS		
1-0	SIOS	>	1-0	5105		
1-0	5105			: set LPO		
				: set LPO : start		
		<	1 – 0	SIO		
1-0	SIO	` >	1 0	510		
1 0	510	<	1 - 0	SIN		
1-0	SIN	>	1 – 0	5111		
1-0	SIIV	<	1 - 0	SIPO		
	· stop	\	1 – 0	311 0		
1-0	: stop SIOS	>				
1 0	2100	<	1 - 0	SIOS		
			- •	222		
TEST DESCRIPTION						
1.	Soon after alignment com	pletes, A enters "Aligned not ready"				
2.	•	es, stop command is given at B.				
3.		f SIOS, A enters "Out of service" st	ate.			
4.	Repeat test with LPO set a					
	*					

TEST	NUMBER:	1.13			PAGE: 1 OF 1		
REFE	ERENCE: Ç	.703 Clau	uses 7, 8 STD: Fig. 8				
TITL	E: Link Sta	te Control	- Expected signal units/orders				
SUB	ΓΙΤLE: SIO	received	when "Aligned not ready"				
PURI	POSE: To c	heck the r	esponse following normal alignm	nent whe	n PO has t	oeen set	
PRE-	TEST CONI	DITIONS:	Link out of service				
CON	FIGURATIC	N: 1			TYPE O	OF TEST: VAT	
EXPI	ECTED SIGN	NAL UNI	T SEQUENCE:				
Link	SP	В			Link	SP A	
1 – 0	SIOS		<>		1 – 0	SIOS	
						: set LPO : start	
1 – 0	SIO		<>		1 – 0	SIO	
			<		1 – 0	SIN	
1 – 0	SIN		<>		1 – 0	SIPO	
1 – 0	SIO		<>		1 – 0	SIOS	
TEST	DESCRIPT						
1.		· ·	completes, A enters "Aligned nor	t ready".			
2.	_		inpletes at B, SIO is sent to A.				
3.		_	ion of SIO, A enters "Out of serv	ice" state	e .		
4.	Repeat test	wiui LPO	set at D.				

TEST	NUMBER: 1.14		PAGE:	PAGE: 1 OF 1		
REFE	ERENCE: Q.703 Claus	ses 7, 8 STD: Fig. 8				
TITL	E: Link State Control	- Expected signal units/orders				
SUBT	ΓΙΤLE: Set and clear I	LPO when "Initial alignment"				
PURI	POSE: To check norma	al alignment when PO set and clear du	ring "Initial	alignment"		
PRE-	TEST CONDITIONS:	Link out of service				
CON	FIGURATION: 1		TYPE C	OF TEST: VAT		
EXPE	ECTED SIGNAL UNIT	SEQUENCE:				
Link	SP B		Link	SP A		
1 0	giog	<	1 – 0	SIOS		
1-0	SIOS	>		: start		
1 – 0	SIO	<>	1 - 0	SIO		
1-0	510	<	1 – 0	SIN		
1-0	SIN	>		: set LPO		
				: clear LPO		
1-0	FISU	<>	1 - 0	FISU		
1-0	1150	<	1 – 0	FISU		
TEST DESCRIPTION						
1. 2. 3. 4. 5.	 Set LPO at A during "Initial alignment" state. Check A remains in "Initial alignment" state. Clear LPO before alignment completes at A. Check A enters "In service" state after normal alignment. 					

PAGE: 1 OF 1 TEST NUMBER: 1.15 REFERENCE: Q.703 Clauses 7, 8 STD: Fig. 8 TITLE: Link State Control – Expected signal units/orders SUBTITLE: Set and clear LPO when "aligned ready" PURPOSE: To test the response to LPO when "aligned ready" and to ensure that the aligned ready state resumes when LPO is cleared PRE-TEST CONDITIONS: Link out of service TYPE OF TEST: VAT CONFIGURATION: 1 EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**SIOS** <-----1 - 0**SIOS** ----> : start SIO 1 - 01 - 0**SIO** ----> 1 - 0SIN 1 - 0SIN 1 - 0**FISU** : set LPO 1 - 0**SIPO** : wait 5 secs. : clear LPO 1 - 0**FISU TEST DESCRIPTION** Start link at A. 1. At "aligned ready" state set LPO at A. 2. (Suppress return of FISUs at B to maintain "aligned ready" state.) 3. Clear LPO at A. 4. Check A resumes "aligned ready" state.

TEST	TEST NUMBER: 1.16 PAGE: 1 OF 1				
REFERENCE: Q.703 Clauses 7, 8 STD: Fig. 8					
TITL	E: Link State Control – Ex	spected signal units/orders			
SUB	ΠΤLE: Timer T1 in "align	ed not ready" state			
PURI	POSE: To test the operation	n of Timer T1 when in the "aligned i	not ready" sta	te	
PRE-	TEST CONDITIONS: Lin	ak out of service			
CON	FIGURATION: 1		TYPE OF	TEST: VAT	
EXPI	ECTED SIGNAL UNIT SE	QUENCE:			
	SP B			SP A	
Link			Link		
		<	1 - 0	SIOS	
1 - 0	SIOS	>			
				: set LPO	
				: start	
		<	1 - 0	SIO	
1 - 0	SIO	>			
		<	1 - 0	SIN	
1 - 0	SIN	>			
		<	1 - 0	SIPO	
				T1	
		<	1 - 0	SIOS	
TEST DESCRIPTION					
1.	Set LPO and start link at A	٠.			
2.	Check A enters the "aligne	ed not ready" state.			
3.	Check A takes the link out				
4.	Timer T1 shall be in the ra	nge 40 secs to 50 secs.			

TEST NUMBER: 1.17	PAGE: 1 OF 1
REFERENCE: Q.703 Clause 7 STD: Fig. 9	
TITLE: Link State Control – Expected signal units/orders	
SUBTITLE: No SIO sent during normal proving period	
PURPOSE: To ensure that normal alignment still occurs when SIO	is omitted
PRE-TEST CONDITIONS: Link out of service	
CONFIGURATION: 1	TYPE OF TEST: VAT
EXPECTED SIGNAL UNIT SEQUENCE:	,
SP B Link 1-0 SIOS 1-0 SIN 1-0 SIN	$SP \qquad A$ Link $1-0 \qquad SIOS$ $: start$ $1-0 \qquad SIO \text{ not aligned}$ $1-0 \qquad SIN \qquad \boxed{T3}$ $\boxed{T4(Pn)}$ $1-0 \qquad FISU$
TEST DESCRIPTION 1. Check normal alignment occurs with no SIO sent from SP B.	

TEST NUMBER: 1.18	PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 7 STD: Fig. 8			
TITLE: Link State Control – Expected signal units/orders			
SUBTITLE: Set and cease emergency prior to "start alignment"			
PURPOSE: To test the normal proving period is employed having	"emergency" set and cleared		
PRE-TEST CONDITIONS: Link out of service			
CONFIGURATION: 1	TYPE OF TEST: VAT		
EXPECTED SIGNAL UNIT SEQUENCE:			
SP B Link 1-0 SIOS	SP A Link 1 - 0 SIOS : set EM : clear EM : start 1 - 0 SIO		
<> 1 - 0 SIN>	1-0 SIN		
TEST DESCRIPTION	- 		
Check emergency set and cleared prior to start of alignment. Check normal proving period is carried out.			

		,					
TEST	TEST NUMBER: 1.19 PAGE: 1 OF 1						
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9							
TITLE	E: Link State Contr	ol – Expected signal units/orders					
SUBT	ITLE: Set emerger	acy while in "not aligned state"					
PURP	OSE: To test that e	mergency proving can be set during nor	mal initial ali	gnment			
PRE-T	EST CONDITIONS	S: Link out of service	· ·				
CONF	IGURATION: 1		TYPE O	F TEST: VAT, CPT			
EXPE	CTED SIGNAL UN	IIT SEQUENCE:					
	SP B			SP A			
Link			Link				
		<	1 - 0	SIOS			
1 – 0	SIOS	>					
				: start			
		<	1 – 0	SIO			
		`	- 0	: set EM			
1 – 0	SIO	>		. Set Livi			
1 0	Sie	<	1 – 0	SIE			
		`	1 0				
1 - 0	SIN	>					
				T4(Pe)			
		<	1 - 0	FISU			
TEST	DESCRIPTION						
1.	Check that emergen	cy proving period is used after set EM d	luring normal	initial alignment.			

- 2. The timing of this test is critical, emergency must be set once the start command has been given and before SIO is received (i.e. during Timer T2 operation).
- 3. At 64 kbit/s Timer T4 shall be in the range 0.4 sec to 0.6 sec (nominally 0.5 sec).
- 4. At 4.8 kbit/s Timer T4 shall be in the range 6 secs to 8 secs (nominally 7 secs).

TEST NUMBER: 1.20 PAGE: 1 OF 1 REFERENCE: Q.703 Clause 7 STD: Fig. 9 TITLE: Link State Control – Expected signal units/orders SUBTITLE: Set emergency when "aligned" PURPOSE: To test that emergency proving period is used when emergency set prior to receiving SIN PRE-TEST CONDITIONS: Link out of service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**SIOS** 1 - 0SIOS : start <-----1 - 0SIO ----> 1 - 0SIO <-----SIN 1 - 0: set EM <-----1 - 0SIE 1 - 0SIN T4 (Pe) **FISU** 1 - 0<-----**TEST DESCRIPTION** 1. Check that emergency proving period is used after SIE sent during "aligned" state. The timing of this test is critical. Emergency must be set once SIN has been sent but before 2. Timer T3 expires.

TEST	Γ NUMBER:	1.21		PAGE: 1	OF 1	
REFI	ERENCE: Q	.703 Clause 7	STD: Fig. 8; Fig. 9			
TITL	E: Link Stat	te Control – Exp	pected signal units/orders			
SUB	ΓΙΤLE: Both	n ends set emerg	gency			
PUR	POSE: To cl	heck the emerge	ency alignment procedure and Time	r T4 (Pe)		
PRE-	TEST COND	OITIONS: Link	out of service			
CON	FIGURATIO	N: 1		TYPE OF	TEST:	VAT
EXP	ECTED SIGN	NAL UNIT SEQ	UENCE:			
	SP	В			SP	A
Link				Link		
			<	1 - 0	S	IOS
1-0	SIOS		>			
						t EM
						art
	210		<	1 – 0	S	Ю
1 - 0	SIO		>	4 0	~	-
1 0	QTE.		<	1 - 0	S	lE
1 - 0	SIE		>			T4 (Pe)
			<	1 – 0	171	
				1 0	r.	ISU
TEST DESCRIPTION						
1.	Check corre	ct emergency of	ignment procedure is performed.			
1.	CHECK COILE	er emergency ar	rginnent procedure is performed.			

TEST NUMBER: 1.22	PAGE: 1 OF 1			
REFERENCE: Q.703 Clause 7 STD: Fig. 9				
TITLE: Link State Control – Expected signal units/orders				
SUBTITLE: Individual end sets emergency				
PURPOSE: To check emergency alignment procedure, Emergency	set at the other end			
PRE-TEST CONDITIONS: Link out of service				
CONFIGURATION: 1	TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B Link	$SP \qquad A$ Link $1-0 \qquad SIOS$ $: start$ $1-0 \qquad SIO$ $1-0 \qquad SIN$			
<	T4 (Pe) 1 – 0 FISU			
TEST DESCRIPTION				
 Emergency alignment set at B. Start alignment at A. Check that alignment occurs with the emergency proving period 	d.			

TEST	NUMBER:	1.23		PAGE: 1	PAGE: 1 OF 1		
REFI	ERENCE: Ç	.703 Clau	se 7 STD: Fig. 9	1			
TITL	E: Link Sta	te Control	- Expected signal units/orders				
SUB	ΓΙΤLE: Set	emergency	y during normal proving				
PUR		est that sett gency pro	ting emergency during normal proving ving	g stops normal	proving and starts the		
PRE-	TEST CONI	DITIONS:	Link out of service				
CON	FIGURATIO	N: 1		TYPE O	FTEST: VAT		
EXP	ECTED SIGN	NAL UNIT	Γ SEQUENCE:				
	SP	В			SP A		
Link				Link			
	~~~~		<	1 - 0	SIOS		
1 - 0	SIOS		>				
				1 0	: start		
1-0	SIO		<>	1 - 0	SIO		
1-0	310		< <i>&gt;</i>	1 – 0	SIN		
1-0	SIN		>	1 – 0	SIN		
1-0	SIIV				: set EM		
			<	1 – 0	SIE		
1-0	SIN		· >	1 0			
					T4 (Pe)		
			<	1 – 0	FISU		
TEST DESCRIPTION							
1.	Set emerger	cy during	normal proving period at A.				
2.	Check A ser	nds SIE.					
3.	Repeat test	in reverse	direction.				

TEST NUMBER: 1.24		PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 7 STD: Fig. 9				
TITLE: Link State Control – Expected signal units/orders				
SUBTITLE: No SIO sent during emergency alignment				
PURPOSE: To ensure that emergency alignment still occurs when SIE is received following SIOS				
PRE-TEST CONDITIONS: Link out of service				
CONFIGURATION: 1		TYPE OF TEST: VAT		
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B Link		Sl	P A	
	<	1 – 0	SIOS	
1 – 0 SIOS	<>	: :	set EM start SIO	
1 – 0 SIE	<>	1 – 0	SIE T4 (Pe)	
	<	1 – 0	FISU	
TEST DESCRIPTION				
<ol> <li>Set emergency and start link at A.</li> <li>A receives SIE after sending SIO.</li> <li>Check that link aligns OK after emergency proving.</li> </ol>				

TEST NUMBER: 1.25	PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9			
TITLE: Link State Control – Expected signal units/orders			
SUBTITLE: Deactivation during initial alignment			
PURPOSE: To test the response to the receipt of the stop command while in the initial alignment state (initial alignment is Not Aligned State)			
PRE-TEST CONDITIONS: Link out of service			
CONFIGURATION: 1	TYPE OF TEST: VAT, CPT		
EXPECTED SIGNAL UNIT SEQUENCE:			
SP B Link  1-0 SIOS	SP A  Link 1-0 SIOS  : start 1-0 SIO : wait 5 secs. : stop 1-0 SIOS		
TEST DESCRIPTION			
<ol> <li>Check that alignment ceases after Stop command given.</li> <li>The stop command must be issued before timer T2 expires.</li> <li>Timer T2 shall be in the range 5 secs to 150 secs.</li> </ol>			

TEST	Γ NUMBER:	1.26		PAGE: 1	PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 9							
TITL	E: Link Sta	te Control – E	Expected signal units/orders				
SUB	ГІТLЕ: Dea	ctivation duri	ng aligned state				
PURI			se to the receipt of the stop comma ment is aligned state)	nd while in the	e initial alignment		
PRE-	TEST CONI	DITIONS: Li	ink out of service				
CON	FIGURATIC	N: 1		TYPE OF	FTEST: VAT		
EXPI	ECTED SIGN	NAL UNIT SI	EQUENCE:				
Link 1-0 1-0		B	<> <> <> <>	Link 1 – 0  1 – 0  1 – 0  1 – 0	SP A  SIOS  : start SIO  SIN : stop SIOS		
TEST	Γ DESCRIPT	ION					
1. 2. 3.	2. The stop command must be issued before timer T3 expires.						

TEST NUMBER: 1.27	PAGE: 1 OF 1				
REFERENCE: Q.703 Clauses 7, 8 STD: Fig. 8					
TITLE: Link State Control – Expected signal units/orders					
SUBTITLE: Deactivation during aligned not ready					
PURPOSE: To check the response following normal alignment when	n PO has been set				
PRE-TEST CONDITIONS: Link out of service					
CONFIGURATION: 1	TYPE OF TEST: VAT				
EXPECTED SIGNAL UNIT SEQUENCE:					
SP B  Link  1-0 SIOS   1-0 SIO   1-0 SIN	SP A  Link 1-0 SIOS  : set LPO : start  1-0 SIO  1-0 SIN  1-0 SIPO : stop 1-0 SIOS				
TEST DESCRIPTION  1. Soon after alignment completes, A enters "Aligned not ready". 2. Before alignment completes at B, stop command is given at A. 3. Check that A enters "Out of service" state. 4. Repeat test with LPO set at B.					

TEST	ΓNUI	MBER:	1.28		PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 7 STD: Fig. 8; Fig. 14							
TITLE: Link State Control – Expected signal units/orders							
SUB	ΓΙΤLΙ	E: SIO	received during	link in service			
PURI	POSE	: To ch	eck the deactiva	tion of a signalling link from the '	'In Service" s	state	
PRE-	TEST	COND	ITIONS: Link	in service			
CON	FIGU	RATIO	N: 1		TYPE OF	TEST: VAT	
EXPI	ЕСТЕ	D SIGN	AL UNIT SEQU	JENCE:			
Link		SP	В		Link	SP A	
1 - 0 $1 - 0$		FISU SIO		<> <>	1 – 0	FISU	
				<	1 – 0	SIOS	
TEST	TEST DESCRIPTION						
1. 2.			o A during link i n "in service" lin	n service. Ik can be taken out of service at A			

TEST NUMBER: 1.2	9	PAGE: 1 OF 1			
REFERENCE: Q.703	Clause 7 STD: Fig. 8; Fig. 14				
TITLE: Link State Co	ontrol – Expected signal units/orders				
SUBTITLE: Deactiva	ation during link in service				
PURPOSE: To check	the deactivation of a signalling link from the "	In Service" state			
PRE-TEST CONDITION	ONS: Link in service				
CONFIGURATION:	1	TYPE OF TEST: VAT, CPT			
EXPECTED SIGNAL	UNIT SEQUENCE:				
SP B		SP A			
Link		Link			
1-0 FISU	>	Link			
1-0 1150	ŕ	1 0 FIGUR			
	<	1-0 FISU			
: stop					
1-0 SIOS	>				
	<	1-0 SIOS			
TEST DESCRIPTION					
1. Check that an "I	n service" link can be taken out of service by co	ommand at B			
	mand given at A.	Similaria de B.			
2. Repeat test, com	mand given at A.				

TEST	NUMBER:	1.30		PAGE: 1 OF 1		
REFE	RENCE: Q.	703 Clauses 7, 8	STD: Fig. 10			
TITLE	E: Link State	e Control – Expe	ected signal units/orders			
SUBT	ITLE: Deac	tivation during l	LPO			
PURP	OSE: To ch	eck the response	e to the stop command during LPO	1		
PRE-T	TEST COND	ITIONS: Link	in service			
CONF	FIGURATION	N: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGN	AL UNIT SEQU	JENCE:			
Link	SP	В		Link	SP A	
1 – 0	FISU		<>	1 – 0	FISU	
1-0	FISU		<>	1 – 0	: set LPO SIPO	
			<	1 – 0	: stop SIOS	
TEST	DESCRIPTI	ON				
	SIPO sent from A, stop command given at A, check link enters out of service state.					

TEST NUMBER: 1.31	PAGE: 1 OF 1				
REFERENCE: Q.703 Clauses 7, 8 STD: Fig. 10					
TITLE: Link State Control – Expected signal units/orders					
SUBTITLE: Deactivation during RPO					
PURPOSE: To test the response to the stop command during RPO					
PRE-TEST CONDITIONS: Link in service					
CONFIGURATION: 1	TYPE OF TEST: VAT				
EXPECTED SIGNAL UNIT SEQUENCE:					
SP B Link	SP A Link				
1 – 0 FISU>	1 – 0 FISU				
1 – 0 SIPO>					
<	: stop 1 – 0 SIOS				
TEST DESCRIPTION					
1. SIPO received at A, stop command given at A, check link enter	ers out of service state.				
2. Repeat test, SIPO received at B, stop command given at B, cho	eck link enters out of service state.				

TEST NUMBER: 1.32 PAGE: 1 OF 1 REFERENCE: Q.703 Clause 7, subclause 10.3 STD: Fig. 8; Fig. 9 TITLE: Link State Control – Expected signal units/orders SUBTITLE: Deactivation during the proving period PURPOSE: To test the response to the receipt of SIOS during the proving period PRE-TEST CONDITIONS: Link out of service CONFIGURATION: 1 TYPE OF TEST: VAT, CPT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP A Link Link **SIOS** 1 - 01 - 0SIOS ----> : start 1 - 0SIO <-----SIO 1 - 01 - 0SIN 1 - 0SIN ----> : stop 1 - 0**SIOS SIOS** 1 - 0**TEST DESCRIPTION** 1. Check link enters out of service state when SIOS is received at A during the proving period. 2. Repeat test, SIOS received at B during proving period.

WIII, DEVEL 2						
TEST N	NUMBER: 1.33		PAGE: 1	1 OF 1		
REFER	REFERENCE: Q.703 Clause 7 STD: Fig. 8					
TITLE	: Link State Control	- Expected signal units/orders				
SUBTI	TLE: SIO received i	nstead of FISUs				
PURPO	OSE: To check the re	esponse to the receipt of SIO instead of	of FISUs in the	aligned ready state		
PRE-T	EST CONDITIONS:	Link out of service				
CONFI	GURATION: 1		TYPE O	F TEST: VAT		
EXPEC	CTED SIGNAL UNIT	SEQUENCE:	•			
Link	SP B		Link	SP A		
1 – 0	SIOS	<>	1 – 0	SIOS		
				: start		
1 – 0	SIO	<>	1 - 0	SIO		
1-0	310	<>	1 - 0	SIN		
1-0	SIN	> <	1 – 0	FISU		
1 – 0	SIO	> <	1 – 0	SIOS		
TEST I	DESCRIPTION					
	1. Check link enters out of service state when SIO is received at A instead of FISUs in the aligned ready state.					

TEST	NUMBER: 1.34		PAGE: 1	PAGE: 1 OF 1		
REFI	ERENCE: Q.703 Clause	7 STD: Fig. 8				
TITL	E: Link State Control – F	Expected signal units/orders				
SUB	ΓΙΤLE: SIOS received in	stead of FISUs				
PURI	POSE: To check the response	onse to the receipt of SIOS instead of	FISUs in th	ne aligned ready state		
PRE-	TEST CONDITIONS: L	ink out of service				
CON	FIGURATION: 1		TYPE OF	FTEST: VAT		
EXPI	ECTED SIGNAL UNIT S	EQUENCE:				
	SP B			SP A		
Link	21 2		Link			
		<	1 - 0	SIOS		
1 - 0	SIOS	>				
				: start		
		<	1 - 0	SIO		
1 - 0	SIO	>				
		<	1 - 0	SIN		
1 - 0	SIN	>				
		<	1 - 0	FISU		
	: stop					
1 - 0	SIOS	>				
		<	1 - 0	SIOS		
TEST	TEST DESCRIPTION					
1.	Check link enters out of stready state.	service state when SIOS is received a	t A instead of	of FISUs in the aligned		

TEST NUMBER: 1.35			PAGE: 1 O	PAGE: 1 OF 1		
REFI	ERENCE: Q.703 Clauses	7, 8 STD: Fig. 8				
TITL	E: Link State Control – E	xpected signal units/orders				
SUB	ΠΤΙΕ: SIPO received ins	tead of FISUs				
PURI	POSE: To check the respo	onse to the receipt of SIPO instead or	FISUs in the a	lligned ready state		
PRE-	TEST CONDITIONS: Li	nk out of service				
CON	FIGURATION: 1		TYPE OF T	EST: VAT		
EXPI	ECTED SIGNAL UNIT SE	QUENCE:				
	SP B			SP A		
Link			Link			
		<	1 - 0	SIOS		
1 – 0	SIOS	>		· atout		
				: start		
1 0	GIO.	<	1 - 0	SIO		
1 – 0	SIO	>	1 0	CD.		
4 0	G77.Y	<	1 - 0	SIN		
1 - 0	SIN	>				
		<	1 - 0	FISU		
	: set LPO					
1 - 0	SIPO	>				
		<	1 - 0	FISU		
TEST DESCRIPTION						
1.	Check link enters process	or outage state when SIPO is receive	ed at A instead	of FISUs in the		
1.	aligned ready state.	or sample same when our o is receive	at 11 moteur	or in the		

TEST	NUMBER: 2.1		PAGE: 1	PAGE: 1 OF 1		
REFE	ERENCE: Q.703 Clause	es 7, 11 STD: Fig. 8	<u>.</u>			
TITL	E: Link State Control –	Unexpected signal units/orders				
SUB	ΓΙΤLE: Unexpected sig	nal units/orders in "Out of service	" state			
PURI	POSE: To check that th	e unexpected signal units/orders a	re ignored			
PRE-	TEST CONDITIONS:	Link out of service				
CON	FIGURATION: 1		TYPE OF	TEST: VAT		
EXPI	ECTED SIGNAL UNIT	SEQUENCE:				
Link	SP B		Link	SP A		
1 – 0	SIOS xxx	<> >	1 – 0	SIOS		
				yyy : start		
1 – 0	SIO	<>	1 – 0	SIO		
1-0	SIN	<>	1 - 0	SIN		
1 – 0	FISU	<>	1 – 0	FISU		
TEST	DESCRIPTION					
<ol> <li>1.</li> <li>2.</li> </ol>	1. Check that the unexpected signal units xxx received from B are ignored without impact on the system. xxx are successively SIO, SIN, SIE, SIPO, SIB, aberrant LSSU (non-existing status, one and two octets), FISU and MSU.					

TEST	NUMBER: 2.2		PAGE: 1 OF 1			
REFI	ERENCE: Q.703 Cla	uses 7, 11 STD: Fig. 9				
TITL	E: Link State Contro	ol – Unexpected signal units/orders				
SUB	ΓΙΤLE: Unexpected	signal units/orders in "Not aligned" state				
PURI	POSE: To check that	the unexpected signal units/orders are ign	ored			
PRE-	TEST CONDITIONS	: Link out of service				
CON	FIGURATION: 1		TYPE OF TEST: VAT			
EXPI	ECTED SIGNAL UN	IT SEQUENCE:				
Link	SP B		SP A Link			
1 – 0	SIOS	<>	1 – 0 SIOS			
1 0	5100	<	: start 1 – 0 SIO			
	XXX	>	ууу			
1-0	SIO	> <	1 – 0 SIN			
1-0	SIN	> <	1 – 0 FISU			
1 – 0	FISU	>				
TEST DESCRIPTION						
1.	system. xxx are successively SIOS, SIPO, SIB, aberrant LSSU, FISU and MSU.					
2.		pected orders yyy received from level 3 a essively clear EM and start (if applicable).	-			

TEST	NUMBER: 2.3				PAGE: 1 OF 1		
REFI	ERENCE: Q.703	Clauses 7, 11	STD: Fig. 9				
TITL	E: Link State Co	ontrol – Unexp	ected signal units/c	rders			
SUB	ΓΙΤLE: Unexpec	eted signal unit	ts/orders in "Aligne	d" state			
PURI	POSE: To check	that the unexp	pected signal units/o	orders are ign	ored		
PRE-	TEST CONDITIO	ONS: Link ou	at of service				
CON	FIGURATION:	1			TYPE OF	TEST: VAT	
EXPI	ECTED SIGNAL	UNIT SEQUE	ENCE:				
Link	SP B				Link	SP A	
1 – 0	SIOS	<	<		1 – 0	SIOS	
1-0	5105			-/		: start	
1-0	SIO		<		1 – 0	SIO	
		<	<		1 – 0	SIN	
	XXX	-		>		ууу	
1 – 0	SIN				1 0	EIGH	
1-0	FISU		< 		1 – 0	FISU	
TEST	DESCRIPTION						
1.			nal units xxx recei IO, SIPO, SIB, abe		•	without impact on the ISU.	
2.	Check that the u	inexpected ord		rom level 3 a	re ignored	without impact on the	

PAGE: 1 OF 1 TEST NUMBER: 2.4 REFERENCE: Q.703 Clauses 7, 11 STD: Fig. 9 TITLE: Link State Control – Unexpected signal units/orders SUBTITLE: Unexpected signal units/orders in "Proving" state PURPOSE: To check that the unexpected signal units/orders are ignored PRE-TEST CONDITIONS: Link out of service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**SIOS** 1 - 0SIOS ----> : start <-----1 - 0SIO ----> 1 - 0**SIO** <-----1 - 0SIN 1 - 0----> SIN XXXууу 1 - 0**FISU** <-----1 - 0**FISU** 

#### **TEST DESCRIPTION**

- 1. Check that the unexpected signal units xxx received from B are ignored without impact on the system. xxx are successively SIPO, SIB, aberrant LSSU, FISU and MSU.
- 2. Check that the unexpected orders yyy received from level 3 are ignored without impact on the system. yyy are successively clear EM and start (if applicable).

NOTE – The reception of SIB in "Initial alignment" state may possibly cause link failure after transferring to "In service" state because of the T6 expiration.

PAGE: 1 OF 1 TEST NUMBER: 2.5 REFERENCE: Q.703 Clauses 7, 11 STD: Fig. 8 TITLE: Link State Control – Unexpected signal units/orders SUBTITLE: Unexpected signal units/orders in "Aligned ready" state PURPOSE: To check that the unexpected signal units/orders are ignored PRE-TEST CONDITIONS: Link out of service TYPE OF TEST: VAT CONFIGURATION: 1 EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**SIOS** 1 - 0SIOS ----> : start <-----1 - 0SIO ----> 1 - 0SIO <-----1 - 0SIN 1 - 0SIN ----> <-----1 - 0**FISU** ----> XXX ууу 1 - 0**FISU** 

### TEST DESCRIPTION

- 1. Check that the unexpected signal units xxx received from B are ignored without impact on the system. xxx are successively SIB and aberrant LSSU.
- 2. Check that the unexpected orders yyy received from level 3 are ignored without impact on the system. yyy are successively set EM, clear EM, clear LPO and start (if applicable).

NOTE – The reception of SIB in "Aligned ready" state may possibly cause link failure after transferring to "In service" state because of the T6 expiration.

		<u> </u>		
TEST 1	NUMBER: 2.6		PAGE:	1 OF 1
REFER	RENCE: Q.703 CI	auses 7, 11 STD: Fig. 8	·	
TITLE	: Link State Contr	rol – Unexpected signal units/orders		
SUBTI	TLE: Unexpected	l signal units/orders in "Aligned not rea	ıdy" state	
PURPO	OSE: To check that	at the unexpected signal units/orders are	e ignored	
PRE-T	EST CONDITION	S: Link out of service		
CONFI	GURATION: 1		TYPE O	F TEST: VAT
EVDE		ALL CLOVIEN OF		
EXPEC	CTED SIGNAL UN	NIT SEQUENCE:		
	SP B			SP A
Link			Link	
		<	1 – 0	SIOS
1 - 0	SIOS	>		
				: set LPO
		<	1 – 0	: start SIO
1 – 0	SIO	>	1-0	510
1-0	510	<	1 – 0	SIN
1 – 0	SIN	· >	1 0	
		<	1 – 0	SIPO
	xxx	>		
				ууу
1 - 0	FISU	>		
		<	1 - 0	SIPO
TEST DESCRIPTION				
1. (	Theck that the une	xnected signal units xxx received from	n B are ignored	without impact on the
1. Check that the unexpected signal units xxx received from B are ignored without impact on the system. xxx are successively SIB and aberrant LSSU.				
2. Check that the unexpected orders yyy received from level 3 are ignored without impact on the				
system. yyy are successively set EM, clear EM, clear LPO and start (if applicable).				

TEST NUMBER: 2.7	PAGE: 1 OF 1				
REFERENCE: Q.703 Clauses 7, 11 STD: Fig. 8	REFERENCE: Q.703 Clauses 7, 11 STD: Fig. 8				
TITLE: Link State Control – Unexpected signal units/orders					
SUBTITLE: Unexpected signal units/orders in "In service" state					
PURPOSE: To check that the unexpected signal units/orders are ign	ored				
PRE-TEST CONDITIONS: Link out of service					
CONFIGURATION: 1	TYPE OF TEST: VAT				
EXPECTED SIGNAL UNIT SEQUENCE:					
SP B Link	SP A Link				
<> 1 – 0 FISU> aberrant LSSU	1 – 0 FISU  yyy  THEN				
1 – 0 FISU>	1 – 0 FISU				
TEST DESCRIPTION					
<ol> <li>Check that an aberrant LSSU received from B is ignored without Check that the unexpected orders yyy received from level 3 a system. yyy are successively set EM, clear EM, clear LPO and</li> </ol>	are ignored without impact on the				

TEST NUMBER: 2.8	PAGE: 1 OF 1		
REFERENCE: Q.703 Clauses 7, 11 STD: Fig. 8			
TITLE: Link State Control – Unexpected signal units/orders			
SUBTITLE: Unexpected signal units/orders in "Processor outage" s	tate		
PURPOSE: To check that the unexpected signal units/orders are ign	ored		
PRE-TEST CONDITIONS: Link in service			
CONFIGURATION: 1	TYPE OF TEST: VAT		
EXPECTED SIGNAL UNIT SEQUENCE:			
SP B Link	SP A Link : set LPO 1 – 0 SIPO  yyy		
TEST DESCRIPTION			
<ol> <li>Check that the unexpected signal units xxx received from B a system. xxx are successively SIB and aberrant LSSU.</li> <li>Check that the unexpected orders yyy received from level 3 a system. yyy are successively set EM, clear EM and start (if approximately system).</li> </ol>	are ignored without impact on the		

	·			
TEST NUMBER: 3.1	PAGE: 1 OF 1	l		
REFERENCE: Q.703 Clause	e 4, subclause 10.2 STD: Fig. 8			
TITLE: Transmission failure				
SUBTITLE: Link aligned rea	ady (Break Tx path)			
PURPOSE: To test the response ready" state	nse to a transmission failure – detected	by SUERM – wl	nen in "Aligned	
PRE-TEST CONDITIONS:	Link out of service			
CONFIGURATION: 1		TYPE OF TES	T: VAT	
EXPECTED SIGNAL UNIT	SEQUENCE:			
SP B Link  1-0 SIOS  1-0 SIO  1-0 SIN  : break Tx	<> <> <> <> <> <> <>	SP Link 1-0 : 1-0 1-0 1-0	SIOS start SIO SIN FISU SIOS	
TEST DESCRIPTION				
the link is taken out of service.  Repeat test, break Tx at A.				

TEST	NUMBER: 3.2		PAGE: 1	OF 1	
REFE	REFERENCE: Q.703 Subclause 5.3 STD: Fig. 8				
TITLE	E: Transmission failure				
SUBT	TITLE: Link aligned ready (C	orrupt FIBs – Basic)			
PURP	PURPOSE: To check the response to a link failure after corruption of two FIBs – detected by reception control – while in Aligned ready State				
PRE-7	TEST CONDITIONS: Aligne	ed ready			
CONF	FIGURATION: 1		TYPE OF	TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQU	ENCE:			
Link 1-0 1-0	FISU corrupt FIB (FIB + FSN = 7F) FISU corrupt FIB (FIB + FSN = 7F)	<>> <	Link 1 – 0 1 – 0	SP A FISU SIOS	
TEST DESCRIPTION					
		SUs at A with corrupt FIB's at li	ink aligned	ready state causes the	
	link to be taken out of service.		angilou .	ready state eauties the	

TEST NUMBER: 3.3 PAGE: 1 OF 1 REFERENCE: Q.703 Clause 8, subclause 10.3 STD: Fig. 8 TITLE: Transmission failure SUBTITLE: Link aligned not ready (Break Tx path) PURPOSE: To test the response to a break in the transmission path – detected by SUERM – in "Aligned not ready" state PRE-TEST CONDITIONS: Link out of service TYPE OF TEST: VAT CONFIGURATION: 1 EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**SIOS** 1 - 0**SIOS** ----> set LPO start 1 - 0SIO ----> 1 - 0**SIO** 1 - 0SIN 1 - 0SIN 1 - 0**SIPO** : break Tx <-----1 - 0**SIOS TEST DESCRIPTION** Set LPO at A. 1. 2. Start link alignment at A. 3. In link aligned not ready state break Tx at B and check link is taken out of service. 4. Repeat test for B with break in Tx at A, check link is taken out of service.

5.

The Tx path must be broken before Timer T1 expires.

TEST NUMBER: 3.4			PAGE: 1 C	OF 1	
REFERE	NCE: Q.703 Subclause 5.3, c.	lause 8 STD: Fig. 8			
TITLE:	Transmission failure				
SUBTITI	E: Link aligned not ready (C	orrupt FIBs – Basic)			
PURPOS	PURPOSE: To check the response to a link failure after corruption of two FIBs – detected by reception control – while in "Aligned not ready"				
PRE-TES	T CONDITIONS: Link out o	f service			
CONFIG	URATION: 1		TYPE OF T	TEST: VAT	
EXPECT	ED SIGNAL UNIT SEQUEN	CE:			
Link	SP B		Link	SP A	
1 – 0	SIOS	<>	1 – 0	SIOS	
		<	1-0	: set LPO : start SIO	
1 – 0	SIO	> <	1 – 0	SIN	
1 - 0 $1 - 0$	SIN	<> <>	1 – 0	SIPO	
1-0	FISU corrupt FIB (FIB + FSN = 7F) FISU corrupt FIB (FIB + FSN = 7F)	>			
		<	1 – 0	SIOS	
TEST DESCRIPTION					
<ol> <li>Sta</li> <li>Ser</li> </ol>	LPO at A.  rt link alignment at A.  ad two corrupt FISUs (corrupt)  eck link is taken out of service	•	ły.		

TEST NUMBER: 3.5	PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 4, subclause 10.2 STD: Fig. 8			
TITLE: Transmission failure			
SUBTITLE: Link in service (Break Tx path)			
PURPOSE: To test the response to a transmission failure when the l	ink is "In service"		
PRE-TEST CONDITIONS: Link in service			
CONFIGURATION: 1	TYPE OF TEST: VAT, CPT		
EXPECTED SIGNAL UNIT SEQUENCE:			
SP B Link	SP A Link 1-0 FISU  SIOS		
TEST DESCRIPTION			
<ol> <li>Break Tx at B, check SIOS returned from A.</li> <li>Repeat test, break at A.</li> </ol>			

TEST NUMBER: 3.6	PAGE: 1 OF 1			
REFERENCE: Q.703 Subclause 5.3 STD: Fig. 8				
TITLE: Transmission failure				
SUBTITLE: Link in service (Corrupt FIBs – Basic)				
PURPOSE: To check the response to a link failure after corruption of two FIBS – detected by reception control – while "In service"				
PRE-TEST CONDITIONS: Link in service				
CONFIGURATION: 1	TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B  Link  1 - 0 FISU	SP A Link 1-0 FISU  1-0 SIOS			
TEST DESCRIPTION				
Check that receipt of two FISUs at A with corrupt FIBs at lin be taken out of service.	k in service state causes the link to			

TEST NUMBER: 3.7	PAGE: 1 OF 1			
REFERENCE: Q.703 Clause 8, subclause 10.2 STD: Fig. 8				
TITLE: Transmission failure				
SUBTITLE: Link in processor outage (Break Tx path)				
PURPOSE: To test the response to a transmission failure when the li	nk is "Processor outage"			
PRE-TEST CONDITIONS: Link in service				
CONFIGURATION: 1	TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B Link  < 1-0 FISU>	SP A Link 1-0 FISU			
<:: break Tx	: set LPO 1 – 0 SIPO			
<	1 – 0 SIOS			
TEST DESCRIPTION				
<ol> <li>Break Tx path at B when in "Processor outage" state, check th and the link is taken out of service.</li> <li>Repeat test, break Tx at A.</li> </ol>	at the SUERM detects the failure			

TEST NUMB	BER: 3.8		PAGE: 1 OF 1	
REFERENCE	E: Q.703 Subclause 5.3, cla	ause 8 STD: Fig. 8		
TITLE: Tran	nsmission failure			
SUBTITLE:	Link in processor outage (	Corrupt FIBs – Basic)		
	To check the response to a reception control – while in	link failure after corruption of "Processor outage"	of two FIBs – detected by	
PRE-TEST C	ONDITIONS: Link in ser	vice		
CONFIGURA	ATION: 1		TYPE OF TEST: VAT	
EXPECTED S	SIGNAL UNIT SEQUENC	Œ:		
Link $1-0 \qquad \text{FI}$	SU	<>	SP A Link 1-0 FISU	
(F. 1 – 0 FI	SU corrupt FIB TB + FSN = 7F) SU corrupt FIB TB + FSN = 7F)	<> <	: set LPO  1 – 0 SIPO  1 – 0 SIOS	
		A with corrupt FIBs on prod	ocessor outage state causes the link	

TEST NUMBER: 4.1 PAGE: 1 OF 1 REFERENCE: Q.703 Clause 8 STD: Fig. 10 TITLE: Processor outage control SUBTITLE: Set and clear LPO while link in service PURPOSE: To check the ability to perform correctly when LPO is set and recovered PRE-TEST CONDITIONS: Link in service TYPE OF TEST: VAT CONFIGURATION: 1 EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0<-----**FISU** (FSN = 7F, BSN = 7F)1 - 0**FISU** ----> (FSN = 7F, BSN = 7F)accepted 1 - 0MSU (1) <-----(FSN = 0, BSN = 7F)<-----1 - 0MSU (2) (FSN = 1, BSN = 7F): set LPO 1 - 0**MSU** (FSN = 0, BSN = 0)1 - 0**SIPO** (FSN = 1, BSN = 7F)1 - 0**FISU** ----> (FSN = 0, BSN = 0): clear LPO 1 - 0MSU (3) (FSN = 1, BSN = x)**TEST DESCRIPTION** Set LPO at A while link in service. 1.

- 2. Check that MSU from B is discarded.
- 3. Clear LPO at A after at least 1.2 s.
- 4. Check that "old" messages are flushed from level 2 buffers and not transmitted on the link. Check that new MSUs are sent correctly.

TEST NUMBER: 4.2	PAGE: 1 OF 1			
REFERENCE: Q.703 Clause 8 STD: Fig. 10				
TITLE: Processor outage control				
SUBTITLE: RPO during LPO				
PURPOSE: To test the response to RPO is	set and cleared when "LPO"			
PRE-TEST CONDITIONS: Link in service	. LPO set at B			
CONFIGURATION: 1	TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B Link	SP A Link : set LPO			
•	1 – 0 SIPO			
: clear LPO	> 1 – 0 SIPO			
	1 – 0 SIPO			
TEST DESCRIPTION				
<ol> <li>Set LPO at A.</li> <li>Clear LPO at B.</li> <li>Check is SIPO sent from A.</li> </ol>				

TEST NUMBER: 4.3		PAGE: 1 OF 1		
REFERENCE: Q.703	Clause 8 STD: Fig. 10			
TITLE: Processor out	age control			
SUBTITLE: Clear LP	O when "Both processor outage"			
PURPOSE: To test th	e response to LPO, RPO recovered when "Both	processor outage"		
PRE-TEST CONDITIO	ONS: LPO set at A and B			
CONFIGURATION:	1	TYPE OF TEST: VAT		
EXPECTED SIGNAL	UNIT SEQUENCE:			
SP B Link		SP A Link 1 – 0 SIPO		
1 – 0 SIPO : clear LPO 1 – 0 FISU	O>	: clear LPO 1 – 0 FISU 1 – 0 FISU		
TEST DESCRIPTION				
<ol> <li>Clear LPO at A.</li> <li>Clear LPO at B.</li> <li>Check is FISU see</li> </ol>	ent from A.			

TEST NUMBER: 5.1			PAGE: 1 OF 1	
REFERENCE: Q.703 Subclause 4.1 STD: Fig. 11				
TITL	E: SU delimitation, alignm	ent, error detection and correction		
SUB	ΠΤΙΕ: More than seven '1	's between MSU opening and closing	ng flags	
PURPOSE: To test the signal unit delimitation, alignment, and error detection action on receipt of an MSU containing seven or more consecutive '1's				
PRE-	TEST CONDITIONS: Lin	k in service		
CONFIGURATION: 1			TYPE OF TEST: VAT	
EXPI	ECTED SIGNAL UNIT SEC	QUENCE:		
	SP B			SP A
Link			Link	
		<	1 - 0	FISU
1 - 0	FISU	>		
1 – 0	corrupt MSU (FIB + FSN = 80) (containing seven consecutive '1's)	>		
		<	1 – 0	FISU (BSN unchanged)
1 – 0	FISU	>		
TEST DESCRIPTION				
1.	Send a corrupt MSU at B containing seven consecutive '1's.			
2.	Check that A discards the signal unit, and goes into octet counting mode.			
3.	On reception of a correct FISU, check that A leaves the octet counting mode and remains in the "in service" state.			

TEST	NUMBER: 5.2	PAGE: 1 OF 1	
REFERENCE: Q.703 Subclause 4.1 STD: Fig. 11			
TITL	E: SU delimitation, alignment, error detection and correction		
SUB	ΠΤΙΕ: Greater than maximum signal unit length		
PURPOSE: To test the signal unit delimitation, alignment, error detection action on receipt of signal unit greater than the maximum length			
PRE-	TEST CONDITIONS: Link in service		
CON	FIGURATION: 1	TYPE OF TEST: VAT	
EXPI	ECTED SIGNAL UNIT SEQUENCE:		
	SP B	S	SP A
Link		Link	
	<	1 - 0	FISU
1 – 0	FISU>		
1 – 0	corrupt MSU> (FIB + FSN = 80) (signal unit length > max. Allowed)		
	<	1 – 0	FISU (BSN unchanged)
1-0	FISU>		
TEST DESCRIPTION			
1.	Send corrupt MSU at B with maximum length plus extra bits and good sumcheck.		
2.	Check A discards the signal unit, and goes into octet counting mode.		
3.	On reception of a correct FISU, check that A leaves the octet c "in service" state.		and remains in the

TEST NUMBER: 5.3			PAGE: 1	PAGE: 1 OF 1	
REFERENCE: Q.703 Subclause 4.1 STD: Fig. 11					
TITLE: SU delimitation, alignment, error detection and correction					
SUB	ΓΙΤLE: Below minimur	n signal unit length			
PURPOSE: To test the signal unit delimitation, alignment and error detection action on receipt of signal unit less than the minimum length					
PRE-	TEST CONDITIONS:	Link in service			
CONFIGURATION: 1			TYPE O	TYPE OF TEST: VAT	
EXPI	ECTED SIGNAL UNIT	SEQUENCE:			
Link	SP B		Link	SP A	
		<	1 – 0	FISU $(BIB + BSN = FF)$	
1 - 0	FISU	>			
1 – 0	corrupt MSU (FIB + FSN = 80) (signal unit less than 6 octets)	>			
		<	1 – 0	FISU (BSN unchanged)	
1 – 0	FISU	>			
TEST DESCRIPTION					
1.	Generate a corrupt MSU at B of less than 6 octet (i.e. less than 5 octets between flags).				
2.	Check A discards the signal unit and may go into octet counting mode.				
3.	On reception of a correct remains in the "in service"	et FISU, check that A leaves the octe ce" state.	t counting mo	de if it was entered and	

TEST NUMBER: 5.4	PAGE: 1 OF 1		
REFERENCE: Q.703 Clause 2 STD: Fig. 11			
TITLE: SU delimitation, alignment, error detection	and correction		
SUBTITLE: Reception of single and multiple flags	petween FISUs		
PURPOSE: To check that single and multiple flags b	etween FISUs can be received		
PRE-TEST CONDITIONS: Link in service			
CONFIGURATION: 1	TYPE OF TEST: VAT		
EXPECTED SIGNAL UNIT SEQUENCE:			
$SP \qquad B$ $Link$ $1-0 \qquad FISU$ $case 1 \qquad \qquad FISU F FISU$ $case 2 \qquad \qquad FISU F F$ $FISU$ $n(\geq 2)$ $1-0 \qquad FISU$	F: Flag  n = number of flags		
TEST DESCRIPTION			
1. Check that single and n flags, case 1 and case 2	respectively, can be received.		

TEST NUMBER: 5.5			PAGE: 1 OF 1
REFERENCE: Q.703 Clause 2 STD: Fig. 11			
TITLE: SU	U delimitation, alignment,	error detection and correction	
SUBTITLE: Reception of single and multiple flags between MSUs			
PURPOSE:	: To check that single and	multiple flags between MSUs of	can be received
PRE-TEST	CONDITIONS: Link in	service	
CONFIGUI	RATION: 1		TYPE OF TEST: VAT
EXPECTEI	D SIGNAL UNIT SEQUE	NCE:	
Link 1 – 0	SP B  FISU case 1 case 2  FISU	MSU F MSU  MSU F F  MSU  n(≥ 2)	SP A Link  F: Flag  n = number of flags
TEST DESCRIPTION			
1. Chec	ek that single and n flags, ca	ase 1 and case 2 respectively, ca	nn be received.

TEST NUMBER: 6.1

PAGE: 1 OF 1

REFERENCE: Q.703 Subclause 10.2

STD: Fig. 11; Fig. 18; Fig. 8

TITLE: SUERM check

SUBTITLE: Error rate of 1 in 256 – Link remains in service

PURPOSE: To check the SUERM at a link error rate of 1 in 256 units

PRE-TEST CONDITIONS: Link in service

CONFIGURATION: 1

TYPE OF TEST: VAT

EXPECTED SIGNAL UNIT SEQUENCE:

SP В SP A

Link

Link

1 - 0

**FISU** 

1 - 0**FISU** 

Ct

: corrupt 1 in 256

#### **TEST DESCRIPTION**

- 1. Check that "In service" state is maintained. The test should run for several minutes.
- 2. Ct = the count of corrupted FISUs.

NOTE – 1) The number (x) of corrupt signal units before an SIOS returned is calculated according to the following formula (a = number of correct signal units):

$$x = \frac{1}{1 + a} \left( \frac{256 \times 64}{\frac{256}{1 + a} - 1} \right)$$
 for  $a < 256$ 

2) In this case as a = 255, so x = infinity.

TEST NUMBER: 6.2	PAGE: 1 OF 1				
REFERENCE: Q.703 Subclause 10.2 STD: Fig. 11; Fig. 18; Fig. 8					
TITLE: SUERM check					
SUBTITLE: Error rate of 1 in 254 – Link into out of service					
PURPOSE: To check the SUERM at a link error rate of 1 in 254 uni	its				
PRE-TEST CONDITIONS: Link in service					
CONFIGURATION: 1	TYPE OF TEST: VAT				
EXPECTED SIGNAL UNIT SEQUENCE:					
SP B  Link  1 - 0 FISU	SP A Link 1-0 FISU  1-0 SIOS				
TEST DESCRIPTION					
<ol> <li>SIOS should be returned after approx. 8192 corrupt FISUs (e.g</li> <li>Ct = the count of corrupted FISUs.</li> </ol>	. CRC error).				

TEST NUMBER: 6.3	PAGE: 1 OF 1			
REFERENCE: Q.703 Subclause 10.2 STD: Fig. 11; Fig. 18; Fig. 8				
TITLE: SUERM check				
SUBTITLE: Consecutive corrupted Sus				
PURPOSE: To test the SUERM on consecutive corrupted signal uni	ts			
PRE-TEST CONDITIONS: Link in service				
CONFIGURATION: 1	TYPE OF TEST: VAT			
EXPECTED SIGNAL UNIT SEQUENCE:				
SP B  Link  1 - 0 FISU	SP A Link 1 – 0 FISU  1 – 0 SIOS			
TEST DESCRIPTION				
<ol> <li>SIOS should be returned after approx. 64 corrupt FISUs (e.g. C</li> <li>Ct = the count of corrupted FISUs.</li> </ol>	RC error).			

TEST NU	MBER: 6.4			PAGE: 1 OF 1		
REFERENCE: Q.703 Subclause 10.2 STD: Fig. 11; Fig. 18						
TITLE: SUERM check						
SUBTITL	E: Time controlled brea	k of the link				
PURPOSE	E: To check response to	a range of time c	ontrolled breaks o	of Tx or Rx		
PRE-TES	Γ CONDITIONS: Link	in service				
CONFIGU	JRATION: 1			TYPE OF	TEST: V	AT
EXPECTE	ED SIGNAL UNIT SEQU	JENCE:				
Link $1-0$	FISU: break Tx: restore Tx FISU	<<	·>	Link 1 – 0	SP FISU	A
TEST DESCRIPTION						
	ak the transmission link, approx. 128 ms for 64 k		ore level 2 goes o	out of service	ce. (Break ti	me is less
	ck that A enters and leav		ting mode on rece	eption of an	FISU.	

TEST NUMBER: 7.1 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 10.3 STD: Fig. 9; Fig. 11; Fig. 17 TITLE: AERM check SUBTITLE: Error rate below the normal threshold PURPOSE: To test the AERM on error rates below the normal threshold PRE-TEST CONDITIONS: Link out of service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**SIOS** 1 - 0SIOS : start <-----1 - 0SIO SIO ----> 1 - 0SIN 1 - 01 - 0SIN ----> T4 1 - 0corrupt **LSSUs** 1 - 0SIN 1 - 0**FISU** <-----**TEST DESCRIPTION** 1. Start link at A. Generate x number of corrupt LSSUs (e.g. CRC error) at B (x < Tin). Check that the proving period continues and the link aligns successfully. 3.

TEST	NUMBER: 7.2		PAGE: 1 OF 1			
REFI	REFERENCE: Q.703 Subclause 10.3 STD: Fig. 9; Fig. 11; Fig. 17					
TITL	TITLE: AERM check					
SUB	SUBTITLE: Error rate at the normal threshold					
PURI	POSE: To test the AERM	at an error rate equal to the normal	threshold			
PRE-	TEST CONDITIONS: Lii	nk out of service				
CON	FIGURATION: 1		TYPE O	FTEST: VAT		
EXPI	ECTED SIGNAL UNIT SE	QUENCE:				
Link  1 - 0  1 - 0  1 - 0	SP B  SIOS  SIO  SIN  corrupt LSSUs SIN	<> <> <> <> <> <> <>	Link 1 - 0  1 - 0  1 - 0	SP A  SIOS  : start SIO  SIN  T4  FISU		
TEST DESCRIPTION						
1. 2. 3.	<ol> <li>Start link at A.</li> <li>Generate x number of corrupt LSSUs (e.g. CRC error) at B (x ≥ Tin).</li> </ol>					

TEST N	UMBER: 7.3		PAGE: 1 OF 1		
REFERENCE: Q.703 Subclause 10.3 STD: Fig. 9; Fig. 11; Fig. 17					
TITLE:	AERM check				
SUBTIT	LE: Error rate above the	ne normal threshold			
PURPO	SE: To test the AERM	at an error rate above the threshol	ld over five pr	oving periods	
PRE-TE	ST CONDITIONS: Li	nk out of service			
CONFIC	GURATION: 1		ТҮРЕ О	F TEST: VAT	
EXPEC	ΓED SIGNAL UNIT SE	QUENCE:			
	SP B			SP A	
Link			Link		
		<	1 - 0	SIOS	
1 - 0	SIOS	>			
				: start	
		<	1 - 0	SIO	
1 - 0	SIO	>			
		<	1 - 0	SIN	
1 - 0	SIN	>			
1 - 0	corrupt LSSUs	>			
		<	1 - 0	SIN	
1 - 0	SIN	>			
1 - 0	corrupt LSSUs	>			
		<	1 - 0	SIN	
1 - 0	SIN	>			
1 - 0	corrupt LSSUs	>			
		<	1 - 0	SIN	
1 - 0	SIN	>			
1 - 0	corrupt LSSUs	>			
		<	1 - 0	SIN	
1 - 0	SIN	>			
1 - 0	corrupt LSSUs	>			
< 1 – 0 SIOS					
TEST D	ESCRIPTION				
1. St	art link at A.				
2. G	enerate x number of cor	rupt LSSUs (e.g. CRC error) at B	$(x \ge Tin)$ .		
3. Observe that 5 proving period attempts are made before link out of service state.					

TEST	ΓNU	MBER: 7.4		PAGE: 1 OF 1		
REFI	REFERENCE: Q.703 Subclause 10.3 STD: Fig. 9; Fig. 11; Fig. 17					
TITL	E: A	AERM check				
SUB	ΓΙΤL	E: Error rate at the emer	gency threshold			
PURI	POSE	E: To test the AERM at t	he emergency threshold			
PRE-	TES	Γ CONDITIONS: Link (	out of service			
CON	FIGU	JRATION: 1		TYPE OF	TEST: VAT	
EXPI	ECTE	ED SIGNAL UNIT SEQU	JENCE:			
Link  1-0  1-0  1-0  1-0  1-0  T4 (Pe)		SP B  SIOS  SIO  SIE  corrupt LSSU SIE	<> <> <> <> <> <> <> <> <> <>	Link 1-0 1-0 1-0 1-0	SP A  SIOS  : start SIO  SIN  SIN  FISU	
TEST DESCRIPTION						
1. 2. 3.	<ol> <li>Start link at A, check emergency proving started from B.</li> <li>Generate x number of corrupt LSSUs (e.g. CRC error) at B (5 &gt; x ≥ Tie).</li> </ol>					

TEST N	UMBER: 8.1		PAGE:	1 OF 1
REFERI	ENCE: Q.703 Subclause	5.2 STD: Fig. 13; Fig. 14	- 	
TITLE:	Transmission and recepti	on control (Basic)		
SUBTIT	TLE: MSU transmission a	and reception		
PURPO	SE: To check basic MSU	transmission and reception		
PRE-TE	ST CONDITIONS: Link	in service		
CONFIG	GURATION: 1		TYPE C	OF TEST: VAT, CPT
EXPEC'	TED SIGNAL UNIT SEQ	UENCE:		
	SP B			SP A
Link			Link	
		<	1 - 0	FISU
1 - 0	FISU	>		
1 - 0	MSU	>		
	(FIB + FSN = 80)			
	(BIB + BSN = FF)		1 ^	FIGU
		<	1 - 0	FISU (FIR + FSN - FF)
				(FIB + FSN = FF) (BIB + BSN = 80)
1 – 0	FISU	>		(nm   nnu – 00)
1 0	(FIB + FSN = 80)	/		
	(BIB + BSN = FF)			
	,	<	1 - 0	MSU
				(FIB + FSN = 80)
				(BIB + BSN = 80)
1 - 0	FISU	>		
	(FIB + FSN = 80)			
	(BIB + BSN = 80)			
		<	1 - 0	FISU (FIR. FISN. 90)
				(FIB + FSN = 80)
				(BIB + BSN = 80)
TEST D	ESCRIPTION			
	enerate an MSU at B.			
		(SU correctly, and returns a posi	tive acknowl	edgement.
	enerate an MSU at A.			
4. C	heck that B receives the M	SU correctly, and returns a posi	tive acknowl	edgement.

TEST	TEST NUMBER: 8.2 PAGE: 1 OF 1					
REFERENCE: Q.703 Subclause 5.3 STD: Fig. 13						
TITL	TITLE: Transmission and reception control (Basic)					
SUB	SUBTITLE: Negative acknowledgement of an MSU					
PURI	POSE: To test the response to	a negatively acknowledged MSU	J			
PRE-	TEST CONDITIONS: Link in	n service				
CON	FIGURATION: 1		TYPE OF	TEST: VAT		
EXPI	ECTED SIGNAL UNIT SEQUI	ENCE:				
	SP B			SP A		
Link			Link			
		<	1 - 0	FISU		
1 – 0	EICH		- *			
1-0	FISU	> <	1 – 0	MSU $(FIB + FSN = 80)$		
		<	1 – 0	MSU $(FIB + FSN = 81)$		
1 – 0	FISU $(BIB + BSN = 7F)$	>		,		
	,	<	1 – 0	MSU $(FIB + FSN = 00)$		
		<	1 - 0	MSU		
		·	1 0	(FIB + FSN = 01)		
TEST	DESCRIPTION					
1.	Send MSU from A.					
2.	Reply with negative acknowle	dgement from B.				
3.	Check that A retransmits the N					

TEST NUMBER: 8.3 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 5.3 STD: Fig. 13 TITLE: Transmission and reception control (Basic) SUBTITLE: Check RTB full PURPOSE: To check that MSUs are buffered when no acknowledgements are received PRE-TEST CONDITIONS: Link in service TYPE OF TEST: VAT CONFIGURATION: 1 EXPECTED SIGNAL UNIT SEQUENCE: SP В SP A Link Link 1 - 0**FISU** <-----1 - 0**FISU** ----> (BIB + BSN = FF)1 - 0MSU (FIB + FSN = 80)<-----1 - 0**MSU** (FIB + FSN = FE)1 - 0**FISU** (FIB + FSN = FE)1 - 0FISU (BIB + BSN = 7F)<-----1 - 0**MSU** (FIB + FSN = 00)<-----1 - 0**MSU** (FIB + FSN = 7E)**TEST DESCRIPTION** 

- 1. Generate MSUs at A, at a rate of 100 per second, in order to fill the RTB before the EDA timer T7 expires.
- 2. No acknowledgements are sent from B until the last message is received, then send negative acknowledgement to the first message received.
- 3. Check that the complete contents of the RTB are retransmitted.

TEST NUMBER: 8.4 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 5.2 STD: Fig. 14 TITLE: Transmission and reception control (Basic) SUBTITLE: Single MSU with erroneous FIB PURPOSE: To ensure correct performance when an MSU with erroneous FIB is received PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP A Link Link 1 - 0<-----**FISU** (BIB + BSN = 7F)1 - 0**FISU** (FIB + FSN = 7F)1 - 0**MSU** (FIB + FSN = 80)1 - 0**FISU** <-----(BIB + BSN = 7F)1 - 0**FISU** (FIB + FSN = 00)1 - 0**FISU** (FIB + FSN = 00)1 - 0**FISU** (BIB + BSN = FF)1 - 0**MSU** (FIB + FSN = 80)1 - 0**FISU** (BIB + BSN = 80)TEST DESCRIPTION 1. Generate an MSU at B with FIB inverted. 2. Check A discards the MSU. 3. Generate 2 FISUs at B with correct FIB. 4. Check A discards the FISU and negative acknowledgement returned. 5. Check that B retransmits the MSU correctly, and positive acknowledgement returned.

PAGE: 1 OF 1 TEST NUMBER: 8.5 REFERENCE: Q.703 Subclause 5.2 STD: Fig. 14 TITLE: Transmission and reception control (Basic) SUBTITLE: Duplicated FSN PURPOSE: To test the reception control response to duplicated FSNs PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** 1 - 0**FISU** 1 - 0**MSU** (FIB + FSN = 80)1 - 0**FISU** (BIB + BSN = 80)----> 1 - 0**MSU** (FIB + FSN = 80)1 - 0**FISU** (FIB + FSN = 81)1 - 0**FISU** (BIB + BSN = 00)1 - 0**MSU** (FIB + FSN = 01)1 - 0**FISU** (BIB + BSN = 01)**TEST DESCRIPTION** Generate an MSU at B, check A receives the MSU correctly and returns a positive 1. acknowledgement. 2. Duplicate the FSN at B, check that A responds with a negative acknowledgement. 3. Retransmit the MSU with correct FSN, check that A replies with a positive acknowledgement.

TEST NUMBER: 8.6 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 5.2 STD: Fig. 14 TITLE: Transmission and reception control (Basic) SUBTITLE: Erroneous retransmission – Single MSU PURPOSE: To test the reception control response to retransmission of a single MSU PRE-TEST CONDITIONS: Link in service TYPE OF TEST: VAT CONFIGURATION: 1 EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** <-----(BIB + BSN = FF)1 - 0**FISU** ----> (FIB + FSN = FF)1 - 0**MSU** (FIB + FSN = 00)1 - 0**FISU** (FIB + FSN = 80)1 - 0**FISU** (FIB + FSN = 80)<-----1 - 0**FISU** (BIB + BSN = 7F)1 - 0**MSU** (FIB + FSN = 00)1 - 0**FISU** (BIB + BSN = 00)**TEST DESCRIPTION** 1. A single MSU with FIB inverted in error is sent to A, followed by FISUs with correct FIBs. 2. Check that A returns a negative acknowledgement for the MSU. 3. Retransmit the MSU correctly.

Check that A receives the MSU correctly and returns a positive acnowledgement.

4.

TEST	NUMBER: 8.7		PAGE: 1 OF 1		
REFERENCE: Q.703 Subclause 5.3 STD: Fig. 14					
TITL	E: Transmission and recepti	on control (Basic)			
SUB	ΓΙΤLE: Erroneous retransmi	ssion – Multiple FISUs			
PURI	POSE: To test reception con	trol response to retransmission of	multiple FIS	SUs	
PRE-	TEST CONDITIONS: Link	in service			
CON	FIGURATION: 1		TYPE OF	FTEST: VAT	
EXPI	ECTED SIGNAL UNIT SEQ	UENCE:	1		
Link	SP B		Link	SP A	
1 – 0	FISU (FIB + FSN = FF)	<>	1 – 0	FISU	
1-0	FISU $(FIB + FSN = 7F)$	>			
1-0	FISU $(FIB + FSN = FF)$	>			
1-0	FISU ( $FIB + FSN = 7F$ )	>			
		<	1 – 0	SIOS	
TEST	DESCRIPTION				
1.	Generate FISUs with the FII	B inverted at B.			
2.	Check that A responds with link out of service.				

TEST NUMBER: 8.8	PAGE: 1 OF 1				
REFERENCE: Q.703 Subclause 5.3 STD: Fig. 14					
TITLE: Transmission and reception control (Basic)					
SUBTITLE: Single FISU with corrupt FIB					
PURPOSE: To test the response to receive an FISU with a corrupt F	ІВ				
PRE-TEST CONDITIONS: Link in service					
CONFIGURATION: 1	TYPE OF TEST: VAT				
EXPECTED SIGNAL UNIT SEQUENCE:					
SP B Link	SP A Link				
<> 1 – 0 FISU> (FIB + FSN = FF)	1 – 0 FISU				
1 - 0   FISU  > $(FIB + FSN = 7F)$					
<> 1 – 0 FISU> (FIB + FSN = FF)	1-0 FISU				
<	1-0 FISU				
TEST DESCRIPTION					
1. Generate one FISU with a corrupt FIB at B, and check that the link status remains in service.					

TEST	NUMBER: 8.9		PAGE: 1 OF 1		
REFE	RENCE: Q.703 Subclause 5	.2 STD: Fig. 10; Fig. 14			
TITL	TITLE: Transmission and reception control (Basic)				
SUBT	TITLE: Single FISU prior to	RPO being set			
PURF	POSE: To test the response to	RPO while in the abnormal FIB	state		
PRE-	ΓΕST CONDITIONS: Link i	n service			
CONI	FIGURATION: 1		TYPE O	F TEST: VAT	
EXPE	CTED SIGNAL UNIT SEQU	JENCE:			
Link	SP B		Link	SP A	
Liiik		<	1 – 0	FISU	
1 – 0	FISU	>			
1 – 0	FISU (one only) (FIB + FSN = 7F)	>			
1 - 0	SIPO	>			
1 – 0	MSU $(FIB + FSN = 80)$	>			
1 – 0	FISU ( $FIB + FSN = 80$ )	> ^{a)}			
1 – 0	FISU $(FIB + FSN = 80)$	>			
	,	<	1 – 0	FISU $(BIB + BSN = 7F)$	
1 – 0	MSU (FIB + FSN = 00)	>			
		<	1 – 0	FISU $(BIB + BSN = 00)$	
a) RF	O at A has recovered, but this	FISU is discarded.			
TEST	DESCRIPTION				
1.	Generate one FISU at B with	abnormal FIB.			
2.	Send SIPO from B, followed	by an MSU.			
3.	·				

TEST	NUMBER: 8.10		PAGE:	1 OF 1	
REF	REFERENCE: Q.703 Subclause 5.3 STD: Fig. 14				
TITL	E: Transmission and reception	on control (Basic)			
SUB	ΓΙΤLE: Abnormal BSN – Sir	ngle MSU			
PURI	POSE: To test the response to	an abnormal BSN			
PRE-	TEST CONDITIONS: Link	in service			
CON	CONFIGURATION: 1 TYPE OF TEST: VAT				
EXPECTED SIGNAL UNIT SEQUENCE:					
	SP B			SP A	
Link			Link		
		<	1 - 0	FISU	
1 - 0	FISU (EID + ESN - EE)	>			
	(FIB + FSN = FF) (BIB + BSN = FF)				
1-0	MSU	>			
1 0	(FIB + FSN = 80)	·			
	(BIB + BSN = BF)				
1 – 0	FISU	a)			
	(FIB + FSN = 80)				
	(BIB + BSN = FF)				
1 - 0	FISU	>			
	(FIB + FSN = 80) (BIB + BSN = FF)				
	(DID + DSIN = 11)	<	1 – 0	FISU	
			1 0	(BIB + BSN = 7F)	
1 – 0	MSU	>		,	
	(FIB + FSN = 00)				
	(BIB + BSN = FF)				
		<	1 - 0	FISU	
				(BIB + BSN = 00)	
a) Th	ough UNB: =1, abnormal BS	NR is not cancelled.			
TEST	DESCRIPTION				
1.		abnormal BSN at B, followed b	w FISHe with	a correct RSN	
2.	· ·	a negative acknowledgement.	/y 1 1508 WIUI	COHOCI DOIN.	
3.	Retransmit the MSU correctl				
4.		ved correctly and positive ackno	wledgement	is given.	

TEST	NUMBER: 8.11	PAGE:	1 OF 1		
REFI	ERENCE: Q.703 Subclause 5	.3 STD: Fig. 14			
TITL	E: Transmission and reception	on control (Basic)			
SUB	ΓΙΤLE: Abnormal BSN – Tw	o consecutive FISUs			
PURI	POSE: To test the response to	abnormal BSNs in two consec	eutive FISUs		
PRE-	TEST CONDITIONS: Link i	n service			
CON	FIGURATION: 1		ТҮРЕ О	F TEST: VAT	
EXPI	ECTED SIGNAL UNIT SEQU	JENCE:			
Link	SP B		Link	SP A	
2		<	1 – 0	FISU	
1 – 0	FISU $(BIB + BSN = FF)$	>	2 0	1150	
1 – 0	FISU $(BIB + BSN = BF)$	>			
1 – 0	FISU $(BIB + BSN = BF)$	>			
1 – 0	FISU $(BIB + BSN = FF)$	>			
		<	1 – 0	SIOS	
TEST	DESCRIPTION				
1.	Generate two consecutive FIS	SUs at B with abnormal BSNs.			
2.	Check that A responds by tak	ing the link out of service.			

TEST NUMBER: 8.12 PAGE: 1 OF 1

REFERENCE: Q.703 Subclause 5.3 STD: Fig. 14

TITLE: Transmission and reception control (Basic)

SUBTITLE: Excessive delay of acknowledgement

PURPOSE: To test the transmission control response to the expiration of EDA timer T7

PRE-TEST CONDITIONS: Link in service

CONFIGURATION: 1 TYPE OF TEST: VAT

EXPECTED SIGNAL UNIT SEQUENCE:

(BIB + BSN = FF)

SP B SP A

Link Link

<----- 1 – 0 FISU

1 – 0 FISU ----->

<----- 1-0 MSU (FIB + FSN = 80)

<----- 1 – 0 SIOS

## **TEST DESCRIPTION**

- 1. Generate an MSU at A.
- 2. Discard the received MSU at B and send no acknowledgement to A for more than T7 period.
- 3. Check that the link is taken out of service by SIOS generated at A after T7 has expired.
- 4. Timer T7 shall be in the range 0.5 secs to 2.0 secs.

TEST	ΓNUMBER: 8.13		PAGE: 1	OF 1	
REF	ERENCE: Q.703 Clause 7	STD: Fig. 14			
TITL	E: Transmission and recep	otion control (Basic)			
SUB	TITLE: Level 3 Stop comm	nand			
PUR	POSE: To test the response	e to a Stop command			
PRE-	TEST CONDITIONS: Lin	ık in service			
CON	FIGURATION: 1		TYPE OF	TEST: VAT	
EXP	ECTED SIGNAL UNIT SE	QUENCE:	1		
	SP B			SP A	
Link			Link		
		<	1 - 0	FISU	
1-0	FISU	>			
				: stop	
		<	1 - 0	SIOS	
		<u> </u>			
TEST	TEST DESCRIPTION				
1.	Give Stop command at A.				
2.	Check that A responds wit	h link out of service.			

TEST N	UMBER: 9.1		PAGE: 1	OF 1			
REFER	REFERENCE: Q.703 Subclause 6.2 STD: Fig. 15; Fig. 16						
TITLE:	Transmission and reception co	ontrol (PCR)					
SUBTIT	TLE: MSU transmission and re	ception					
PURPO	SE: To check basic MSU trans	smission and reception					
PRE-TE	ST CONDITIONS: Link in se	ervice					
CONFIG	GURATION: 1		TYPE OF	TEST: VAT, CPT			
EXPEC	TED SIGNAL UNIT SEQUEN	CE:					
* • •	SP B		· · ·	SP A			
Link			Link				
		<	1 – 0	FISU $(FSN = 7F, BSN = 7F)$			
1 – 0	FISU $(FSN = 7F, BSN = 7F)$	>					
	(ISIV 71, BSIV 71)	<	1 – 0	MSU $(FSN = 0, BSN = 7F)$			
		<	1 – 0	MSU (FSN = 0, BSN = 7F)			
				•			
1 – 0	FISU $(FSN = 7F, BSN = 0)$	>		-			
		<	1 – 0	FISU $(FSN = 0, BSN = 7F)$			
1 – 0	MSU $(FSN = 0, BSN = 0)$	>					
		<	1 – 0	FISU $(FSN = 0, BSN = 0)$			
TEST D	ESCRIPTION						
1. G	enerate an MSU at A.						
	heck that B receives the MSU c	•					
	heck that A sends FISUs after r	eceiving an FISU with a posit	ive acknowl	edgement.			
4. G	enerate an MSU at B.						

Check that A receives the MSU correctly and returns a positive acknowledgement.

5.

	NUMBER: 9.2		PAGE: 1	OF 1
	ERENCE: Q.703 Subclause 6.3	<u> </u>		
TITL	E: Transmission and reception co	ontrol (PCR)		
SUB	FITLE: Priority control			
PURI	POSE: To check the preventive re	etransmission procedure		
PRE-	TEST CONDITIONS: Link in se	ervice		
CON	FIGURATION: 1		TYPE OF	FTEST: VAT
EXPI	ECTED SIGNAL UNIT SEQUEN	CE:		
	SP B		T 1 1	SP A
Link		<	Link 1 – 0	FISU
		<b>&lt;</b>	1 – 0	(FSN = 7F, BSN = 7F)
1-0	FISU	>		
	(FSN = 7F, BSN = 7F)		1 0	MOLL
		<	1 - 0	MSU $(FSN = 0, BSN = 7F)$
		<	1 - 0	MSU O, BSIV 717
				(FSN = 1, BSN = 7F)
				•
		<	1 - 0	MSU
		•	1 0	(FSN = 2, BSN = 7F)
				•
		<	1 – 0	MSU
		<b>\</b>	1 – 0	(FSN = 0, BSN = 7F)
		<	1 - 0	MSU
		<	1 – 0	(FSN = 1, BSN = 7F) MSU
		<b>\</b>	1 – 0	(FSN = 2, BSN = 7F)
				•
1 0	FISU			•
1-0	(FSN = 7F, BSN = 0)	>		
1 – 0	FISU	>		
4 0	(FSN = 7F, BSN = 1)			
1 - 0	FISU $(FSN = 7F, BSN = 2)$	>		
	(1.511 - 71, 1.511 - 2)	<	1 - 0	FISU
				(FSN = 2, BSN = 7F)
<u> </u>	DESCRIPTION			
1.	Generate two MSUs at A.			
2.	No positive acknowledgement is			
3.	Check that MSUs are retransmitted. Generate another MSU at A	ed at A.		
- 4	Grenerale anomer MIST A			

- 4. Generate another MSU at A.
- 5. Check that B receives MSUs correctly.
- 6. Reply with positive acknowledgement at B.
- 7. Check that A stops retransmission after receiving the positive acknowledgement for the last MSU in RTB and sends FISU.

ILD.	ΓNUMBER: 9.3		PAGE:	1 OF 1
REF	ERENCE: Q.703 Subclause 6.4	4 STD: Fig. 15		
TITL	E: Transmission and reception	n control (PCR)		
SUB	TITLE: Forced retransmission	with the value N ₁		
PUR	POSE: To check that "RTB fu	ll" is detected by N ₁ and force	ed retransmis	ssion occurs
PRE-	TEST CONDITIONS: Link in	ı service		
CON	FIGURATION: 1		TYPE (	OF TEST: VAT
EXP	ECTED SIGNAL UNIT SEQU	ENCE:		
	SP B			SP A
Link		<	Link 1 – 0	FISU (FSN = 7F, BSN = 7F)
1 – 0	FISU (FSN = 7F, BSN = 7F)	>	1 – 0	MSU
		<u> </u>	1 – 0	(FSN = 0, BSN = 7F)
		<	1 – 0	MSU $(FSN = 7E, BSN = 7F)$
		<	1 – 0	MSU  (FSN = 0, BSN = 7F)
1 – 0	FISU	<>	1 – 0	MSU (FSN = X, BSN = 7F)
1-0	(FSN = 7F, BSN = 0)	<	1 – 0	MSU $(FSN = X + 1, BSN = 7F)$
		<	1 – 0	MSU (FSN = 7F, BSN = 7F)
TEST	Γ DESCRIPTION			
1.	Generate 128 MSUs at A, at a	a rate of 100 per second, in o	order to fill t	he RTB before the EDA
2	timer T7 expires.	tic cont from D until a fame of	rotronomicai	on starts at $\Lambda$
2. 3.	No positive acknowledgement Reply with a positive acknowledgement			
4.	Check that the forced retransn		_	
	NOTE – $N_1$ is the maximum normally 1	number of MSUs which are av		

		,		
TEST	Γ NUMBER: 9.4		PAGE	: 1 OF 1
REFI	ERENCE: Q.703 Subclause 6.4	STD: Fig. 15		
TITL	E: Transmission and reception	control (PCR)		
SUB'	FITLE: Forced retransmission v	vith the value N ₂		
PUR	POSE: To check that "RTB full"	is detected by N2 and force	ed retransmi	ssion starts
PRE-	TEST CONDITIONS: Link in	service		
CON	FIGURATION: 1		TYPE	OF TEST: VAT
EXP	ECTED SIGNAL UNIT SEQUE	NCE:		
T 11.	SP B		T 11.	SP A
Link		<	Link 1 – 0	FISU (FSN = 7F, BSN = 7F)
1-0	FISU  (FSN = 7F, BSN = 7F)	>		,
		<	1 – 0	MSU (FSN = 0, BSN = 7F)
		<	1 – 0	MSU (FSN = N – 1, BSN = 7F)
		<	1 – 0	MSU (FSN = 0, BSN = 7F)
		<	1 – 0	MSU $(FSN = X, BSN = 7F)$
1 - 0	FISU $(FSN = 7F, BSN = a - 1)$	>		
	(1817 71, 2817 4 1)	<	1 – 0	MSU $(FSN = a, BSN = 7F)$
		<	1 – 0	MSU $(FSN = N, BSN = 7F)$ $(a > X)$
TEST	T DESCRIPTION			
1.	Generate N + 1 MSUs at A (the	octet count of N MSUs is 1	arger than N	J ₂ )
2.	Send no positive acknowledgen		C	<del>-</del> ,
3.	Check that B receives the MSU with FSN = N.			
1	D 1 24 22 1 1	1 4 24 DCN 1	4 D	

- 4. Reply with a positive acknowledgement with BSN = a 1 at B.
- 5. Check that the retransmission restarts from the next value of FSN which is acknowledged by B when the retransmission is interrupted.
- 6. Check that B receives the MSU with FSN = N.
  - $NOTE N_2$  is the maximum number of octets which are available for retransmission.

TEST NUMBER: 9.5 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.4 STD: Fig. 15 TITLE: Transmission and reception control (PCR) SUBTITLE: Forced retransmission cancel PURPOSE: To check that the forced retransmission is cancelled when BSN equal to FSNL is received PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP A Link Link 1 - 0**FISU** <-----(FSN = 7F, BSN = 7F)**FISU** 1 - 0----> (FSN = 7F, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)**MSU** 1 - 0(FSN = 7E, BSN = 7F)1 - 0<-----**MSU** (FSN = 0, BSN = 7F)**MSU** <-----1 - 0(FSN = X, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 7E)1 - 0**MSU** (FSN = 7F, BSN = 7F)**TEST DESCRIPTION** 1. Generate  $N_1 + 1$  MSUs at A (e.g. 128). 2. Send no positive acknowledgement at B until a retransmission occurs at A. 3. Reply with a positive acknowledgement with BSN = 7E at B. 4. Check that a forced retransmission is cancelled and the MSU with FSN = 7F is sent at A. NOTE 1 – FSNL is the FSN of the last MSU in RTB. NOTE 2 – Alternatively, the number of octets threshold (N₂), instead of the number of MSUs thresthold (N₁), could be used to start forced retransmission.

TEST NUMBER: 9.6 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.4 STD: Fig. 15 TITLE: Transmission and reception control (PCR) SUBTITLE: Repetition of forced retransmission PURPOSE: To check that the forced retransmission repeats when "RTB full" is still detected after finishing a forced retransmission PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP A Link Link 1 - 0**FISU** <-----(FSN = 7F, BSN = 7F)1 - 0**FISU** ----> (FSN = 7F, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)1 - 0**MSU** (FSN = 7E, BSN = 7F)1 - 0<-----MSU (FSN = 0, BSN = 7F)**MSU** <-----1 - 0(FSN = 7E, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)**TEST DESCRIPTION** 1. Generate MSUs at A at a rate of N per second, in order to make A repeat a forced

retransmission.

 $(N \ge 127 \div T)$ , where T = lower limit of T7).

- 2. No acknowledgement is sent from B.
- 3. Check that A repeats a forced retransmission.

TEST N	UMBER: 9.7		PAGE:	1 OF 1
REFERI	ENCE: Q.703 Subclause 6.2	STD: Fig. 15		
TITLE:	Transmission and reception	control (PCR)		
SUBTIT	LE: MSU transmission whil	e RPO set		
PURPOS	SE: To ensure correct perform	mance while RPO is set		
PRE-TE	ST CONDITIONS: Link in	service		
CONFIC	GURATION: 1		ТҮРЕ О	F TEST: VAT
	ΓED SIGNAL UNIT SEQUE	NCE:		
2	SP B			SP A
Link		<	Link 1 – 0	FISU (FSN = 7F, BSN = 7F)
1 – 0	FISU (FSN = 7F, BSN = 7F)	>		(1511 – 71, B511 – 71)
		<	1 – 0	MSU $(FSN = 0, BSN = 7F)$
	: set LPO			: :
1 – 0	SIPO $(FSN = 7F, BSN = 7F)$	>		
		<	1 – 0	FISU $(FSN = 0, BSN = 7F)$
	: clear LPO			: :
1 – 0	MSU $(FSN = 0, BSN = 7F)$	>		
		<	1 – 0	FISU $(FSN = 7F, BSN = 0)$
1 – 0	MSU $(FSN = 0, BSN = 7F)$	>		
	,	<	1 – 0	FISU $(FSN = 7F, BSN = 0)$

#### TEST DESCRIPTION

- 1. Generate an MSU at A.
- 2. Instead of sending positive acknowledgement, set and keep PO at B for at least 1.2 s.
- 3. Check A stops a retransmission of the MSU and sends FISUs and does not detect link failure by the expiration of T7.
- 4. Cease PO after at least 1.2 s and send an MSU with no positive acknowledgement at B.
- 5. Check A flushed its buffer and no old MSU is sent.
- 6. Generate an MSU at B.
- 7. Check A receives the MSU and responds correctly.

TEST NUMBER: 9.8 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.3 STD: Fig. 16 TITLE: Transmission and reception control (PCR) SUBTITLE: Abnormal BSN – Single MSU PURPOSE: To test the response to an abnormal BSN PRE-TEST CONDITIONS: Link in service TYPE OF TEST: VAT CONFIGURATION: 1 EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** (FSN = 7F, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 7F)1 - 0**MSU** (FSN = 0, BSN = 0)1 - 0**MSU** (FSN = 0, BSN = 7F)1 - 0MSU (FSN = 0, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 0)**TEST DESCRIPTION** 1. Generate a single MSU at B with abnormal BSN followed by retransmission of that MSU with normal BSN. 2. Check that A responds with a positive acknowledgement and not detect link failure.

TEST NUMBER: 9.9 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.3 STD: Fig. 16 TITLE: Transmission and reception control (PCR) SUBTITLE: Abnormal BSN - Two MSUs PURPOSE: To test the response to two consecutive MSUs with an MSU having normal BSN between them PRE-TEST CONDITIONS: Link in service TYPE OF TEST: VAT CONFIGURATION: 1 EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** (FSN = 7F, BSN = 7F)**FISU** 1 - 0(FSN = 7F, BSN = 7F)1 - 0**MSU** (FSN = 0, BSN = 7E)1 - 0**MSU** (FSN = 0, BSN = 7F)1 - 0**MSU** (FSN = 0, BSN = 7E)<-----1 - 0**SIOS** (FSN = 7F, BSN = 7F)**TEST DESCRIPTION** 1. Generate two consecutive MSUs at B with abnormal BSN with an MSU having normal BSN between them. Check that all MSUs are discarded at A. 2. 3. Check that A responds by taking the link out of service.

TEST NUMBER: 9.10 PAGE: 1 OF 1

REFERENCE: Q.703 Subclause 6.2 STD: Fig. 16

TITLE: Transmission and reception control (PCR)

SUBTITLE: Unexpected FSN

PURPOSE: To check the reception control response to an MSU with unexpected FSN

PRE-TEST CONDITIONS: Link in service

CONFIGURATION: 1 TYPE OF TEST: VAT

EXPECTED SIGNAL UNIT SEQUENCE:

SP B SP A

Link

(FSN = 7F, BSN = 0)

1 – 0 FISU ----->

(FSN = 7F, BSN = 7F)

1 - 0 MSU -----> (FSN = 0, BSN = 7F)

1-0 MSU ----->

(FSN = 2, BSN = 7F) <----- 1 - 0 FISU

**TEST DESCRIPTION** 

- 1. Generate an MSU with unexpected FSN at B.
- 2. Check A discards the MSU with unexpected FSN and does not send acknowledgement for that MSU.

TEST NUMBER: 9.11 PAGE: 1 OF 1

REFERENCE: Q.703 Subclause 6.3 STD: Fig. 15

TITLE: Transmission and reception control (PCR)

SUBTITLE: Excessive delay of acknowledgement

PURPOSE: To test the transmission control response to the expiration of EDA timer T7

PRE-TEST CONDITIONS: Link in service

CONFIGURATION: 1 TYPE OF TEST: VAT

EXPECTED SIGNAL UNIT SEQUENCE:

SP B SP A

Link Link

<----- 1-0 FISU (FSN = 7F, BSN = 7F)

1-0 FISU ----->

(FSN = 7F, BSN = 7F)

(FSN = 0, BSN = 7F)

## **TEST DESCRIPTION**

- 1. Generate an MSU at A.
- 2. Suspend sending positive acknowledgement at B for more than T7 period.
- 3. Check that A sends SIOSs instead of retransmission of MSU after T7 expires.
- 4. Timer T7 shall be in the range 0.5 secs to 2.0 secs.

TEST NUMBER: 9.12 PAGE: 1 OF 1 REFERENCE: Q.703 Subclause 6.2 STD: Fig. 16 TITLE: Transmission and reception control (PCR) SUBTITLE: FISU with FSN expected for MSU PURPOSE: To check that the received FISU having FSN expected for MSU is discarded PRE-TEST CONDITIONS: Link in service CONFIGURATION: 1 TYPE OF TEST: VAT EXPECTED SIGNAL UNIT SEQUENCE: SP В SP Α Link Link 1 - 0**FISU** (FSN = 7F, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 7F)1 - 0**FISU** (FSN = 0, BSN = 7F)1 - 0**FISU** (FSN = 7F, BSN = 7F)**TEST DESCRIPTION** 

- 1. Generate an FISU with FSN expected for MSU at B.
- 2. Check that A discards the FISU and responds with an FISU with correct BSN.

TEST NUMBER: 9.13	PAGE: 1 OF 1
REFERENCE: Q.703 Clause 7 STD: Fig. 16	
TITLE: Transmission and reception control (PCR)	
SUBTITLE: Level 3 Stop command	
PURPOSE: To test the response to a Stop command	
PRE-TEST CONDITIONS: Link in service	
CONFIGURATION: 1	TYPE OF TEST: VAT
EXPECTED SIGNAL UNIT SEQUENCE:	
SP B	SP A
Link	Link
<	1-0 FISU
1 – 0 FISU>	
	: stop
<	1-0 SIOS
TEST DESCRIPTION	
Give Stop command at A.	
2. Check that A responds with link out of service.	

TEST	NUMBER: 10.1	PAGE: 1 OF 1	
REFE	RENCE: Q.703 Clause 9 STD: Fig. 19		
TITL	E: Congestion Control		
SUBT	TITLE: Congestion abatement		
PURI	POSE: To check the congestion abatement procedure		
PRE-	TEST CONDITIONS: Link in service		
CON	FIGURATION: 1	TYPE OF	TEST: VAT
EXPE	CTED SIGNAL UNIT SEQUENCE:		
Link	SP B	Link	SP A
			: make congestion state
	<	1 – 0	SIB
		T5	
	<	1 – 0	SIB •
			: clear congestion state
	<	1 – 0	FISU
TEGT	DESCRIPTION		
1	DESCRIPTION		
1.	Make congestion state at A and check A sends SIB. (Implementation of congestion control is not specified.)		
2.	Check B receives SIBs at the interval of T5.		
3.	Clear congestion state at A and check A stops sending SIBs.		
4.	Timer T5 shall be in the range 80 ms to 120 ms.		

TEST	ΓNUMBER: 10.2			PAGE: 1	OF 1
REFI	ERENCE: Q.703 S	Subclause 9	0.2 STD: Fig. 19		
TITL	E: Congestion Co	ontrol			
SUB	TITLE: Timer T7				
PUR	POSE: To check to	imer T7 is 1	restarted at the reception of SIB (w	vithout expir	ing of T6)
PRE-	TEST CONDITIO	NS: Link	in service		
CON	FIGURATION: 1			TYPE OF	TEST: VAT
EXP	ECTED SIGNAL U	JNIT SEQU	JENCE:		
Link  1 - 0  1 - 0  1 - 0	SIB  • SIB	Ct Bt	<> >	Link 1 – 0	SP A  MSU  T6
1-0			>		
TEST	T DESCRIPTION				
1.	Generate an MSU				
2.	, ,				
3.	Check that link remains in service during Ct.				
4.					
5.	Check that link remains in service.				
6.	Ct = more than T7		1an 16.		
7.	Bt = less than T7.				
8.	(Ct + Bt) is less th	nan T6.			

TEST NUMBER: 10.3	PAGE: 1 OF 1
REFERENCE: Q.703 Subclause 9.3 STD: Fig. 19	
TITLE: Congestion Control	
SUBTITLE: Timer T6	
PURPOSE: To check "Remote Congestion" Timer T6	
PRE-TEST CONDITIONS: Link in service	
CONFIGURATION: 1	TYPE OF TEST: VAT
EXPECTED SIGNAL UNIT SEQUENCE:	
SP B	SP A
Link <	Link 1 – 0 MSU
1 – 0 SIB>	
1 – 0 SIB>	
•	T6
1 – 0 SIB>	
•	
1 – 0 SIB>	
<	1 – 0 SIOS
TEST DESCRIPTION	
1. Generate an MSU at A.	
2. Generate SIB at B until Timer T6 expires.	
3. Check link becomes out of service.	
4. Timer T6 shall be in the range 3 secs to 6 secs (8 to 12 secs for	4.8 kbit/s).

# ITU-T RECOMMENDATIONS SERIES

Series A	Organization of the work of the ITU-T
Series B	Means of expression
Series C	General telecommunication statistics
Series D	General tariff principles
Series E	Telephone network and ISDN
Series F	Non-telephone telecommunication services
Series G	Transmission systems and media
Series H	Transmission of non-telephone signals
Series I	Integrated services digital network
Series J	Transmission of sound-programme and television signals
Series K	Protection against interference
Series L	Construction, installation and protection of cables and other elements of outside plant
Series M	Maintenance: international transmission systems, telephone circuits, telegraphy, facsimile and leased circuits
Series N	Maintenance: international sound-programme and television transmission circuits
Series O	Specifications of measuring equipment
Series P	Telephone transmission quality
Series Q	Switching and signalling
Series R	Telegraph transmission
Series S	Telegraph services terminal equipment
Series T	Terminal equipments and protocols for telematic services
Series U	Telegraph switching
Series V	Data communication over the telephone network
Series X	Data networks and open system communication
Series Z	Programming languages